

# 13 Diagnostics

The display on the drive gives various information about the status of the drive. These fall into three categories:

- Trip indications
- Alarm indications
- Status indications



Users must not attempt to repair a drive if it is faulty, nor carry out fault diagnosis other than through the use of the diagnostic features described in this chapter. If a drive is faulty, it must be returned to an authorized Control Techniques distributor for repair.

## 13.1 Trip indications

If the drive trips, the output of the drive is disabled so that the drive stops controlling the motor. The lower display indicates that a trip has occurred and the upper display shows the trip. If this is a multi-module drive and a power module has indicated a trip, then the upper display will alternate between the trip string and the module number.


Trips are listed alphabetically in Table 13-1 based on the trip indication shown on the drive display. Refer to Figure 13-1.

If a display is not used, the drive LED Status indicator will flash if the drive has tripped. Refer to Figure 13-2.

The trip indication can be read in Pr 10.20 providing a trip number. Trip numbers are listed in numerical order in Table 13-2 so the trip indication can be cross referenced and then diagnosed using Table 13-1.

### Example

1. Trip code 3 is read from Pr 10.20 via serial communications.
2. Checking Table 13-2 shows Trip 3 is an OI.AC trip.



3. Look up OI.AC in Table 13-1.
4. Perform checks detailed under *Diagnostics*.

Figure 13-1 Keypad status modes








Figure 13-2 Location of the status LED



Trip	Diagnosis
OI.AC	<b>Instantaneous output over current detected: peak output current greater than 225%</b>
3	Acceleration / deceleration rate is too short. If seen during autotune reduce voltage boost Pr 5.15 Check for short circuit on output cabling Check integrity of motor insulation Check feedback device wiring Check feedback device mechanical coupling Check feedback signals are free from noise Is motor cable length within limits for that frame size? Reduce the values in speed loop gain parameters – Pr 3.10, Pr 3.11 and Pr 3.12 (closed loop vector and servo modes only) Has offset measurement test been completed? (servo mode only) Reduce the values in current loop gain parameters - Pr 4.13 and Pr 4.14 (closed loop vector and servo modes only)

**Table 13-1 Trip indications**

Trip	Diagnosis
<b>C.Acc</b>	<b>SMARTCARD trip: SMARTCARD Read / Write fail</b>
185	Check SMARTCARD is fitted / located correctly Replace SMARTCARD
<b>C.boot</b>	<b>SMARTCARD trip: The menu 0 parameter modification cannot be saved to the SMARTCARD because the necessary file has not been created on the SMARTCARD</b>
177	A write to a menu 0 parameter has been initiated via the keypad with Pr 11.42 set to auto(3) or boot(4), but the necessary file on the SMARTCARD has not been created Ensure that Pr 11.42 is correctly set and reset the drive to create the necessary file on the SMARTCARD Re-attempt the parameter write to the menu 0 parameter
<b>C.bUSY</b>	<b>SMARTCARD trip: SMARTCARD can not perform the required function as it is being accessed by a Solutions Module</b>
178	Wait for the Solutions Module to finish accessing the SMARTCARD and then re-attempt the required function
<b>C.Chg</b>	<b>SMARTCARD trip: Data location already contains data</b>
179	Erase data in data location Write data to an alternative data location
<b>C.cPr</b>	<b>SMARTCARD trip: The values stored in the drive and the values in the data block on the SMARTCARD are different</b>
188	Press the red  reset button
<b>C.dAt</b>	<b>SMARTCARD trip: Data location specified does not contain any data</b>
183	Ensure data block number is correct
<b>C.Err</b>	<b>SMARTCARD trip: SMARTCARD data is corrupted</b>
182	Ensure the card is located correctly Erase data and retry Replace SMARTCARD
<b>C.Full</b>	<b>SMARTCARD trip: SMARTCARD full</b>
184	Delete a data block or use different SMARTCARD
<b>cL2</b>	<b>Analogue input 2 current loss (current mode)</b>
28	Check analogue input 2 (terminal 7) current signal is present (4-20mA, 20-4mA)
<b>cL3</b>	<b>Analogue input 3 current loss (current mode)</b>
29	Check analogue input 3 (terminal 8) current signal is present (4-20mA, 20-4mA)
<b>CL.bit</b>	<b>Trip initiated from the control word (Pr 6.42)</b>
35	Disable the control word by setting Pr 6.43 to 0 or check setting of Pr 6.42
<b>C.OPtn</b>	<b>SMARTCARD trip: Solutions Modules fitted are different between source drive and destination drive</b>
180	Ensure correct Solutions Modules are fitted Ensure Solutions Modules are in the same Solutions Module slot Press the red  reset button
<b>C.rdo</b>	<b>SMARTCARD trip: SMARTCARD has the Read Only bit set</b>
181	Enter 9777 in Pr xx.00 to allow SMARTCARD Read / Write access Ensure card is not writing to data locations 500 to 999

Trip	Diagnosis																												
<b>C.rtg</b>	<b>SMARTCARD trip: SMARTCARD attempting to change the destination drive ratings No drive rating parameters have been transferred</b>																												
<b>186</b>	<p>Press the red  reset button Drive rating parameters are:</p> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td><b>2.08</b></td> <td>Standard ramp voltage</td> </tr> <tr> <td><b>4.05/6/7, 21.27/8/9</b></td> <td>Current limits</td> </tr> <tr> <td><b>4.24</b></td> <td>User current maximum scaling</td> </tr> <tr> <td><b>5.07, 21.07</b></td> <td>Motor rated current</td> </tr> <tr> <td><b>5.09, 21.09</b></td> <td>Motor rated voltage</td> </tr> <tr> <td><b>5.10, 21.10</b></td> <td>Rated power factor</td> </tr> <tr> <td><b>5.17, 21.12</b></td> <td>Stator resistance</td> </tr> <tr> <td><b>5.18</b></td> <td>Switching frequency</td> </tr> <tr> <td><b>5.23, 21.13</b></td> <td>Voltage offset</td> </tr> <tr> <td><b>5.24, 21.14</b></td> <td>Transient inductance</td> </tr> <tr> <td><b>5.25, 21.24</b></td> <td>Stator inductance</td> </tr> <tr> <td><b>6.06</b></td> <td>DC injection braking current</td> </tr> <tr> <td><b>6.48</b></td> <td>Mains loss ride through detection level</td> </tr> </tbody> </table> <p>The above parameters will be set to their default values.</p>	Parameter	Function	<b>2.08</b>	Standard ramp voltage	<b>4.05/6/7, 21.27/8/9</b>	Current limits	<b>4.24</b>	User current maximum scaling	<b>5.07, 21.07</b>	Motor rated current	<b>5.09, 21.09</b>	Motor rated voltage	<b>5.10, 21.10</b>	Rated power factor	<b>5.17, 21.12</b>	Stator resistance	<b>5.18</b>	Switching frequency	<b>5.23, 21.13</b>	Voltage offset	<b>5.24, 21.14</b>	Transient inductance	<b>5.25, 21.24</b>	Stator inductance	<b>6.06</b>	DC injection braking current	<b>6.48</b>	Mains loss ride through detection level
Parameter	Function																												
<b>2.08</b>	Standard ramp voltage																												
<b>4.05/6/7, 21.27/8/9</b>	Current limits																												
<b>4.24</b>	User current maximum scaling																												
<b>5.07, 21.07</b>	Motor rated current																												
<b>5.09, 21.09</b>	Motor rated voltage																												
<b>5.10, 21.10</b>	Rated power factor																												
<b>5.17, 21.12</b>	Stator resistance																												
<b>5.18</b>	Switching frequency																												
<b>5.23, 21.13</b>	Voltage offset																												
<b>5.24, 21.14</b>	Transient inductance																												
<b>5.25, 21.24</b>	Stator inductance																												
<b>6.06</b>	DC injection braking current																												
<b>6.48</b>	Mains loss ride through detection level																												
<b>C.TyP</b>	<b>SMARTCARD trip: SMARTCARD parameter set not compatible with drive</b>																												
<b>187</b>	Press the reset button Ensure destination drive type is the same as the source parameter file drive type																												
<b>dEst</b>	<b>Two or more parameters are writing to the same destination parameter</b>																												
<b>199</b>	Set Pr <b>xx.00</b> = 12001 check all visible parameters in the menus for duplication																												
<b>EEF</b>	<b>EEPROM data corrupted - Drive mode becomes open loop and serial comms will timeout with remote keypad on the drive RS485 comms port.</b>																												
<b>31</b>	This trip can only be cleared by loading default parameters and saving parameters																												
<b>Enc1</b>	<b>Drive encoder trip: Encoder power supply overload</b>																												
<b>189</b>	Check encoder power supply wiring and encoder current requirement Maximum current = 200mA @ 15V, or 300mA @ 8V and 5V																												
<b>Enc2</b>	<b>Drive encoder trip: Wire break (Drive encoder terminals 1 &amp; 2, 3 &amp; 4, 5 &amp; 6)</b>																												
<b>190</b>	Check cable continuity Check wiring of feedback signals is correct Check encoder power is set correctly Replace feedback device If wire break detection on the main drive encoder input is not required, set Pr <b>3.40</b> = 0 to disable the Enc2 trip																												
<b>Enc3</b>	<b>Drive encoder trip: Phase offset incorrect whilst running</b>																												
<b>191</b>	Check the encoder signal for noise Check encoder shielding Check the integrity of the encoder mechanical mounting Repeat the offset measurement test																												
<b>Enc4</b>	<b>Drive encoder trip: Feedback device comms failure</b>																												
<b>192</b>	Ensure encoder power supply is correct Ensure baud rate is correct Check encoder wiring Replace feedback device																												
<b>Enc5</b>	<b>Drive encoder trip: Checksum or CRC error</b>																												
<b>193</b>	Check the encoder signal for noise Check the encoder cable shielding With EnDat encoders, check the comms resolution and/or carry out the auto-configuration Pr <b>3.41</b>																												
<b>Enc6</b>	<b>Drive encoder trip: Encoder has indicated an error</b>																												
<b>194</b>	Replace feedback device With SSI encoders, check the wiring and encoder supply setting																												

<b>Trip</b>	<b>Diagnosis</b>
<b>Enc7</b>	<b>Drive encoder trip: Initialisation failed</b>
195	Re-set the drive Check the correct encoder type is entered into Pr 3.38 Check encoder wiring Check encoder power supply is set correctly Carry out the auto-configuration Pr 3.41 Replace feedback device
<b>Enc8</b>	<b>Drive encoder trip: Auto configuration on power up has been requested and failed</b>
196	Change the setting of Pr 3.41 to 0 and manually enter the drive encoder turns (Pr 3.33) and the equivalent number of lines per revolution (Pr 3.34) Check the comms resolution
<b>Enc9</b>	<b>Drive encoder trip: Position feedback selected is selected from a Solutions Module slot which does not have a speed / position feedback Solutions Module fitted</b>
197	Check setting of Pr 3.26 (or Pr 21.21 if the second motor parameters have been enabled)
<b>Enc10</b>	<b>Drive encoder trip: Servo mode phasing failure because encoder phase angle (Pr 3.25 or Pr 21.20) is incorrect</b>
198	Check the encoder wiring. Perform an autotune to measure the encoder phase angle or manually enter the correct phase angle into Pr 3.25 (or Pr 21.20). Spurious Enc10 trips can be seen in very dynamic applications. This trip can be disabled by setting the overspeed threshold in Pr 3.08 to a value greater than zero. Caution should be used in setting the over speed threshold level as a value which is too large may mean that an encoder fault will not be detected.
<b>Enc11</b>	<b>Drive encoder trip: A failure has occurred during the alignment of the analogue signals of a SINCOS encoder with the digital count derived from the sine and cosine waveforms and the comms position (if applicable). This fault is usually due to noise on the sine and cosine signals.</b>
161	Check encoder cable shield. Examine sine and cosine signals for noise.
<b>Enc12</b>	<b>Drive encoder trip: Hiperface encoder - The encoder type could not be identified during auto-configuration</b>
162	Check encoder type can be auto-configured. Check encoder wiring. Enter parameters manually.
<b>Enc13</b>	<b>Drive encoder trip: EnDat encoder - The number of encoder turns read from the encoder during auto-configuration is not a power of 2</b>
163	Select a different type of encoder.
<b>Enc14</b>	<b>Drive encoder trip: EnDat encoder - The number of comms bits defining the encoder position within a turn read from the encoder during auto-configuration is too large.</b>
164	Select a different type of encoder. Faulty encoder.
<b>Enc15</b>	<b>Drive encoder trip: The number of periods per revolution calculated from encoder data during auto-configuration is either less than 2 or greater than 50,000.</b>
165	Linear motor pole pitch / encoder ppr set up is incorrect or out of parameter range i.e. Pr 5.36 = 0 or Pr 21.31 = 0. Faulty encoder.
<b>Enc16</b>	<b>Drive encoder trip: EnDat encoder - The number of comms bits per period for a linear encoder exceeds 255.</b>
166	Select a different type of encoder. Faulty encoder.
<b>Enc17</b>	<b>Drive encoder trip: The periods per revolution obtained during auto-configuration for a rotary SINCOS encoder is not a power of two.</b>
167	Select a different type of encoder. Faulty encoder.
<b>ENP.Er</b>	<b>Data error from electronic nameplate stored in selected position feedback device</b>
176	Replace feedback device
<b>Et</b>	<b>External trip from input on terminal 31</b>
6	Check terminal 31 signal Check value of Pr 10.32 Enter 12001 in Pr xx.00 and check for parameter controlling Pr 10.32 Ensure Pr 10.32 or Pr 10.38 (=6) are not being controlled by serial comms
<b>HF01</b>	<b>Data processing error: CPU address error</b>
	Hardware fault - return drive to supplier

Trip	Diagnosis
<b>HF02</b>	<b>Data processing error: DMAC address error</b>
	Hardware fault - return drive to supplier
<b>HF03</b>	<b>Data processing error: Illegal instruction</b>
	Hardware fault - return drive to supplier
<b>HF04</b>	<b>Data processing error: Illegal slot instruction</b>
	Hardware fault - return drive to supplier
<b>HF05</b>	<b>Data processing error: Undefined exception</b>
	Hardware fault - return drive to supplier
<b>HF06</b>	<b>Data processing error: Reserved exception</b>
	Hardware fault - return drive to supplier
<b>HF07</b>	<b>Data processing error: Watchdog failure</b>
	Hardware fault - return drive to supplier
<b>HF08</b>	<b>Data processing error: Level 4 crash</b>
	Hardware fault - return drive to supplier
<b>HF09</b>	<b>Data processing error: Heap overflow</b>
	Hardware fault - return drive to supplier
<b>HF10</b>	<b>Data processing error: Router error</b>
	Hardware fault - return drive to supplier
<b>HF11</b>	<b>Data processing error: Access to EEPROM failed</b>
	Hardware fault - return drive to supplier
<b>HF12</b>	<b>Data processing error: Main program stack overflow</b>
	Hardware fault - return drive to supplier
<b>HF13</b>	<b>Data processing error: Software incompatible with hardware</b>
	Hardware or software fault - return drive to supplier
<b>HF17</b>	<b>Multi-module system thermistor short circuit</b>
217	Hardware fault - return drive to supplier
<b>HF18</b>	<b>Multi-module system interconnect cable error</b>
218	Hardware fault - return drive to supplier
<b>HF19</b>	<b>Temperature feedback multiplexing failure</b>
219	Hardware fault - return drive to supplier
<b>HF20</b>	<b>Power stage recognition: serial code error</b>
220	Hardware fault - return drive to supplier
<b>HF21</b>	<b>Power stage recognition: unrecognised frame size</b>
221	Hardware fault - return drive to supplier
<b>HF22</b>	<b>Power stage recognition: multi module frame size mismatch</b>
222	Hardware fault - return drive to supplier
<b>HF23</b>	<b>Power stage recognition: multi module voltage rating mismatch</b>
223	Hardware fault - return drive to supplier
<b>HF24</b>	<b>Power stage recognition: unrecognised drive size</b>
224	Hardware fault - return drive to supplier
<b>HF25</b>	<b>Current feedback offset error</b>
225	Hardware fault - return drive to supplier
<b>HF26</b>	<b>Soft start relay failed to close, soft start monitor failed or braking IGBT short circuit at power up</b>
226	Hardware fault - return drive to supplier
<b>HF27</b>	<b>Power stage thermistor 1 fault</b>
227	Hardware fault - return drive to supplier

Safety Information	Product Information	Mechanical Installation	Electrical Installation	Getting Started	Basic Parameters	Running the motor	Optimisation	Smartcard operation	Onboard PLC	Advanced Parameters	Technical Data	Diagnostics	UL Listing Information
<b>Trip</b>	<b>Diagnosis</b>												
<b>HF28</b>	<b>Power stage thermistor 2 fault or internal fan fault (size 3 and larger)</b>												
<b>228</b>	Hardware fault - return drive to supplier												
<b>HF29</b>	<b>Control board thermistor fault</b>												
<b>229</b>	Hardware fault - return drive to supplier												
<b>HF30</b>	<b>DCCT wire break trip from power module</b>												
<b>230</b>	Hardware fault - return drive to supplier												
<b>HF31</b>	<b>Aux fan failure from power module</b>												
<b>231</b>	Replace auxiliary fan												
<b>HF32</b>	<b>Power stage - a module has not powered up in a multi-module parallel drive</b>												
<b>232</b>	Check AC power supply												
<b>It.AC</b>	<b>Output current overload timed out (<math>I^2t</math>) - accumulator value can be seen in Pr 4.19</b>												
<b>20</b>	<p>Ensure the load is not jammed / sticking  Check the load on the motor has not changed  If seen during an autotune in servo mode, ensure that the motor rated current Pr <b>0.46</b> (Pr <b>5.07</b>) or Pr <b>21.07</b> is <math>\leq</math> Heavy Duty current rating of the drive  Tune the rated speed parameter (closed loop vector only)  Check feedback device signal for noise  Check the feedback device mechanical coupling</p>												
<b>It.br</b>	<b>Braking resistor overload timed out (<math>I^2t</math>) – accumulator value can be seen in Pr 10.39</b>												
<b>19</b>	<p>Ensure the values entered in Pr <b>10.30</b> and Pr <b>10.31</b> are correct  Increase the power rating of the braking resistor and change Pr <b>10.30</b> and Pr <b>10.31</b>  If an external thermal protection device is being used and the braking resistor software overload is not required, set Pr <b>10.30</b> or Pr <b>10.31</b> to 0 to disable the trip</p>												
<b>L.SYnC</b>	<b>Drive failed to synchronise to the supply voltage in Regen mode</b>												
<b>39</b>	Refer to the <i>Diagnostics</i> chapter in the <i>Unidrive SP Regen Installation Guide</i> .												
<b>O.CtL</b>	<b>Drive control board over temperature</b>												
<b>23</b>	<p>Check cubicle / drive fans are still functioning correctly  Check cubicle ventilation paths  Check cubicle door filters  Check ambient temperature  Reduce drive switching frequency</p>												
<b>O.ht1</b>	<b>Power device over temperature based on thermal model</b>												
<b>21</b>	<p>Reduce drive switching frequency  Reduce duty cycle  Decrease acceleration / deceleration rates  Reduce motor load</p>												
<b>O.ht2</b>	<b>Heatsink over temperature</b>												
<b>22</b>	<p>Check cubicle / drive fans are still functioning correctly  Check cubicle ventilation paths  Check cubicle door filters  Increase ventilation  Decrease acceleration / deceleration rates  Reduce drive switching frequency  Reduce duty cycle  Reduce motor load</p>												
<b>Oht2.P</b>	<b>Power module heatsink over temperature</b>												
<b>105</b>	<p>Check cubicle / drive fans are still functioning correctly  Check cubicle ventilation paths  Check cubicle door filters  Increase ventilation  Decrease acceleration / deceleration rates  Reduce drive switching frequency  Reduce duty cycle  Reduce motor load</p>												

<b>Trip</b>	<b>Diagnosis</b>
<b>O.ht3</b>	<b>Drive over-temperature based on thermal model</b>
<b>27</b>	The drive will attempt to stop the motor before tripping. If the motor does not stop in 10s the drive trips immediately. Check cubicle / drive fans are still functioning correctly Check cubicle ventilation paths Check cubicle door filters Increase ventilation Decrease acceleration / deceleration rates Reduce duty cycle Reduce motor load
<b>Oht4.P</b>	<b>Power module rectifier over temperature or input snubber resistor over temperature (size 4 and above)</b>
<b>102</b>	Check for supply imbalance Check for supply disturbance such as notching from a DC drive Check cubicle / drive fans are still functioning correctly Check cubicle ventilation paths Check cubicle door filters Increase ventilation Decrease acceleration / deceleration rates Reduce drive switching frequency Reduce duty cycle Reduce motor load
<b>OI.AC</b>	<b>Instantaneous output over current detected: peak output current greater than 225%</b>
<b>3</b>	Acceleration /deceleration rate is too short. If seen during autotune reduce voltage boost Pr <b>5.15</b> Check for short circuit on output cabling Check integrity of motor insulation Check feedback device wiring Check feedback device mechanical coupling Check feedback signals are free from noise Is motor cable length within limits for that frame size? Reduce the values in speed loop gain parameters – Pr <b>3.10</b> , Pr <b>3.11</b> and Pr <b>3.12</b> (closed loop vector and servo modes only) Has offset measurement test been completed? (servo mode only) Reduce the values in current loop gain parameters - Pr <b>4.13</b> and Pr <b>4.14</b> (closed loop vector and servo modes only)
<b>OI.AC.P</b>	<b>Power module over current detected from the module output currents</b>
<b>104</b>	Acceleration /deceleration rate is too short. If seen during autotune reduce voltage boost Pr <b>5.15</b> Check for short circuit on output cabling Check integrity of motor insulation Check feedback device wiring Check feedback device mechanical coupling Check feedback signals are free from noise Is motor cable length within limits for that frame size? Reduce the values in speed loop gain parameters – Pr <b>3.10</b> , Pr <b>3.11</b> and Pr <b>3.12</b> (closed loop vector and servo modes only) Has offset measurement test been completed? (servo mode only) Reduce the values in current loop gain parameters - Pr <b>4.13</b> and Pr <b>4.14</b> (closed loop vector and servo modes only)
<b>OI.br</b>	<b>Braking transistor over-current detected: short circuit protection for the braking transistor activated</b>
<b>4</b>	Check braking resistor wiring Check braking resistor value is greater than or equal to the minimum resistance value Check braking resistor insulation
<b>OI.br.P</b>	<b>Power module braking IGBT over current</b>
<b>103</b>	Check braking resistor wiring Check braking resistor value is greater than or equal to the minimum resistance value Check braking resistor insulation
<b>OldC.P</b>	<b>Power module over current detected from IGBT on state voltage monitoring</b>
<b>109</b>	Vce IGBT protection activated. Check motor and cable insulation.
<b>O.Ld1</b>	<b>Digital output overload: total current drawn from 24V supply and digital outputs exceeds 200mA</b>
<b>26</b>	Check total load on digital outputs (terminals 24,25,26)and +24V rail (terminal 22)
<b>O.SPd</b>	<b>Motor speed has exceeded the over speed threshold</b>
<b>7</b>	Increase the over speed trip threshold in Pr <b>3.08</b> (closed loop modes only) Speed has exceeded 1.2 x Pr <b>1.06</b> or Pr <b>1.07</b> (open loop mode) Reduce the speed loop P gain (Pr <b>3.10</b> ) to reduce the speed overshoot (closed loop modes only)

Trip	Diagnosis															
<b>OV</b>	<b>DC bus voltage has exceeded the peak level or the maximum continuous level for 15 seconds</b>															
2	<p>Increase deceleration ramp (Pr <b>0.04</b>)  Decrease braking resistor value (staying above the minimum value)  Check nominal AC supply level  Check for supply disturbances which could cause the DC bus to rise – voltage overshoot after supply recovery from a notch induced by DC drives.  Check motor insulation</p> <table border="1"> <thead> <tr> <th>Drive voltage rating</th> <th>Peak voltage</th> <th>Maximum continuous voltage level (15s)</th> </tr> </thead> <tbody> <tr> <td>200</td> <td>415</td> <td>410</td> </tr> <tr> <td>400</td> <td>830</td> <td>815</td> </tr> <tr> <td>575</td> <td>990</td> <td>970</td> </tr> <tr> <td>690</td> <td>1190</td> <td>1175</td> </tr> </tbody> </table> <p>If the drive is operating in low voltage DC mode the overvoltage trip level is 1.45 x Pr <b>6.46</b>.</p>	Drive voltage rating	Peak voltage	Maximum continuous voltage level (15s)	200	415	410	400	830	815	575	990	970	690	1190	1175
Drive voltage rating	Peak voltage	Maximum continuous voltage level (15s)														
200	415	410														
400	830	815														
575	990	970														
690	1190	1175														
<b>OV.P</b>	<b>Power module DC bus voltage has exceeded the peak level or the maximum continuous level for 15 seconds</b>															
106	<p>Increase deceleration ramp (Pr <b>0.04</b>)  Decrease braking resistor value (staying above the minimum value)  Check nominal AC supply level  Check for supply disturbances which could cause the DC bus to rise – voltage overshoot after supply recovery from a notch induced by DC drives.  Check motor insulation</p> <table border="1"> <thead> <tr> <th>Drive voltage rating</th> <th>Peak voltage</th> <th>Maximum continuous voltage level (15s)</th> </tr> </thead> <tbody> <tr> <td>200</td> <td>415</td> <td>410</td> </tr> <tr> <td>400</td> <td>830</td> <td>815</td> </tr> <tr> <td>575</td> <td>990</td> <td>970</td> </tr> <tr> <td>690</td> <td>1190</td> <td>1175</td> </tr> </tbody> </table> <p>If the drive is operating in low voltage DC mode the overvoltage trip level is 1.45 x Pr <b>6.46</b>.</p>	Drive voltage rating	Peak voltage	Maximum continuous voltage level (15s)	200	415	410	400	830	815	575	990	970	690	1190	1175
Drive voltage rating	Peak voltage	Maximum continuous voltage level (15s)														
200	415	410														
400	830	815														
575	990	970														
690	1190	1175														
<b>PAd</b>	<b>Keypad has been removed when the drive is receiving the speed reference from the keypad</b>															
34	<p>Fit keypad and reset  Change speed reference selector to select speed reference from another source</p>															
<b>Ph</b>	<b>AC voltage input phase loss or large supply imbalance detected</b>															
32	<p>Ensure all three phases are present and balanced  Check input voltage levels are correct (at full load)</p> <p><b>NOTE</b></p> <p>Load level must be between 50 and 100% for the drive to trip under phase loss conditions. The drive will attempt to stop the motor before this trip is initiated.</p>															
<b>Ph.P</b>	<b>Power module phase loss detection</b>															
107	<p>Ensure all three phases are present and balanced  Check input voltage levels are correct (at full load)</p>															
<b>PS</b>	<b>Internal power supply fault</b>															
5	<p>Remove any Solutions Modules and reset  Check integrity of interface ribbon cables and connections (size 4,5,6 only)  Hardware fault - return drive to supplier</p>															
<b>PS.10V</b>	<b>10V user power supply current greater than 10mA</b>															
8	<p>Check wiring to terminal 4  Reduce load on terminal 4</p>															
<b>PS.24V</b>	<b>24V internal power supply overload</b>															
9	<p>The total user load of the drive and Solutions Modules has exceeded the internal 24V power supply limit.  The user load consists of the drive's digital outputs, the SM-I/O Plus digital outputs, the drive's main encoder supply and the SM-Universal Encoder Plus encoder supply.</p> <ul style="list-style-type: none"> <li>Reduce load and reset</li> <li>Provide an external 24V &gt;50W power supply</li> <li>Remove any Solutions Modules and reset</li> </ul>															
<b>PS.P</b>	<b>Power module power supply fail</b>															
108	<p>Remove any Solutions Modules and reset  Check integrity of interface ribbon cables and connections (size 4,5,6 only)  Hardware fault - return drive to supplier</p>															
<b>PSAVE.Er</b>	<b>Power down save parameters in the EEPROM are corrupt</b>															
37	<p>Indicates that the power was removed when power down save parameters were being saved.  The drive will revert back to the power down parameter set that was last saved successfully.  Perform a user save (Pr <b>xx.00</b> to 1000 or 1001 and reset the drive) or power down the drive normally to ensure this trip does or occur the next time the drive is powered up.</p>															



<b>Trip</b>	<b>Diagnosis</b>
<b>rS</b>	<b>Failure to measure resistance during autotune or when starting in open loop vector mode 0 or 3</b>
<b>33</b>	Check motor power connection continuity
<b>SAVE.Er</b>	<b>User save parameters in the EEPROM are corrupt</b>
<b>36</b>	Indicates that the power was removed when user parameters were being saved. The drive will revert back to the user parameter set that was last saved successfully. Perform a user save (Pr <b>xx.00</b> to 1000 or 1001 and reset the drive) to ensure this trip does or occur the next time the drive is powered up.
<b>SCL</b>	<b>Drive RS485 serial comms loss to remote keypad</b>
<b>30</b>	Refit the cable between the drive and keypad Check cable for damage Replace cable Replace keypad
<b>SLX.dF</b>	<b>Solutions Module slot X trip: Solutions Module type fitted in slot X changed</b>
<b>204,209,214</b>	Save parameters and reset

Trip	Diagnosis			
<b>SLX.Er</b>	<b>Solutions Module slot X trip: Solutions Module in slot X has detected a fault</b>			
202,207,212	<b>Feedback module category</b>			
	Check value in Pr 15/16/17.50. The following table lists the possible error codes for the SM-Universal Encoder Plus, SM-Encoder Plus and SM-Resolver. See the <i>Diagnostics</i> section in the relevant Solutions Module User Guide for more information.			
	Error code	Module	Trip Description	Diagnostic
	0	All	No trip	No fault detected
	1	SM-Universal Encoder Plus	Encoder power supply overload	Check encoder power supply wiring and encoder current requirement Maximum current = 200mA @ 15V, or 300mA @ 8V and 5V
		SM-Resolver	Excitation output short circuit	Check the excitation output wiring.
	2	SM-Universal Encoder Plus & SM-Resolver	Wire break	Check cable continuity Check wiring of feedback signals is correct Check supply voltage or excitation output level Replace feedback device
	3	SM-Universal Encoder Plus	Phase offset incorrect whilst running	Check the encoder signal for noise Check encoder shielding Check the integrity of the encoder mechanical mounting Repeat the offset measurement test
	4	SM-Universal Encoder Plus	Feedback device communications failure	Ensure encoder power supply is correct Ensure baud rate is correct Check encoder wiring Replace feedback device
	5	SM-Universal Encoder Plus	Checksum or CRC error	Check the encoder signal for noise Check the encoder cable shielding
	6	SM-Universal Encoder Plus	Encoder has indicated an error	Replace encoder
	7	SM-Universal Encoder Plus	Initialisation failed	Check the correct encoder type is entered into Pr 15/16/17.15 Check encoder wiring Check supply voltage level Replace feedback device
	8	SM-Universal Encoder Plus	Auto configuration on power up has been requested and failed	Change the setting of Pr 15/16/17.18 and manually enter the number of turns (Pr 15/16/17.09) and the equivalent number of lines per revolution (Pr 15/16/17.10)
	9	SM-Universal Encoder Plus	Motor thermistor trip	Check motor temperature Check thermistor continuity
	10	SM-Universal Encoder Plus	Motor thermistor short circuit	Check motor thermistor wiring Replace motor / motor thermistor
	11	SM-Universal Encoder Plus	Failure of the sincos analogue position alignment during encoder initialisation	Check encoder cable shield. Examine sine and cosine signals for noise.
		SM-Resolver	Poles not compatible with motor	Check that the correct number of resolver poles has been set in Pr 15/16/17.15.
	12	SM-Universal Encoder Plus	Encoder type could not be identified during auto-configuration	Check encoder type can be auto-configured. Check encoder wiring. Enter parameters manually.
	13	SM-Universal Encoder Plus	Number of encoder turns read from the encoder during auto-configuration is not a power of 2	Select a different type of encoder.
	14	SM-Universal Encoder Plus	Number of comms bits defining the encoder position within a turn read from the encoder during auto-configuration is too large.	Select a different type of encoder. Faulty encoder.
15	SM-Universal Encoder Plus	The number of periods per revolution calculated from encoder data during auto-configuration is either <2 or >50,000.	Linear motor pole pitch / encoder ppr set up is incorrect or out of parameter range i.e. Pr 5.36 = 0 or Pr 21.31 = 0. Faulty encoder.	
16	SM-Universal Encoder Plus	The number of comms bits per period for a linear encoder exceeds 255.	Select a different type of encoder. Faulty encoder.	
74	All	Solutions Module has overheated	Check ambient temperature Check cubicle ventilation	

Trip	Diagnosis																																																																																										
<b>SLX.Er</b>	<b>Solutions Module slot X trip: Solutions Module in slot X has detected a fault</b>																																																																																										
<b>202,207,212</b>	<b>Automation (Applications) module category</b>																																																																																										
	Check value in Pr <b>15/16/17.50</b> . The following table lists the possible error codes for the SM-Applications and SM-Applications Lite. See the <i>Diagnosics</i> section in the relevant Solutions Module User Guide for more information.																																																																																										
	<table border="1"> <thead> <tr> <th style="text-align: center;">Error Code</th> <th style="text-align: center;">Trip Description</th> </tr> </thead> <tbody> <tr><td>39</td><td>User program stack overflow</td></tr> <tr><td>40</td><td>Unknown error - please contact supplier</td></tr> <tr><td>41</td><td>Parameter does not exist</td></tr> <tr><td>42</td><td>Attempt to write to a read-only parameter</td></tr> <tr><td>43</td><td>Attempt to read from a write-only parameter</td></tr> <tr><td>44</td><td>Parameter value out of range</td></tr> <tr><td>45</td><td>Invalid synchronisation modes</td></tr> <tr><td>46</td><td>Unused</td></tr> <tr><td>47</td><td>Synchronisation lost with CTSync Master</td></tr> <tr><td>48</td><td>RS485 not in user mode</td></tr> <tr><td>49</td><td>Invalid RS485 configuration</td></tr> <tr><td>50</td><td>Maths error - divide by zero or overflow</td></tr> <tr><td>51</td><td>Array index out of range</td></tr> <tr><td>52</td><td>Control word user trip</td></tr> <tr><td>53</td><td>DPL program incompatible with target</td></tr> <tr><td>54</td><td>DPL task overrun</td></tr> <tr><td>55</td><td>Unused</td></tr> <tr><td>56</td><td>Invalid timer unit configuration</td></tr> <tr><td>57</td><td>Function block does not exist</td></tr> <tr><td>58</td><td>Flash PLC Storage corrupt</td></tr> <tr><td>59</td><td>Drive rejected application module as Sync master</td></tr> <tr><td>60</td><td>CTNet hardware failure. Please contact your supplier</td></tr> <tr><td>61</td><td>CTNet invalid configuration</td></tr> <tr><td>62</td><td>CTNet invalid baud-rate</td></tr> <tr><td>63</td><td>CTNet invalid node ID</td></tr> <tr><td>64</td><td>Digital Output overload</td></tr> <tr><td>65</td><td>Invalid function block parameter(s)</td></tr> <tr><td>66</td><td>User heap too large</td></tr> <tr><td>67</td><td>RAM file does not exist or a non-RAM file id has been specified</td></tr> <tr><td>68</td><td>The RAM file specified is not associated to an array</td></tr> <tr><td>69</td><td>Failed to update drive parameter database cache in Flash memory</td></tr> <tr><td>70</td><td>User program downloaded while drive enabled</td></tr> <tr><td>71</td><td>Failed to change drive mode</td></tr> <tr><td>72</td><td>Invalid CTNet buffer operation</td></tr> <tr><td>73</td><td>Fast parameter initialisation failure</td></tr> <tr><td>74</td><td>Over-temperature</td></tr> <tr><td>75</td><td>Hardware unavailable</td></tr> <tr><td>76</td><td>Module type cannot be resolved. Module is not recognised.</td></tr> <tr><td>77</td><td>Inter-option module comms error with module in slot 1</td></tr> <tr><td>78</td><td>Inter-option module comms error with module in slot 2</td></tr> <tr><td>79</td><td>Inter-option module comms error with module in slot 3</td></tr> <tr><td>80</td><td>Inter-option module comms error with module unknown slot</td></tr> <tr><td>81</td><td>APC internal error</td></tr> <tr><td>82</td><td>Communcations to drive faulty</td></tr> </tbody> </table>	Error Code	Trip Description	39	User program stack overflow	40	Unknown error - please contact supplier	41	Parameter does not exist	42	Attempt to write to a read-only parameter	43	Attempt to read from a write-only parameter	44	Parameter value out of range	45	Invalid synchronisation modes	46	Unused	47	Synchronisation lost with CTSync Master	48	RS485 not in user mode	49	Invalid RS485 configuration	50	Maths error - divide by zero or overflow	51	Array index out of range	52	Control word user trip	53	DPL program incompatible with target	54	DPL task overrun	55	Unused	56	Invalid timer unit configuration	57	Function block does not exist	58	Flash PLC Storage corrupt	59	Drive rejected application module as Sync master	60	CTNet hardware failure. Please contact your supplier	61	CTNet invalid configuration	62	CTNet invalid baud-rate	63	CTNet invalid node ID	64	Digital Output overload	65	Invalid function block parameter(s)	66	User heap too large	67	RAM file does not exist or a non-RAM file id has been specified	68	The RAM file specified is not associated to an array	69	Failed to update drive parameter database cache in Flash memory	70	User program downloaded while drive enabled	71	Failed to change drive mode	72	Invalid CTNet buffer operation	73	Fast parameter initialisation failure	74	Over-temperature	75	Hardware unavailable	76	Module type cannot be resolved. Module is not recognised.	77	Inter-option module comms error with module in slot 1	78	Inter-option module comms error with module in slot 2	79	Inter-option module comms error with module in slot 3	80	Inter-option module comms error with module unknown slot	81	APC internal error	82	Communcations to drive faulty
	Error Code	Trip Description																																																																																									
	39	User program stack overflow																																																																																									
	40	Unknown error - please contact supplier																																																																																									
	41	Parameter does not exist																																																																																									
	42	Attempt to write to a read-only parameter																																																																																									
	43	Attempt to read from a write-only parameter																																																																																									
	44	Parameter value out of range																																																																																									
	45	Invalid synchronisation modes																																																																																									
	46	Unused																																																																																									
	47	Synchronisation lost with CTSync Master																																																																																									
	48	RS485 not in user mode																																																																																									
	49	Invalid RS485 configuration																																																																																									
	50	Maths error - divide by zero or overflow																																																																																									
	51	Array index out of range																																																																																									
	52	Control word user trip																																																																																									
	53	DPL program incompatible with target																																																																																									
	54	DPL task overrun																																																																																									
	55	Unused																																																																																									
	56	Invalid timer unit configuration																																																																																									
	57	Function block does not exist																																																																																									
	58	Flash PLC Storage corrupt																																																																																									
	59	Drive rejected application module as Sync master																																																																																									
	60	CTNet hardware failure. Please contact your supplier																																																																																									
	61	CTNet invalid configuration																																																																																									
	62	CTNet invalid baud-rate																																																																																									
	63	CTNet invalid node ID																																																																																									
	64	Digital Output overload																																																																																									
	65	Invalid function block parameter(s)																																																																																									
	66	User heap too large																																																																																									
	67	RAM file does not exist or a non-RAM file id has been specified																																																																																									
68	The RAM file specified is not associated to an array																																																																																										
69	Failed to update drive parameter database cache in Flash memory																																																																																										
70	User program downloaded while drive enabled																																																																																										
71	Failed to change drive mode																																																																																										
72	Invalid CTNet buffer operation																																																																																										
73	Fast parameter initialisation failure																																																																																										
74	Over-temperature																																																																																										
75	Hardware unavailable																																																																																										
76	Module type cannot be resolved. Module is not recognised.																																																																																										
77	Inter-option module comms error with module in slot 1																																																																																										
78	Inter-option module comms error with module in slot 2																																																																																										
79	Inter-option module comms error with module in slot 3																																																																																										
80	Inter-option module comms error with module unknown slot																																																																																										
81	APC internal error																																																																																										
82	Communcations to drive faulty																																																																																										

Trip	Diagnosis																																																																								
<b>SLX.Er</b>	<b>Solutions Module slot X trip: Solutions Module in slot X has detected a fault</b>																																																																								
202,207,212	<b>Automation (I/O Expansion) module category</b> Check value in Pr 15/16/17.50. The following table lists the possible error codes for the SM-I/O Plus, SM-I/O Lite, SM-I/O Timer, SM-PELV and SM-I/O 120V modules. See the <i>Diagnostics</i> section in the relevant Solutions Module User Guide for more information.																																																																								
	<table border="1"> <thead> <tr> <th>Error code</th> <th>Module</th> <th>Reason for fault</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>All</td> <td>No errors</td> </tr> <tr> <td>1</td> <td>All</td> <td>Digital output overload</td> </tr> <tr> <td rowspan="2">2</td> <td>SM-I/O Lite, SM-I/O Timer</td> <td>Analogue input 1 current input too high (&gt;22mA) or too low (&lt;3mA)</td> </tr> <tr> <td>SM-PELV</td> <td>Digital input overload</td> </tr> <tr> <td>3</td> <td>SM-PELV</td> <td>Analogue input 1 current input too low (&lt;3mA)</td> </tr> <tr> <td>4</td> <td>SM-PELV</td> <td>User power supply absent</td> </tr> <tr> <td>5</td> <td>SM-I/O Timer</td> <td>Real time clock communication error</td> </tr> <tr> <td>74</td> <td>All</td> <td>Module over temperature</td> </tr> </tbody> </table>	Error code	Module	Reason for fault	0	All	No errors	1	All	Digital output overload	2	SM-I/O Lite, SM-I/O Timer	Analogue input 1 current input too high (>22mA) or too low (<3mA)	SM-PELV	Digital input overload	3	SM-PELV	Analogue input 1 current input too low (<3mA)	4	SM-PELV	User power supply absent	5	SM-I/O Timer	Real time clock communication error	74	All	Module over temperature																																														
	Error code	Module	Reason for fault																																																																						
	0	All	No errors																																																																						
	1	All	Digital output overload																																																																						
	2	SM-I/O Lite, SM-I/O Timer	Analogue input 1 current input too high (>22mA) or too low (<3mA)																																																																						
		SM-PELV	Digital input overload																																																																						
	3	SM-PELV	Analogue input 1 current input too low (<3mA)																																																																						
	4	SM-PELV	User power supply absent																																																																						
	5	SM-I/O Timer	Real time clock communication error																																																																						
74	All	Module over temperature																																																																							
<b>SLX.Er</b>	<b>Solutions Module slot X trip: Solutions Module in slot X has detected a fault</b>																																																																								
202,207,212	<b>Fieldbus module category</b> Check value in Pr 15/16/17.50. The following table lists the possible error codes for the Fieldbus modules. See the <i>Diagnostics</i> section in the relevant Solutions Module User Guide for more information.																																																																								
	<table border="1"> <thead> <tr> <th>Error code</th> <th>Module</th> <th>Trip Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>All</td> <td>No trip</td> </tr> <tr> <td>52</td> <td>SM-PROFIBUS-DP, SM-Interbus, SM-DeviceNet, SM-CANOpen</td> <td>User control word trip</td> </tr> <tr> <td>61</td> <td>SM-PROFIBUS-DP, SM-Interbus, SM-DeviceNet, SM-CANOpen, SM-SERCOS</td> <td>Configuration error</td> </tr> <tr> <td>64</td> <td>SM-DeviceNet</td> <td>Expected packet rate timeout</td> </tr> <tr> <td>65</td> <td>SM-PROFIBUS-DP, SM-Interbus, SM-DeviceNet, SM-CANOpen, SM-SERCOS</td> <td>Network loss</td> </tr> <tr> <td>66</td> <td>SM-PROFIBUS-DP</td> <td>Critical link failure</td> </tr> <tr> <td></td> <td>SM-CAN, SM-DeviceNet, SM-CANOpen</td> <td>Bus off error</td> </tr> <tr> <td>69</td> <td>SM-CAN</td> <td>No acknowledgement</td> </tr> <tr> <td>70</td> <td>All (except SM-Ethernet)</td> <td>Flash transfer error</td> </tr> <tr> <td></td> <td>SM-Ethernet</td> <td>No valid menu data available for the module from the drive</td> </tr> <tr> <td>74</td> <td>All</td> <td>Solutions module over temperature</td> </tr> <tr> <td>75</td> <td>SM-Ethernet</td> <td>The drive is not responding</td> </tr> <tr> <td>76</td> <td>SM-Ethernet</td> <td>The Modbus connection has timed out</td> </tr> <tr> <td>80</td> <td>All (except SM-SERCOS)</td> <td>Inter-option communications error</td> </tr> <tr> <td>81</td> <td>All (except SM-SERCOS)</td> <td>Communications error to slot 1</td> </tr> <tr> <td>82</td> <td>All (except SM-SERCOS)</td> <td>Communications error to slot 2</td> </tr> <tr> <td>83</td> <td>All (except SM-SERCOS)</td> <td>Communications error to slot 3</td> </tr> <tr> <td>84</td> <td>SM-Ethernet</td> <td>Memory allocation error</td> </tr> <tr> <td>85</td> <td>SM-Ethernet</td> <td>File system error</td> </tr> <tr> <td>86</td> <td>SM-Ethernet</td> <td>Configuration file error</td> </tr> <tr> <td>87</td> <td>SM-Ethernet</td> <td>Language file error</td> </tr> <tr> <td>98</td> <td>All</td> <td>Internal watchdog error</td> </tr> <tr> <td>99</td> <td>All</td> <td>Internal software error</td> </tr> </tbody> </table>	Error code	Module	Trip Description	0	All	No trip	52	SM-PROFIBUS-DP, SM-Interbus, SM-DeviceNet, SM-CANOpen	User control word trip	61	SM-PROFIBUS-DP, SM-Interbus, SM-DeviceNet, SM-CANOpen, SM-SERCOS	Configuration error	64	SM-DeviceNet	Expected packet rate timeout	65	SM-PROFIBUS-DP, SM-Interbus, SM-DeviceNet, SM-CANOpen, SM-SERCOS	Network loss	66	SM-PROFIBUS-DP	Critical link failure		SM-CAN, SM-DeviceNet, SM-CANOpen	Bus off error	69	SM-CAN	No acknowledgement	70	All (except SM-Ethernet)	Flash transfer error		SM-Ethernet	No valid menu data available for the module from the drive	74	All	Solutions module over temperature	75	SM-Ethernet	The drive is not responding	76	SM-Ethernet	The Modbus connection has timed out	80	All (except SM-SERCOS)	Inter-option communications error	81	All (except SM-SERCOS)	Communications error to slot 1	82	All (except SM-SERCOS)	Communications error to slot 2	83	All (except SM-SERCOS)	Communications error to slot 3	84	SM-Ethernet	Memory allocation error	85	SM-Ethernet	File system error	86	SM-Ethernet	Configuration file error	87	SM-Ethernet	Language file error	98	All	Internal watchdog error	99	All	Internal software error
	Error code	Module	Trip Description																																																																						
	0	All	No trip																																																																						
	52	SM-PROFIBUS-DP, SM-Interbus, SM-DeviceNet, SM-CANOpen	User control word trip																																																																						
	61	SM-PROFIBUS-DP, SM-Interbus, SM-DeviceNet, SM-CANOpen, SM-SERCOS	Configuration error																																																																						
	64	SM-DeviceNet	Expected packet rate timeout																																																																						
	65	SM-PROFIBUS-DP, SM-Interbus, SM-DeviceNet, SM-CANOpen, SM-SERCOS	Network loss																																																																						
	66	SM-PROFIBUS-DP	Critical link failure																																																																						
		SM-CAN, SM-DeviceNet, SM-CANOpen	Bus off error																																																																						
	69	SM-CAN	No acknowledgement																																																																						
	70	All (except SM-Ethernet)	Flash transfer error																																																																						
		SM-Ethernet	No valid menu data available for the module from the drive																																																																						
	74	All	Solutions module over temperature																																																																						
	75	SM-Ethernet	The drive is not responding																																																																						
	76	SM-Ethernet	The Modbus connection has timed out																																																																						
	80	All (except SM-SERCOS)	Inter-option communications error																																																																						
	81	All (except SM-SERCOS)	Communications error to slot 1																																																																						
	82	All (except SM-SERCOS)	Communications error to slot 2																																																																						
	83	All (except SM-SERCOS)	Communications error to slot 3																																																																						
	84	SM-Ethernet	Memory allocation error																																																																						
	85	SM-Ethernet	File system error																																																																						
	86	SM-Ethernet	Configuration file error																																																																						
	87	SM-Ethernet	Language file error																																																																						
	98	All	Internal watchdog error																																																																						
	99	All	Internal software error																																																																						

Trip	Diagnosis																																												
<b>SLX.Er</b>	<b>Solutions Module slot X trip: Solutions Module in slot X has detected a fault</b>																																												
<b>202,207,212</b>	<b>SLM module category</b> Check value in Pr <b>15/16/17.50</b> . The following table lists the possible error codes for the SM-SLM. See the <i>Diagnostics</i> section in the <i>SM-SLM User Guide</i> for more information.																																												
	<table border="1"> <thead> <tr> <th>Error Code</th> <th>Trip Description</th> </tr> </thead> <tbody> <tr><td>0</td><td>No fault detected</td></tr> <tr><td>1</td><td>Power supply overloaded</td></tr> <tr><td>2</td><td>SLM version is too low</td></tr> <tr><td>3</td><td>DriveLink error</td></tr> <tr><td>4</td><td>Incorrect switching frequency selected</td></tr> <tr><td>5</td><td>Feedback source selection incorrect</td></tr> <tr><td>6</td><td>Encoder error</td></tr> <tr><td>7</td><td>Motor object number of instances error</td></tr> <tr><td>8</td><td>Motor object list version error</td></tr> <tr><td>9</td><td>Performance object number of instances error</td></tr> <tr><td>10</td><td>Parameter channel error</td></tr> <tr><td>11</td><td>Drive operating mode incompatible</td></tr> <tr><td>12</td><td>Error writing to the SLM EEPROM</td></tr> <tr><td>13</td><td>Motor object type incorrect</td></tr> <tr><td>14</td><td>Unidrive SP object error</td></tr> <tr><td>15</td><td>Encoder object CRC error</td></tr> <tr><td>16</td><td>Motor object CRC error</td></tr> <tr><td>17</td><td>Performance object CRC error</td></tr> <tr><td>18</td><td>Unidrive SP object CRC error</td></tr> <tr><td>19</td><td>Sequencer timeout</td></tr> <tr><td>74</td><td>Solutions module over temperature</td></tr> </tbody> </table>	Error Code	Trip Description	0	No fault detected	1	Power supply overloaded	2	SLM version is too low	3	DriveLink error	4	Incorrect switching frequency selected	5	Feedback source selection incorrect	6	Encoder error	7	Motor object number of instances error	8	Motor object list version error	9	Performance object number of instances error	10	Parameter channel error	11	Drive operating mode incompatible	12	Error writing to the SLM EEPROM	13	Motor object type incorrect	14	Unidrive SP object error	15	Encoder object CRC error	16	Motor object CRC error	17	Performance object CRC error	18	Unidrive SP object CRC error	19	Sequencer timeout	74	Solutions module over temperature
	Error Code	Trip Description																																											
	0	No fault detected																																											
	1	Power supply overloaded																																											
	2	SLM version is too low																																											
	3	DriveLink error																																											
	4	Incorrect switching frequency selected																																											
	5	Feedback source selection incorrect																																											
	6	Encoder error																																											
	7	Motor object number of instances error																																											
	8	Motor object list version error																																											
	9	Performance object number of instances error																																											
	10	Parameter channel error																																											
	11	Drive operating mode incompatible																																											
	12	Error writing to the SLM EEPROM																																											
	13	Motor object type incorrect																																											
	14	Unidrive SP object error																																											
	15	Encoder object CRC error																																											
	16	Motor object CRC error																																											
17	Performance object CRC error																																												
18	Unidrive SP object CRC error																																												
19	Sequencer timeout																																												
74	Solutions module over temperature																																												
<b>SLX.HF</b>	<b>Solutions Module slot X trip: Solutions Module X hardware fault</b>																																												
<b>200,205,210</b>	Ensure Solutions Module is fitted correctly Return Solutions Module to supplier																																												
<b>SLX.nF</b>	<b>Solutions Module slot X trip: Solutions Module has been removed</b>																																												
<b>203,208,213</b>	Ensure Solutions Module is fitted correctly Re-fit Solutions Module Save parameters and reset drive																																												
<b>SL.rtd</b>	<b>Solutions Module trip: Drive mode has changed and Solutions Module parameter routing is now incorrect</b>																																												
<b>215</b>	Press reset. If the trip persists, contact the supplier of the drive.																																												
<b>SLX.tO</b>	<b>Solutions Module slot X trip: Solutions Module watchdog timeout</b>																																												
<b>201,206,211</b>	Press reset. If the trip persists, contact the supplier of the drive.																																												
<b>t010</b>	<b>User trip defined in 2<sup>nd</sup> processor Solutions Module code</b>																																												
<b>10</b>	SM-Applications program must be interrogated to find the cause of this trip																																												
<b>t038</b>	<b>User trip defined in 2<sup>nd</sup> processor Solutions Module code</b>																																												
<b>38</b>	SM-Applications program must be interrogated to find the cause of this trip																																												
<b>t040 to t089</b>	<b>User trip defined in 2<sup>nd</sup> processor Solutions Module code</b>																																												
<b>40 to 89</b>	SM-Applications program must be interrogated to find the cause of this trip																																												
<b>t099</b>	<b>User trip defined in 2<sup>nd</sup> processor Solutions Module code</b>																																												
<b>99</b>	SM-Applications program must be interrogated to find the cause of this trip																																												
<b>t101</b>	<b>User trip defined in 2<sup>nd</sup> processor Solutions Module code</b>																																												
<b>101</b>	SM-Applications program must be interrogated to find the cause of this trip																																												
<b>t111 to t160</b>	<b>User trip defined in 2<sup>nd</sup> processor Solutions Module code</b>																																												
<b>111 to 160</b>	SM-Applications program must be interrogated to find the cause of this trip																																												

<b>Trip</b>	<b>Diagnosis</b>
<b>t168 to t175</b>	<b>User trip defined in 2<sup>nd</sup> processor Solutions Module code</b>
<b>168 to 175</b>	SM-Applications program must be interrogated to find the cause of this trip
<b>t216</b>	<b>User trip defined in 2<sup>nd</sup> processor Solutions Module code</b>
<b>216</b>	SM-Applications program must be interrogated to find the cause of this trip
<b>th</b>	<b>Motor thermistor trip</b>
<b>24</b>	Check motor temperature Check thermistor continuity Set Pr 7.15 = VOLt and reset the drive to disable this function
<b>thS</b>	<b>Motor thermistor short circuit</b>
<b>25</b>	Check motor thermistor wiring Replace motor / motor thermistor Set Pr 7.15 = VOLt and reset the drive to disable this function
<b>tunE*</b>	<b>Autotune stopped before completion</b>
<b>18</b>	The drive has tripped out during the autotune The red stop key has been pressed during the autotune The secure disable signal (terminal 31) was active during the autotune procedure
<b>tunE1*</b>	<b>The position feedback did not change or required speed could not be reached during the inertia test (see Pr 5.12)</b>
<b>11</b>	Ensure the motor is free to turn i.e. brake was released Check feedback device wiring is correct Check feedback parameters are set correctly Check encoder coupling to motor
<b>tunE2*</b>	<b>Position feedback direction incorrect or motor could not be stopped during the inertia test (see Pr 5.12)</b>
<b>12</b>	Check motor cable wiring is correct Check feedback device wiring is correct Swap any two motor phases (closed loop vector only)
<b>tunE3*</b>	<b>Drive encoder commutation signals connected incorrectly or measured inertia out of range (see Pr 5.12)</b>
<b>13</b>	Check motor cable wiring is correct Check feedback device U,V and W commutation signal wiring is correct
<b>tunE4*</b>	<b>Drive encoder U commutation signal fail during an autotune</b>
<b>14</b>	Check feedback device U phase commutation wires continuity Replace encoder
<b>tunE5*</b>	<b>Drive encoder V commutation signal fail during an autotune</b>
<b>15</b>	Check feedback device V phase commutation wires continuity Replace encoder
<b>tunE6*</b>	<b>Drive encoder W commutation signal fail during an autotune</b>
<b>16</b>	Check feedback device W phase commutation wires continuity Replace encoder
<b>tunE7*</b>	<b>Motor number of poles set incorrectly</b>
<b>17</b>	Check lines per revolution for feedback device Check the number of poles in Pr 5.11 is set correctly
<b>Unid.P</b>	<b>Power module unidentified trip</b>
<b>110</b>	Check all interconnecting cables between power modules Ensure cables are routed away from electrical noise sources
<b>UP ACC</b>	<b>Onboard PLC program: cannot access Onboard PLC program file on drive</b>
<b>98</b>	Disable drive - write access is not allowed when the drive is enabled Another source is already accessing Onboard PLC program - retry once other action is complete
<b>UP div0</b>	<b>Onboard PLC program attempted divide by zero</b>
<b>90</b>	Check program
<b>UP OFL</b>	<b>Onboard PLC program variables and function block calls using more than the allowed RAM space (stack overflow)</b>
<b>95</b>	Check program
<b>UP ovr</b>	<b>Onboard PLC program attempted out of range parameter write</b>
<b>94</b>	Check program
<b>UP PAr</b>	<b>Onboard PLC program attempted access to a non-existent parameter</b>
<b>91</b>	Check program



The trips can be grouped into the following categories. It should be noted that a trip can only occur when the drive is not tripped or is already tripped but with a trip with a lower priority number.

**Table 13-3 Trip categories**

Priority	Category	Trips	Comments
1	Hardware faults	HF01 to HF16	These indicate fatal problems and cannot be reset. The drive is inactive after one of these trips and the display shows <b>HFxx</b> . The Drive Healthy relay opens and the serial comms will not function.
2	Non-resetable trips	HF17 to HF32, SL1.HF, SL2.HF, SL3.HF	Cannot be reset. Requires the drive to be powered down.
3	EEF trip	EEF	Cannot be reset unless a code to load defaults is first entered in Pr <b>xx.00</b> or Pr <b>11.43</b> .
4	SMARTCARD trips	C.boot, C.Busy, C.Chg, C.OPtn, C.RdO, C.Err, C.dat, C.FULL, C.Acc, C.rtg, C.TyP, C.cpr	Can be reset after 1.0s SMARTCARD trips have priority 5 during power-up
4	Encoder power supply trips	PS.24V, EnC1	Can be reset after 1.0s These trips can only override the following priority 5 trips: EnC2 to EnC8 or Enc11 to Enc17
5	Autotune	tunE, tunE1 to tunE7	Can be reset after 1.0s, but the drive cannot be made to run unless it is disabled via the Secure Disable input (terminal 31), <i>Drive enable</i> (Pr <b>6.15</b> ) or the <i>Control word</i> (Pr <b>6.42</b> and Pr <b>6.43</b> ).
5	Normal trips with extended reset	OI.AC, OI.Br, OIAC.P, OIBr.P, OldC.P	Can be reset after 10.0s
5	Normal trips	All other trips not included in this table	Can be reset after 1.0s
5	Non-important trips	th, thS, Old1, cL2, cL3, SCL	If Pr <b>10.37</b> is 1 or 3 the drive will stop before tripping
5	Phase loss	PH	The drive attempts to stop before tripping
5	Drive over-heat based on thermal model	O.ht3	The drive attempts to stop before tripping, but if it does not stop within 10s the drive will automatically trip
6	Self-resetting trips	UV	Under voltage trip cannot be reset by the user, but is automatically reset by the drive when the supply voltage is with specification

Although the UV trip operates in a similar way to all other trips, all drive functions can still operate but the drive cannot be enabled. The following differences apply to the UV trip:

1. Power-down save user parameters are saved when UV trip is activated except when the main high voltage supply is not active (i.e. operating in Low Voltage DC Supply Mode, Pr **6.44** = 1).
2. The UV trip is self-resetting when the DC bus voltage rises above the drive restart voltage level. If another trip is active instead of UV at this point, the trip is not reset.
3. The drive can change between using the main high voltage supply and low voltage DC supply only when the drive is in the under voltage condition (Pr **10.16** = 1). The UV trip can only be seen as active if another trip is not active in the under voltage condition.
4. When the drive is first powered up a UV trip is initiated if the supply voltage is below the restart voltage level and another trip is not active. This does not cause save power down save parameters to be saved at this point.

## 13.2 Alarm indications

In any mode an alarm flashes alternately with the data displayed on the 2<sup>nd</sup> row when one of the following conditions occur. If action is not taken to eliminate any alarm except "Autotune" the drive may eventually trip.

**Table 13-4 Alarm indications**

Lower display	Description
<b>br.rS</b>	Braking resistor overload
	Braking resistor I <sup>2</sup> t accumulator (Pr <b>10.37</b> ) in the drive has reached 75.0% of the value at which the drive will trip and the braking IGBT is active.
<b>Hot</b>	Heatsink or control board or inverter IGBT over temperature alarms are active
	<ul style="list-style-type: none"> <li>The drive heatsink temperature has reached a threshold and the drive will trip O.ht2 if the temperature continues to rise (see the O.ht2 trip).</li> </ul> Or <ul style="list-style-type: none"> <li>The ambient temperature around the control PCB is approaching the over temperature threshold (see the O.CtL trip).</li> </ul>
<b>OVLd</b>	Motor overload
	The motor I <sup>2</sup> t accumulator in the drive has reached 75% of the value at which the drive will be tripped and the load on the drive is >100%



### 13.3 Status indications

Table 13-5 Status indications

Upper display	Description	Drive output stage
<b>ACt</b>	Regeneration mode active The regen unit is enabled and synchronised to the supply.	Enabled
<b>ACUU</b>	AC Supply loss The drive has detected that the AC supply has been lost and is attempting to maintain the DC bus voltage by decelerating the motor.	Enabled
<b>*Auto tunE</b>	Autotune in progress The autotune procedure has been initialised. **'Auto' and 'tunE' will flash alternatively on the display.	Enabled
<b>dc</b>	DC applied to the motor The drive is applying DC injection braking.	Enabled
<b>dEC</b>	Decelerating The drive is decelerating the motor.	Enabled
<b>inh</b>	Inhibit The drive is inhibited and cannot be run. The drive enable signal is not applied to terminal 31 or Pr 6.15 is set to 0.	Disabled
<b>PLC</b>	Onboard PLC program is running An Onboard PLC program is fitted and running. The lower display will flash 'PLC' once every 10s.	Not applicable
<b>POS</b>	Positioning The drive is positioning/orientating the motor shaft.	Enabled
<b>rdY</b>	Ready The drive is ready to be run.	Disabled
<b>run</b>	Running The drive is running.	Enabled
<b>SCAn</b>	Scanning OL> The drive is searching for the motor frequency when synchronising to a spinning motor. Regen> The drive is enabled and is synchronising to the line.	Enabled
<b>StoP</b>	Stop or holding zero speed The drive is holding zero speed. Regen> The drive is enabled but the AC voltage is too low, or the DC bus voltage is still rising or falling.	Enabled
<b>triP</b>	Trip condition The drive has tripped and is no longer controlling the motor. The trip code appears on the lower display.	Disabled

Table 13-6 Solutions Module and SMARTCARD status indications at power-up

Lower display	Description
<b>boot</b>	A parameter set is being transferred from the SMARTCARD to the drive during power-up. For further information, please refer to section 9.2.4 <i>Booting up from the SMARTCARD on every power up (Pr 11.42 = boot (4))</i> on page 153.
<b>cArd</b>	The drive is writing a parameter set to the SMARTCARD during power-up. For further information, please refer to section 9.2.3 <i>Auto saving parameter changes (Pr 11.42 = Auto (3))</i> on page 153.
<b>IoAding</b>	The drive is writing information to a Solutions Module.

### 13.4 Displaying the trip history

The drive retains a log of the last 10 trips that have occurred in Pr 10.20 to Pr 10.29 and the corresponding multi-module drive module number (Pr 6.49 = 1) or the trip time (Pr 6.49 = 0) for each trip in Pr 10.41 to Pr 10.51. The time of the trip is recorded from the powered-up clock (if Pr 6.28 = 0) or from the run time clock (if Pr 6.28 = 1).

Pr 10.20 is the most recent trip, or the current trip if the drive is in a trip condition (with the module number or trip time stored in Pr 10.41 and Pr 10.42). Pr 10.29 is the oldest trip (with the module number or trip time stored in Pr 10.51). Each time a new trip occurs, all the parameters move down one, such that the current trip (and time) is stored in Pr 10.20 (and Pr 10.41 to Pr 10.42) and the oldest trip (and time) is lost out of the bottom of the log.

If any parameter between Pr 10.20 and Pr 10.29 inclusive is read by serial communications, then the trip number in Table 13-1 *Trip indications* on page 276 is the value transmitted.