


Leica TS15

Athletics Measurements

Manual for SmartWorx Viva

Onboard Application



Version 1.0
English

- when it has to be **right**

Leica
Geosystems

Introduction



To use the product in a permitted manner, please refer to the detailed safety directions in the TS15 User Manual. Also refer to the Leica Viva TPS Getting Started Guide and to the Leica Viva Series Series Technical Reference Manual.

Validity of this manual




- This manual applies to the **Athletics** application of SmartWorx Viva running on the TS15. The application allows measurements to be taken for athletics field events.
 - Distances or heights may be measured for the following events:
 - Pole Vault
 - Long Jump and Triple Jump
 - Discus
 - Hammer
 - Shot Putt
 - Javelin
 - Distances and heights are recorded according to the rules set out in the Competition Rules Handbook of the **International Association of Athletics Federations (IAAF)**.
-

Table of Contents




In this manual	Chapter	Page
	1 Accessing Athletics	4
	2 Configuring Athletics	5
	2.1 Overview	5
	2.2 Standard Configuration	5
	2.3 Hidden Configuration	6
	3 Pole Vault	9
	3.1 Understanding Terms and Expressions	9
	3.2 Menu	10
	3.3 Measuring the Ground Plane	11
	3.4 Measuring the Base Point	12
	3.5 Measuring the Crossbar	13
	4 Long Jumps	15
	4.1 Understanding Terms and Expressions	15
	4.2 Menu	15
	4.3 Measuring the Foul Line	17
	4.4 Measuring the Jumps	17
	5 Throwing Events	19
	5.1 Understanding Terms and Expressions	19
	5.2 Menu	20
	5.3 Measuring the Centre Point	21
	5.4 Measuring the Foul Line	22
	5.5 Measuring the Throws	24
	6 Resuming Measurements	26

1 Accessing Athletics

Accessing a menu option

Description	Illustration
<p>There are three ways to access a menu option.</p> <ol style="list-style-type: none"> Using the touchscreen functionality. Tap on the menu item using the stylus provided. Using the up and down navigation arrows. Move the focus to the menu item. Select OK, or press the OK  button, or the ENTER  button. Using the numbered keypad. Select the number that corresponds to the menu item. For example, press 1 from the Jobs & Data menu to access the New job screen. 	

Access

Step	Description
1.	Select Main Menu: Go to Work! . OR Press  .
2.	Select Survey+/Athletics .
3.	Press OK .
4.	In Athletics measurements , select the required event. 
	It is not necessary to position and orient the instrument in order to use any of the options. All measurements are made relative to the instrument position.



Make sure that the correct prism type (prism constant) is set. A wrong prism constant would lead to incorrect results in all following distance measurements.

2 Configuring Athletics

2.1 Overview

Types of configurations

The application can be configured to suit user preferences. Two configurations are available:

- **Standard** configuration: Available to all users, containing basic configuration information.
- **Hidden** configuration: Used to configure vital measurement parameters. This configuration is reached by a special sequence of key strokes. It could be that the sequence of key strokes is not given to some operators to ensure that the configured parameters are not changed.

2.2 Standard Configuration

Standard configuration

The standard configuration can be accessed from most screens by pressing Fn **Conf**.

The screenshot shows a configuration window titled 'Configuration' with a refresh icon. It contains two settings: 'Write Logfile' with a dropdown menu set to 'Yes', and 'Logfile Name' with a text input field containing 'Athletics.txt'.

The screenshot shows a status bar with the following text: 'Hz: 76°11'48" V: 24°03'12" Fn abc 18:06'. Below the status bar is a blue bar with the text 'OK' and several vertical lines.

Key	Description
OK	To return to the screen from where this screen was accessed.

Description of fields

Field	Option	Description
Write Logfile	Yes or No	Establishes whether a logfile is written or not. The default value for this parameter is Yes . If this parameter is set to Yes , each time Store is pressed whilst running the application, information is written to the logfile. The information written depends on the place in the application where Store is pressed.
Logfile Name	Editable field	The name of the logfile. The logfile is saved to the \DATA folder of the data storage device. By using the txt-extension, the logfile can directly be accessed and viewed using the text editor of WinCE onboard.

Access

Step	Description
1.	Access the standard configuration by pressing Fn Conf .
2.	Press the "." key three times in rapid succession.


Configuration,
Circles page

In this screen, the radius of the throwing circles can be entered.

 This is the only place in the application where these values can be edited.

The default values for the circle radius of each event is that specified in the IAAF Competition Rules handbook.


To modify a value, select the required event and type in the new value.




Key	Description
OK	To save changes and return to standard configuration screen.
Deflt	To recall the default settings. The default values are: <ul style="list-style-type: none"> • Discus: 1.2500 m • Hammer: 1.0675 m • Shot Putt: 1.0675 m • Javelin: 8.0000 m
Page	To change to another page on this screen.
ESC	To return to the standard configuration without saving changes..

Configuration,
Rounding page

This screen is used to define the number of decimal places to which the reported distances is displayed for the throwing events. Distances are always rounded down to the nearest place as specified in the configuration.

 The rounding value entered in this screen does not affect the decimal places of the distances sent via the serial port.

To modify a value, select the required event and select the value from the list.

Configuration | ↻

Circles | Rounding | Recording

Discus: 0.01 ▼

Hammer: 0.01 ▼

Shot Putt: 0.01 ▼

Javelin: 0.01 ▼

H_z: 76°11'48" V: 24°03'12" Fn abc 18:19

OK | | | Deflt | Page

Key	Description
OK	To save changes and return to standard configuration screen.
Deflt	To recall the default settings. The default value for all events is 0.01.
Page	To change to another page on this screen.
ESC	To return to the standard configuration without saving changes..

Configuration, Recording page

This screen allows the settings to send results of the application through one of the instrument serial ports.

Configuration | ↻

Circles | Rounding | Recording

Record RS232: Yes ▼


Port: Cable ▼

H_z: 76°11'48" V: 24°03'12" Fn abc 18:22

OK | | | Devce | Page

Key	Description
OK	To save changes and return to standard configuration screen.
Devce	To call the standard system Connection Settings screen. The device associated with each available RS232 port can be configured.
Page	To change to another page on this screen.
ESC	To return to the standard configuration without saving changes..

Description of fields

Field	Option	Description
Record RS232	YES or NO	To activate and deactivate the sending of results through the serial port.  All distances sent through the RS232 port are rounded down to the nearest centimetre.

Field	Option	Description
		<ul style="list-style-type: none"> • If this parameter is set to YES, pressing Store sends a distance through the serial port in the following format: <STX>nnn.nn<ETX> > <STX> ASCII 2, start transmission <ETX> ASCII 3, end transmission nnn.nn Distance in meters Leading spaces are used for shorter distances. • The screen indicates that the distance has been sent successfully with the message Measurement sent successfully. • In the case of the Foul key being pressed, the following message is sent via the serial port: <STX> x<ETX> Leading spaces are used to pad the message to six characters.
Port	Selectable list	The RS232 port through which the results are sent.

3


Pole Vault

3.1

Understanding Terms and Expressions


Pole vault

In the pole vault event it is required to measure the distance (reported height), in whole centimetres, perpendicular to a horizontal plane defining the level of the runway to the lowest part of the upsides of the crossbar. It is assumed that the lowest part of the crossbar is in the centre of the two vertical crossbar supports defined by two measured points (base point 1, base point 2). However it is also possible to measure the lowest point of the crossbar if this is not the case.



- a) Base point 1
- b) Base point 2
- c) Crossbar
- d) Reported height
- e) Pit
- f) Ground point 1
- g) Ground point 2
- h) Ground point 3


The horizontal plane marking the level of the runway is defined by the measuring of three points at the level of the runway (ground point 1, ground point 2, ground point 3) on the box used for planting the pole when vaulting:




Pole vault box

- a) Level of the runway

Once the plane of the level of the runway has been established, the two base points (base point 1, base point 2) are measured on the vertical supports of the crossbar. These two points are then used to calculate the centre of the crossbar where the height should be measured.

 The pole can be offset in a plane parallel to the vertical plane defined by the two base points. The athlete can decide the distance of the pole offset for each jump.



- a) Pole offset

Steps of pole vault measurements

The pole vault event involves three steps. Each step in the process can be selected in the **Pole Vault** menu.

Step	Description
1.	Measure three points in a horizontal plane to define the level of the runway from which heights will be measured.
2.	Measure two base points on the vertical supports of the crossbar.
3.	Measure the height of the crossbar.

Pole Vault

Key	Description
OK	To select the highlighted option and to continue with the subsequent screen.
Resum	To re-start pole vault measurements. Refer to "6 Resuming Measurements".
Fn Conf	To configure the Athletics application.
Fn Quit	To exit the screen.

Description of options

Option	Description
Measure ground plane	To measure three points in a horizontal plane to define the level of the runway from which heights will be measured. If no ground plane has been measured previously, only Measure ground plane is available for selection.
Measure base points	To measure two base points on the vertical supports of the crossbar. It is necessary to measure the ground plane successfully before Measure base points can commence.
Measure bar	To measure the height of the crossbar. It is necessary to measure the base point successfully before Measure bar can commence.

Next step

Select an option and press **OK**.

Description

The level of the runway is defined by a horizontal plane. The height of this horizontal plane is defined by measuring three points on the pole vault box. These points are measured in turn and then the deviation of the three points from the plane is calculated. Before continuing, decide if the maximum deviation from the plane is acceptable or not.

Measuring a point in the ground plane

To measure a point on the ground plane, locate a prism pole on a point on the pole vault box and aim at the prism.

 Set the correct **Target height** of the prism.

Reflectorless measurements can be used if a reflectorless EDM is available.

Ground Plane: Point 1	
Point ID:	1
Target height:	1.5000 m
H_z:	76°11'48"
V:	24°03'13"
Slope distance:	50.0344m
Aim at point on pole vault box and press DIST (F2)	

H _z : 76°11'48"	V: 24°03'12"	Fn abc	18:32
Next	Dist		Back

Key	Description
Next	To store the measurement and to move on to measure the next point on the ground plane. It is only possible to move on to the next point if a valid distance has been measured. If all three points have been measured, the maximum deviation from a horizontal plane is calculated and displayed.
Dist	To measure and display distances.
Back	To return to the previous screen.

Results

Once three points have been measured successfully, the maximum deviation from a horizontal plane is displayed. Decide, if the maximum deviation from the plane meets the requirements.

Ground Plane Results	
Deviation from a horizontal plane	
Maximum:	0.0001m
Press F3 to save result Press F5 to remeasure	


H _z : 135°00'01"	V: 24°03'13"	Fn abc	18:35
	Store	Remea	

Key	Description
Store	To store the mean height of the three measured points as the ground plane height and to return to the Pole Vault menu.
Remea	To return to Ground Plane : measurement.

3.4 Measuring the Base Point

Access

If the ground plane has been measured successfully, the option **Measure base points** is enabled in the **Pole Vault** menu.




This option allows the measurement of two points located on the vertical crossbar supports. By these points, the position of the centre of the crossbar can be calculated.

Press **OK**.

Measuring the base points

To measure a base point, locate a prism on the point to measure and aim at the prism. Reflectorless measurements can be used if a reflectorless EDM is available.



Aim at base point and press DIST (F2)



Key	Description
Next	To store the measurement and to move on to measure the next base point. It is only possible to move on to the next base point if a valid distance has been measured. If both points have been measured successfully, the application returns to the Pole Vault menu.
Dist	To measure and display distances.
Back	To return to the previous screen.

Access

If the base points have been measured successfully, the option **Measure bar** is enabled in the **Pole Vault** menu.




This option allows the measurement of the height of the crossbar over the defined ground plane.

Press **OK**.

Measuring the crossbar

On entering the screen, the instrument turns to the point that is calculated to be halfway between, and in the same plane as, the two base points.

Manually turn the instrument so that the crosshairs of the telescope coincide with the upper part of the bar at its lowest point.



Aim at upperside of crossbar at lowest point



Key	Description
Store	To store the measurement. Depending on the configuration, the measurement is sent to a serial port and/or the log file. If the distance is sent successfully, a message appears.
ESC	To return to the Pole Vault menu.

Description of fields

Field	Option	Description
Athlete ID	Editable field	The point ID of the point to be measured.

Field	Option	Description
Pole Offset	Editable field	The athlete may decide to offset the pole from the plane of the measured base points. In this case, the pole offset must be entered so that the calculation of the intersection of the pointing of the sensor and the plane of the crossbar is correct. Refer to "Pole vault".
Hz. Offset	Display only	The horizontal distance from the calculated centre point of the crossbar, halfway between the base points.
Crossbar Height	Display only	The height of the crossbar over the ground plane.

4

Long Jumps

4.1


Understanding Terms and Expressions

Jump events

The triple jump and long jump share the same measuring methodology and terminology.

A foul line marking the vertical plane from which the jump must be measured is defined by two points (P1, P2).

Once a jump has been made, a judge places a prism at the point indicating the nearest break in the landing area made by any part of the body to the foul line, or the projection of the foul line.



- a) Point 1
- b) Point 2
- c) Foul line (reference line)
- d) Reported distance

005264_001



The reported distance must be measured perpendicular to the foul line or its projection. The reported distance is recorded in whole centimetres.

4.2

Menu

Steps of long jump measurements

The long jumps function can be used for measuring both the long jump and triple jump events. No distinction is made between these events as the methodology used is identical for both events.

Measurement of a long jump involves two steps. Each step in the process can be selected in the **Long Jump**.

Step	Description
1.	Measure two points that define the foul line from which jumps will be measured.
2.	Measure the jump distance of each competitor.

Long Jump

Long Jump			↩
1	Measure foul line		
2	Measure jumps		

Hz: 18°13'51"	V: 90°00'01"	Fn abc	09:03
OK			

Key	Description
OK	To select the highlighted option and to continue with the subsequent screen.
Resum	To re-start long jumps measurements. Refer to "6 Resuming Measurements".
Fn Conf	To configure the Athletics application.
Fn Quit	To exit the screen.

Description of options

Option	Description
Measure foul line	To measure two points that define the foul line from which jumps are measured. If no foul line has been measured previously, only Measure foul line is available for selection.
Measure jumps	To measure the jump distance of each competitor. It is necessary to measure the foul line successfully before Measure jumps can commence.

Next step

Select an option and press **OK**.

4.3

Measuring the Foul Line

Description

The foul line is defined by two points. Each point must be measured in turn.

Measuring points on the foul line

To measure a point on the foul line, locate a prism on the point to measure and aim at the prism. Reflectorless measurements can be used if a reflectorless EDM is available.

Repeated the process for the both points on the foul line.

Measure foul: Point 1 | ↻

Point ID: 1

Hz: 94°30'01"
V: 90°23'36"
Slope distance: 8.0344m

Aim at point on foul line and press Dist (F2)

Hz: 94°30'01" V: 90°23'36" Fn abc 19:22

Next | Dist | Back

Key	Description
Next	To store the measurement and to move on to measure the next point on the foul line. It is only possible to move on to the next point if a valid distance has been measured. To return to Long Jump , if both points have been measured.
Dist	To measure and display distances.
Back	To return to the previous screen.

4.4

Measuring the Jumps

Access

If the base points have been measured successfully, the option **Measure jumps** is enabled in the **Long Jump**.

Long Jump | ↻

1 Measure foul line
2 Measure jumps

Hz: 173°33'16" V: 71°33'04" Fn abc 06:12

OK

This option allows the measurement the length of a jump with respect to the foul line.

Press **OK**.

Measuring long jumps

To measure a jump, locate a prism on the point to measure and aim at the prism. Reflectorless measurements can be used if a reflectorless EDM is available.

The **Plot** page allows a graphical view of the jump in relation to the foul line.

The description of keys is valid for both pages.

Key	Description
Dist	To measure and display distances in Distance Jumped .
Store	To store the measurement. Depending on the configuration, the measurement is sent to a serial port and/or the log file. If the distance is sent successfully, a message appears.
Foul	To store the jump as invalid. Depending on the configuration, an invalid measurement is sent to a serial port and/or the log file. If the information is sent successfully, a message appears.
Page	To change to another page on this screen.
Fn Save	To save the measurement to the logfile.
Fn Fine	To change the display for Distance Jumped to fine mode. The distance is displayed with three decimal places for ten seconds. Then the display reverts to two decimal places. This function may be used for checking purposes but does not affect the recording of the data. All measurements are recorded in centimetres.

Description of fields

Field	Option	Description
Athlete ID	Editable field	The number of the athlete. Enter the number in order to save this information with the corresponding measurement in the log file.
Distance Jumped	Display only	The distance jumped.

5 Throwing Events

5.1 Understanding Terms and Expressions


Throwing events

The same methodology is used for the hammer, discus and shot putt and javelin events.

A foul line is delimited by a circle or part of a circle.


Once a throw is made, the calculated distance from the centre of the circle defining the foul line to the point where the implement lands is made. The radius of the circle (R for discus, hammer, shot putt, L for the javelin) is then subtracted from the calculated distance to give the reported distance.

The foul line for the hammer, discus and shot putt is represented by a circle (boundary) and is defined by measuring three points on the circle:



- a) Boundary
- b) Calculated distance
- c) Radius R of the circle
- d) Reported distance

The foul line for the javelin is represented by an arc defined by two points measured in a clockwise direction:



- a) Calculated distance
- b) Radius R of the circle
- c) Reported distance

Throwing events

The throwing events comprise four available events: **Discus**, **Hammer**, **Shot Putt** or **Javelin**.


The methodology used for each event is identical apart from the measurement of the javelin foul line. More details are given in the appropriate section of this chapter.

The process explained in this manual is applicable to all events except where any modifications to the process for a specific event are explicitly stated.

Steps of throwing measurements

A throwing event involves two steps. Each step in the process can be selected in the menu.

Step	Description
1.	Define the foul line.
2.	Measure the throw distance of each competitor.

Discus Menu

Key	Description
OK	To select the highlighted option and to continue with the subsequent screen.
Resum	To re-start measurements. Refer to "6 Resuming Measurements".
Fn Conf	To configure the Athletics application.
Fn Quit	To exit the screen.

Description of options

Option	Description
Measure centre point	The foul line for the throwing events is defined by a circle or part of a circle. In some installations, the centre of the circle is marked on the ground and may be measured. In this case, definition of the foul line is possible by simply measuring the centre point.
Measure foul line	If the centre point is not marked on the ground, it can be calculated by measuring three (two for javelin) points along the foul line.
Measure throw	To measure the distance of a throw. It is necessary to measure the foul line successfully before Measure throw can commence.

Next step


Select an option and press **OK**.

5.3

Measuring the Centre Point

Measuring the centre point


The centre point of a circle can be measured for each throw event.



Key	Description
Dist	To measure the distance from the instrument to the centre point.
Store	To store the centre point as the point from which measurements will be calculated.
Done	To return to the throw event menu. This function is only enabled once a valid distance has been stored.
Page	To change to another page on this screen.
Fn Config..	To configure the Athletics application.

Checking the centre point


The distance from the centre point of the circle to the foul line can be checked on the **Check** page.



The explanations given for the softkeys on the **Measure** page are valid.

Key	Description
Dist	To check the circle radius, measure a point on the foul line.

Description of fields

Field	Option	Description
Stored Radius	Display only	The radius of the event circle stored in the program configuration.  In the configuration, a different radius is stored for each throwing event. Refer to "2 Configuring Athletics" for information on the configuration.
Measured Radius	Display only	The measured distance from the centre point to the point measured on the foul line.

5.4

Measuring the Foul Line

Description

If the centre point of the throwing circle is unavailable, it is possible to define the foul line by measuring points along the line. In the case of the javelin, two points must be measured in a **clockwise** direction. For the other events, three points are measured on the foul line with the direction of measurement being unimportant.

The measure foul line function can be selected from the menu of each individual throw event.

Measuring points on the foul line

To measure a point on the foul line, locate a prism on the point to measure and aim at the prism. Reflectorless measurements can be used if a reflectorless EDM is available.

Repeated the process for the other points on the foul line.



In case of javelin, measure two points in **clockwise** direction.

Measure circle: Point 1 | ↻

Point ID: 1

Hz: 45°00'00"

V: 45°00'00"

Slope distance: 15.0344m

Aim at point on foul line and press Dist (F2)

Hz: 45°00'00" V: 45°00'00" Fn abc 19:57
Next | Dist | | | Back

Key	Description
Next	To store the measurement and to move on to measure the next point on the foul line. It is only possible to move on to the next point if a valid distance has been measured. To display the results, if all points have been measured.
Dist	To measure and display distances.
Back	To return to the previous screen.

Results

Once enough points have been measured successfully, the distance from the centre point of the circle to the foul line is displayed. Decide, if the requirements are met.

Discus: Circle centre | ↻

Point ID: Centre

Stored Radius: 1.2500m


Measured Radius: 1.2501m

Press Store (F3) to save result

Hz: 49°30'00" V: 45°00'01" Fn abc 20:00
| Store | Remea |

Key	Description
Store	To store the radius of the measured points and to return to throw event menu.
Remea	To return to the Measure circle: screen.

Description of fields

Field	Option	Description
Stored Radius	Display only	The radius of the event circle stored in the program configuration.  In the configuration, a different radius is stored for each throwing event. Refer to "2 Configuring Athletics" for information on the configuration.
Measured Radius	Display only	The measured distance from the centre point to the point measured on the foul line.

5.5

Measuring the Throws

Access

If the foul line has been measured successfully, the option **Measure throw** is enabled in the throw event menu.




This option allows the measurement the length of a throw with respect to the foul line.

Press **OK**.

Measuring throws

To measure a throw, locate a prism on the point to measure and aim at the prism. Reflectorless measurements can be used if a reflectorless EDM is available.



The **Plot** page allows a graphical view of the throw in relation to the foul line.

The description of keys is valid for both pages.

Key	Description
Dist	To measure and display distances in Event Distance .
Store	To store a valid throw measurement. Depending on the configuration, the measurement is sent to a serial port and/or the log file. If the distance is sent successfully, a message appears.
Foul	To store the throw as invalid. Depending on the configuration, an invalid measurement is sent to a serial port and/or the log file. If the information is sent successfully, a message appears.
Page	To change to another page on this screen.
Fn Save	To store the results to the logfile.

Key	Description
Fn Fine	To change the display for Event Distance to fine mode. The distance is displayed with three decimal places for ten seconds. Then the display reverts to two decimal places. This function may be used for checking purposes but does not affect the recording of the data. All measurements are recorded in centimetres.

Description of fields


Field	Option	Description
Athlete ID	Editable field	The number of the athlete. Enter the number in order to save this information with the corresponding measurement in the log file.
Distance Jumped	Display only	The distance jumped.

Access

Sometimes it is necessary to leave a measurement function and return at a later time, for example, to measure a distance for another event.

Either the ground plane and the base points or the foul line must have been measured successfully. A measurement function can then be re-started without re-measuring the ground plane and base points or the foul line.

To resume an existing measurement, enter the menu of an athletic event from the Main Menu.



Key	Description
Resum	To re-start pole vault measurements. The measured ground plane and base points or the foul line are recalled from the memory. The measurement screen starts up directly.

Total Quality Management: Our commitment to total customer satisfaction.



Leica Geosystems AG, Heerbrugg, Switzerland, has been certified as being equipped with a quality system which meets the International Standards of Quality Management and Quality Systems (ISO standard 9001) and Environmental Management Systems (ISO standard 14001).

Ask your local Leica Geosystems dealer/sales representative for more information about our TQM program.

805530-1.0.0en

Original text

Published in Switzerland

© 2013 Leica Geosystems AG, Heerbrugg, Switzerland

Leica Geosystems AG
Heinrich-Wild-Strasse
CH-9435 Heerbrugg
Switzerland
Phone +41 71 727 31 31
www.leica-geosystems.com

- when it has to be **right**

Leica
Geosystems