

Leica Geosystems

Licence Activation Guide

Licence Activation for GRX1200 Series

Dear valued customer...

Thank you for purchasing a licence for our product. The following instructions will guide you through the licence activation process.

- 👉 Please register your product at myWorld.leica-geosystems.com, our internet platform for our customers. myWorld provides 24/7 access to all information you require to actively manage your equipment. Here, detailed information on individual products and their service history can be found. The information also aids in maintaining the product value while at the same time enabling maximum efficiency and productivity.


Activate licence


- 👉 The procedure is valid for any licence key.

Step	Description		
👉	You can download licence keys from myWorld. Refer to "Download licence".		
👉	To upload a licence key, store the licence key file (for example L_2500123.key) in the \SYSTEM directory of the data storage device. Open a browser window and access the web interface of the GRX1200 Series receiver.		
1.	Go to Configuration\Firmware upgrades .		
2.	<table border="0"><tr><td>To type in a licence key: In the Licence upgrades section, enter the licence key in the empty text field and activate the radio button. Click Upgrade. The licence is activated and can be used.</td><td>To upload a licence key: The licence key is shown in the web interface once loaded onto the data storage device. Activate the radio button before the listed file.</td></tr></table>	To type in a licence key: In the Licence upgrades section, enter the licence key in the empty text field and activate the radio button. Click Upgrade . The licence is activated and can be used.	To upload a licence key: The licence key is shown in the web interface once loaded onto the data storage device. Activate the radio button before the listed file.
To type in a licence key: In the Licence upgrades section, enter the licence key in the empty text field and activate the radio button. Click Upgrade . The licence is activated and can be used.	To upload a licence key: The licence key is shown in the web interface once loaded onto the data storage device. Activate the radio button before the listed file.		
👉	If a software maintenance licence was activated refer to "Update software" to update the software on the product.		



- when it has to be **right**

Download licence

 The procedure is valid for any licence key.

Step	Description
1.	Go to www.myworld.leica-geosystems.com and log in.
2.	Go to myProducts and select your product.
	If your product is not in the list, click Add Product .
3.	On the Overview tab, click Download keys . In the next window, click Save and select a directory to save the file to. Click Save . Copy the *.key file to the \SYSTEM directory of the data storage device.

Update software

Step	Description
1.	Go to www.myworld.leica-geosystems.com and log in.
2.	Go to myProducts and select your product.
	If your product is not in the list, click Add Product .
3.	Click the Software tab and download the GRX1200 Series system firmware and web interface file to your computer.
4.	Upload the files to the \SYSTEM directory of the data storage device.
5.	Open a browser and access the web interface of your receiver.
6.	Go to Configuration\Firmware upgrades .
7.	The firmware file on the data storage device is displayed in the Firmware upgrades section. Activate the radio button and press Upgrade .
8.	The software is installed on the receiver.
	Allow the receiver to reboot twice to make sure the web interface files are installed.

In case activation fails...

In case the licence activation fails:

- contact your local Leica Geosystems agency.

OR

- create new support requests on myWorld.leica-geosystems.com that will be answered by your local Leica Geosystems Support Team.

- when it has to be **right**