


10dec07 tilt sensor az swings after td nut change PITCH – (c0+c1*az from fit)



10dec07 tilt sensor az swings after td nut change Roll – (c0+c1*az from fit)

