
Tsys vs Az for various shims. freq=3414 Pol:I RemoveBase.
3C274 nshims:2
3C405 nshims:3
3C461 nshims:4
nshims:5
Deg K
Az [deg]
70
60
50
40
30
0
100
200


Tsys vs Az for various shims. freq=3414 Pol:A RemoveBase.
Deg K
Az [deg]
70
60
50
40
30
0
100
200


Tsys vs Az for various shims. freq=3414 Pol:B RemoveBase.
Deg K
Az [deg]
70
60
50
40
30
0
100
200


Gain vs Az for various shims. freq=3414 Pol:I RemoveBase.
3C274 nshims:2
3C405 nshims:3
3C461 nshims:4
nshims:5
K/Jy
0.04
0.03
0.02
0.01
0.00
0
100
200
Az [deg]


Gain vs Az for various shims. freq=3414 Pol:A RemoveBase.
K/Jy
0.04
0.03
0.02
0.01
0.00
0
100
200
Az [deg]


Gain vs Az for various shims. freq=3414 Pol:B RemoveBase.
K/Jy
0.04
0.03
0.02
0.01
0.00
0
100
200
Az [deg]


SEFD vs Az for various shims. freq=3414 Pol:I RemoveBase.
3C274 nshims:2
3C405 nshims:3
3C461 nshims:4
nshims:5
Jy
Az [deg]
5000
4000
3000
2000
1000
0
0
100
200


SEFD vs Az for various shims. freq=3414 Pol:A RemoveBase.
Jy
Az [deg]
5000
4000
3000
2000
1000
0
0
100
200


SEFD vs Az for various shims. freq=3414 Pol:B RemoveBase.
Jy
Az [deg]
5000
4000
3000
2000
1000
0
0
100
200


Az BmWidth vs Az for various shims. freq=3414 Pol:I RemoveBase.
3C274 nshims:2
3C405 nshims:3
3C461 nshims:4
nshims:5
Amin
Az [deg]
40
35
30
25
20
15
10
0
100
200


Az BmWidth vs Az for various shims. freq=3414 Pol:A RemoveBase.
Amin
Az [deg]
40
35
30
25
20
15
10
0
100
200


Az BmWidth vs Az for various shims. freq=3414 Pol:B RemoveBase.
Amin
Az [deg]
40
35
30
25
20
15
10
0
100
200

El BmWidth vs Az for various shims. freq=3414 Pol:I RemoveBase.



El BmWidth vs Az for various shims. freq=3414 Pol:A RemoveBase.



El BmWidth vs Az for various shims. freq=3414 Pol:B RemoveBase.




Az/El BmWdRatio vs Az for various shims. freq=3414 Pol:I RemoveBase.
3C274 nshims:2
3C405 nshims:3
3C461 nshims:4
nshims:5
bmWdAz/bmWdEl
Az [deg]
2.0
1.5
1.0
0.5
0.0
0
100
200


Az/El BmWdRatio vs Az for various shims. freq=3414 Pol:A RemoveBase.
bmWdAz/bmWdEl
Az [deg]
2.0
1.5
1.0
0.5
0.0
0
100
200


Az/El BmWdRatio vs Az for various shims. freq=3414 Pol:B RemoveBase.
bmWdAz/bmWdEl
Az [deg]
2.0
1.5
1.0
0.5
0.0
0
100
200

Az Pointing error vs Az for various shims. freq=3414 Pol:I RemoveBase.



Az Pointing error vs Az for various shims. freq=3414 Pol:A RemoveBase.



Az Pointing error vs Az for various shims. freq=3414 Pol:B RemoveBase.



El pointing error vs Az for various shims. freq=3414 Pol:I RemoveBase.



El pointing error vs Az for various shims. freq=3414 Pol:A RemoveBase.



El pointing error vs Az for various shims. freq=3414 Pol:B RemoveBase.