
Tsys vs El for various shims. freq=3414 Pol:I RemoveBase.
3C274 nshims:2
3C405 nshims:3
3C461 nshims:4
nshims:5
Deg K
El [deg]
70
60
50
40
30
0
20
40
60
80


Tsys vs El for various shims. freq=3414 Pol:A RemoveBase.
Deg K
El [deg]
70
60
50
40
30
0
20
40
60
80


Tsys vs El for various shims. freq=3414 Pol:B RemoveBase.
Deg K
El [deg]
70
60
50
40
30
0
20
40
60
80


Gain vs El for various shims. freq=3414 Pol:I RemoveBase.
3C274 nshims:2
3C405 nshims:3
3C461 nshims:4
nshims:5
K/Jy
0.04
0.03
0.02
0.01
0.00
0
20
40
60
80
El [deg]


Gain vs El for various shims. freq=3414 Pol:A RemoveBase.
K/Jy
0.04
0.03
0.02
0.01
0.00
0
20
40
60
80
El [deg]


Gain vs El for various shims. freq=3414 Pol:B RemoveBase.
K/Jy
0.04
0.03
0.02
0.01
0.00
0
20
40
60
80
El [deg]


SEFD vs El for various shims. freq=3414 Pol:I RemoveBase.
3C274 nshims:2
3C405 nshims:3
3C461 nshims:4
nshims:5
Jy
El [deg]
0
1000
2000
3000
4000
5000
0
20
40
60
80


SEFD vs El for various shims. freq=3414 Pol:A RemoveBase.
Jy
El [deg]
0
1000
2000
3000
4000
5000
0
20
40
60
80


SEFD vs El for various shims. freq=3414 Pol:B RemoveBase.
Jy
El [deg]
0
1000
2000
3000
4000
5000
0
20
40
60
80

Az BmWidth vs El for various shims. freq=3414 Pol:I RemoveBase.



Az BmWidth vs El for various shims. freq=3414 Pol:A RemoveBase.



Az BmWidth vs El for various shims. freq=3414 Pol:B RemoveBase.



El BmWidth vs El for various shims. freq=3414 Pol:I RemoveBase.



El BmWidth vs El for various shims. freq=3414 Pol:A RemoveBase.



El BmWidth vs El for various shims. freq=3414 Pol:B RemoveBase.



Az/El BmWdRatio vs El for various shims. freq=3414 Pol:I RemoveBase.



Az/El BmWdRatio vs El for various shims. freq=3414 Pol:A RemoveBase.



Az/El BmWdRatio vs El for various shims. freq=3414 Pol:B RemoveBase.



Az Pointing error vs El for various shims. freq=3414 Pol:I RemoveBase.



Az Pointing error vs El for various shims. freq=3414 Pol:A RemoveBase.



Az Pointing error vs El for various shims. freq=3414 Pol:B RemoveBase.



El pointing error vs El for various shims. freq=3414 Pol:I RemoveBase.



El pointing error vs El for various shims. freq=3414 Pol:A RemoveBase.



El pointing error vs El for various shims. freq=3414 Pol:B RemoveBase.