
Tsys vs Az for various shims. freq=8223 Pol:I RemoveBase.
3C144 nshims:0
3C274 nshims:1
3C405 nshims:2
3C461 nshims:3
nshims:4
nshims:5
Deg K
Az [deg]


Tsys vs Az for various shims. freq=8223 Pol:A RemoveBase.
Deg K
Az [deg]


Tsys vs Az for various shims. freq=8223 Pol:B RemoveBase.
Deg K
Az [deg]


Gain vs Az for various shims. freq=8223 Pol:I RemoveBase.
0.025
0.020
0.015
0.010
0.005
0.000
K/Jy
0
100
200
Az [deg]
3C144 nshims:0
3C274 nshims:1
3C405 nshims:2
3C461 nshims:3
nshims:4
nshims:5


Gain vs Az for various shims. freq=8223 Pol:A RemoveBase.
0.025
0.020
0.015
0.010
0.005
0.000
K/Jy
0
100
200
Az [deg]


Gain vs Az for various shims. freq=8223 Pol:B RemoveBase.
0.025
0.020
0.015
0.010
0.005
0.000
K/Jy
0
100
200
Az [deg]


SEFD vs Az for various shims. freq=8223 Pol:I RemoveBase.
2.0•10^4
1.5•10^4
1.0•10^4
5.0•10^3
0
Jy
0
100
200
Az [deg]
3C144 nshims:0
3C274 nshims:1
3C405 nshims:2
3C461 nshims:3
nshims:4
nshims:5


SEFD vs Az for various shims. freq=8223 Pol:A RemoveBase.
2.0•10^4
1.5•10^4
1.0•10^4
5.0•10^3
0
Jy
0
100
200
Az [deg]


SEFD vs Az for various shims. freq=8223 Pol:B RemoveBase.
2.0•10^4
1.5•10^4
1.0•10^4
5.0•10^3
0
Jy
0
100
200
Az [deg]


Az BmWidth vs Az for various shims. freq=8223 Pol:I RemoveBase.
3C144 nshims:0
3C274 nshims:1
3C405 nshims:2
3C461 nshims:3
nshims:4
nshims:5
Amin
Az [deg]
0
5
10
15
20
25
0
100
200


Az BmWidth vs Az for various shims. freq=8223 Pol:A RemoveBase.
Amin
Az [deg]
0
5
10
15
20
25
0
100
200


Az BmWidth vs Az for various shims. freq=8223 Pol:B RemoveBase.
Amin
Az [deg]
0
5
10
15
20
25
0
100
200

El BmWidth vs Az for various shims. freq=8223 Pol:I RemoveBase.



El BmWidth vs Az for various shims. freq=8223 Pol:A RemoveBase.



El BmWidth vs Az for various shims. freq=8223 Pol:B RemoveBase.




Az/El BmWdRatio vs Az for various shims. freq=8223 Pol:I RemoveBase.
bmWdAz/bmWdEl
Az [deg]
3C144 nshims:0
3C274 nshims:1
3C405 nshims:2
3C461 nshims:3
nshims:4
nshims:5


Az/El BmWdRatio vs Az for various shims. freq=8223 Pol:A RemoveBase.
bmWdAz/bmWdEl
Az [deg]


Az/El BmWdRatio vs Az for various shims. freq=8223 Pol:B RemoveBase.
bmWdAz/bmWdEl
Az [deg]

Az Pointing error vs Az for various shims. freq=8223 Pol:I RemoveBase.



Az Pointing error vs Az for various shims. freq=8223 Pol:A RemoveBase.



Az Pointing error vs Az for various shims. freq=8223 Pol:B RemoveBase.



El pointing error vs Az for various shims. freq=8223 Pol:I RemoveBase.



El pointing error vs Az for various shims. freq=8223 Pol:A RemoveBase.



El pointing error vs Az for various shims. freq=8223 Pol:B RemoveBase.