THIS DRAWING SHOWS THE CONNECTIONS
BETWEEN THE

TRANSMITTER,
RECEIVER RACK CONTROL PANEL,
UPSTAIRS LO GATING,
DOWNSTAIRS LO GATING
DOWNSTAIRS IF CUTOFF
MONOPLEXERS,
JENNINGS COAX SWITCH
WAVEGUIDE Y SWITCH
NOISE PULSE INJECTION CIRCUITS
FREQENCY REFERENCE(S)

430 TRANSMITTER
DWG. 430_RCVR
TITLE: INTERFACE WITH RECEIVING SYSTEM
JBH 10-17-01