
Tsys vs El for various shims. freq=8647 Pol:I RemoveBase.
3C144 nshims:0
3C274 nshims:1
3C405 nshims:2
3C461 nshims:3
nshims:4
nshims:5
Deg K
El [deg]


Tsys vs El for various shims. freq=8647 Pol:A RemoveBase.
Deg K
El [deg]


Tsys vs El for various shims. freq=8647 Pol:B RemoveBase.
Deg K
El [deg]


Gain vs El for various shims. freq=8647 Pol:I RemoveBase.
0.020
0.015
0.010
0.005
0.000
K/Jy
0
20
40
60
80
El [deg]
3C144
3C274
3C405
3C461
nshims:0
nshims:1
nshims:2
nshims:3
nshims:4
nshims:5


Gain vs El for various shims. freq=8647 Pol:A RemoveBase.
0.020
0.015
0.010
0.005
0.000
K/Jy
0
20
40
60
80
El [deg]


Gain vs El for various shims. freq=8647 Pol:B RemoveBase.
0.020
0.015
0.010
0.005
0.000
K/Jy
0
20
40
60
80
El [deg]


SEFD vs El for various shims. freq=8647 Pol:I RemoveBase.
3C144 nshims:0
3C274 nshims:1
3C405 nshims:2
3C461 nshims:3
nshims:4
nshims:5
Jy
El [deg]


SEFD vs El for various shims. freq=8647 Pol:A RemoveBase.
Jy
El [deg]


SEFD vs El for various shims. freq=8647 Pol:B RemoveBase.
Jy
El [deg]


Az BmWidth vs El for various shims. freq=8647 Pol:I RemoveBase.
3C144 nshims:0
3C274 nshims:1
3C405 nshims:2
3C461 nshims:3
nshims:4
nshims:5
Amin
El [deg]
0
5
10
15
20
25
0
20
40
60
80


Az BmWidth vs El for various shims. freq=8647 Pol:A RemoveBase.
Amin
El [deg]
0
5
10
15
20
25
0
20
40
60
80


Az BmWidth vs El for various shims. freq=8647 Pol:B RemoveBase.
Amin
El [deg]
0
5
10
15
20
25
0
20
40
60
80

El BmWidth vs El for various shims. freq=8647 Pol:I RemoveBase.




El BmWidth vs El for various shims. freq=8647 Pol:A RemoveBase.




El BmWidth vs El for various shims. freq=8647 Pol:B RemoveBase.




Az/El BmWdRatio vs El for various shims. freq=8647 Pol:I RemoveBase.
bmWdAz/bmWdEl
El [deg]
3C144 nshims:0
3C274 nshims:1
3C405 nshims:2
3C461 nshims:3
nshims:4
nshims:5


Az/El BmWdRatio vs El for various shims. freq=8647 Pol:A RemoveBase.
bmWdAz/bmWdEl
El [deg]


Az/El BmWdRatio vs El for various shims. freq=8647 Pol:B RemoveBase.
bmWdAz/bmWdEl
El [deg]

Az Pointing error vs El for various shims. freq=8647 Pol:I RemoveBase.




Az Pointing error vs El for various shims. freq=8647 Pol:A RemoveBase.




Az Pointing error vs El for various shims. freq=8647 Pol:B RemoveBase.



El pointing error vs El for various shims. freq=8647 Pol:I RemoveBase.




El pointing error vs El for various shims. freq=8647 Pol:A RemoveBase.




El pointing error vs El for various shims. freq=8647 Pol:B RemoveBase.