
Tsys vs Az for various shims. freq=9073 Pol:I RemoveBase.
3C274 nshims:2
3C405 nshims:3
nshims:4
nshims:5
Deg K
Az [deg]
80
70
60
50
40
30
0
100
200


Tsys vs Az for various shims. freq=9073 Pol:A RemoveBase.
Deg K
Az [deg]
80
70
60
50
40
30
0
100
200


Tsys vs Az for various shims. freq=9073 Pol:B RemoveBase.
Deg K
Az [deg]
80
70
60
50
40
30
0
100
200


Gain vs Az for various shims. freq=9073 Pol:I RemoveBase.
3C274 nshims:2
3C405 nshims:3
nshims:4
nshims:5
K/Jy
0.025
0.020
0.015
0.010
0.005
0.000
0
100
200
Az [deg]


Gain vs Az for various shims. freq=9073 Pol:A RemoveBase.
K/Jy
0.025
0.020
0.015
0.010
0.005
0.000
0
100
200
Az [deg]


Gain vs Az for various shims. freq=9073 Pol:B RemoveBase.
K/Jy
0.025
0.020
0.015
0.010
0.005
0.000
0
100
200
Az [deg]


SEFD vs Az for various shims. freq=9073 Pol:I RemoveBase.
3C274 nshims:2
3C405 nshims:3
nshims:4
nshims:5
Jy
Az [deg]
10000
8000
6000
4000
2000
0
0
100
200


SEFD vs Az for various shims. freq=9073 Pol:A RemoveBase.
Jy
Az [deg]
10000
8000
6000
4000
2000
0
0
100
200


SEFD vs Az for various shims. freq=9073 Pol:B RemoveBase.
Jy
Az [deg]
10000
8000
6000
4000
2000
0
0
100
200


Az BmWidth vs Az for various shims. freq=9073 Pol:I RemoveBase.
3C274 nshims:2
3C405 nshims:3
nshims:4
nshims:5
Amin
Az [deg]
20
18
16
14
12
10
8
6
0
100
200


Az BmWidth vs Az for various shims. freq=9073 Pol:A RemoveBase.
Amin
Az [deg]
20
18
16
14
12
10
8
6
0
100
200


Az BmWidth vs Az for various shims. freq=9073 Pol:B RemoveBase.
Amin
Az [deg]
20
18
16
14
12
10
8
6
0
100
200

El BmWidth vs Az for various shims. freq=9073 Pol:I RemoveBase.



El BmWidth vs Az for various shims. freq=9073 Pol:A RemoveBase.



El BmWidth vs Az for various shims. freq=9073 Pol:B RemoveBase.




Az/El BmWdRatio vs Az for various shims. freq=9073 Pol:I RemoveBase.
bmWdAz/bmWdEl
Az [deg]
3C274 nshims:2
3C405 nshims:3
nshims:4
nshims:5
0.0
0.5
1.0
1.5
2.0
0
100
200


Az/El BmWdRatio vs Az for various shims. freq=9073 Pol:A RemoveBase.
bmWdAz/bmWdEl
Az [deg]
0.0
0.5
1.0
1.5
2.0
0
100
200


Az/El BmWdRatio vs Az for various shims. freq=9073 Pol:B RemoveBase.
bmWdAz/bmWdEl
Az [deg]
0.0
0.5
1.0
1.5
2.0
0
100
200

Az Pointing error vs Az for various shims. freq=9073 Pol:I RemoveBase.



Az Pointing error vs Az for various shims. freq=9073 Pol:A RemoveBase.



Az Pointing error vs Az for various shims. freq=9073 Pol:B RemoveBase.



El pointing error vs Az for various shims. freq=9073 Pol:I RemoveBase.



El pointing error vs Az for various shims. freq=9073 Pol:A RemoveBase.



El pointing error vs Az for various shims. freq=9073 Pol:B RemoveBase.