

Programming Guide

Keysight FieldFox Handheld Analyzers

Table of Contents

| | |
|--|----|
| Home - List of Commands by Mode | 1 |
| See Also | 1 |
| SCPI Concepts and Tips | 3 |
| SCPI Concepts and Tips | 3 |
| FieldFox Programming Tips | 3 |
| Correction Methods Explained | 4 |
| Cal Methods | 5 |
| Summary | 6 |
| How the FieldFox Error Queue Works | 7 |
| Instrument Console (IC) | 8 |
| The Rules and Syntax of SCPI | 9 |
| SCPI Errors | 13 |
| Examples | 21 |
| FieldFox Programming Examples | 21 |
| NA Mode | 21 |
| Calibration Examples | 23 |
| QuickCals | 26 |
| Guided Calibration | 28 |
| ECal Calibration | 29 |
| Marker Example | 30 |
| FOPS Measurement | 31 |
| VVM Mode Example | 32 |
| VVS Example | 33 |
| C# Example Program | 34 |
| Read Block Data using Csharp | 41 |
| Transfer Image to PC | 42 |
| VEE | 43 |
| Get Formatted Data as Real 32 Binary Block | 43 |
| Get Formatted Data as ASCII Output | 44 |
| Trigger Synch Sweep Complete | 45 |
| SpecAn Get Data as ASCII Output | 46 |
| Commands by Mode | 49 |
| CAT Mode Commands | 49 |
| NA Mode Commands | 54 |
| SA Mode Commands | 60 |
| USB Power Meter Mode Commands | 68 |
| FOPS (Option 208) unique commands | 69 |
| Built-in Power Meter (CPM) Mode Commands | 71 |

| | |
|--|-----|
| VVM Mode Commands | 72 |
| Pulse Measurements (Option 330) Commands | 73 |
| ERTA Mode Commands | 76 |
| Channel Scanner Mode (Option 312) Commands - Requires SA | 77 |
| AM/FM Metrics (Option 355) Commands - Requires SA | 79 |
| Commands that are Common to All Modes | 80 |
| Command Reference | 87 |
| New Programming Commands | 87 |
| A.08.15 and A.09.15 | 87 |
| A.08.04 | 88 |
| A.08.00 | 88 |
| A.07.75 | 89 |
| A.07.50 | 90 |
| A.07.25 | 90 |
| A.07.00 | 91 |
| A.06.17 | 91 |
| A.06.00 | 92 |
| A.05.50 | 93 |
| A.05.30 | 93 |
| Replacement Commands | 94 |
| Common Commands | 94 |
| CALCulate:FEED:MODE <char> | 95 |
| CALCulate:IREJection:LEVel <char> | 96 |
| CALCulate:MARKer:AUDio:BEeP <bool> | 96 |
| CALCulate:MARKer<n>:DREF:FIXed <bool> | 97 |
| CALCulate:MARKer<n>:FCOunt[:STATe] <bool> | 97 |
| CALCulate:MARKer:FCOunt:X? | 98 |
| CALCulate:MARKer<n>:FUNctioN <char> | 98 |
| CALCulate:MARKer:FUNctioN:BAND:SPAN <num> | 99 |
| CALCulate:MARKer:FUNctioN:BAND:SPAN:AUTO <bool> | 99 |
| CALCulate:MARKer:FUNctioN:INTerval:SPAN <num> | 100 |
| CALCulate:MARKer:FUNctioN:INTerval:SPAN:AUTO <bool> | 100 |
| CALCulate:MARKer<n>:FUNctioN:PLEft | 101 |
| CALCulate:MARKer<n>:FUNctioN:PRIGht | 101 |
| CALCulate:MARKer<n>:NOISe[:STATe] <bool> - Superseded | 101 |
| CALCulate:MARKer<n>:SET:CENTer | 102 |
| CALCulate:MARKer<n>:SET:REFLeVel | 102 |
| CALCulate:MARKer:TZERo:FIXed <bool> | 102 |
| CALCulate:MEASure:DATA? | 103 |
| CALCulate:MEASurement:QAMPliTude? | 105 |

| | |
|---|-----|
| :CALCulate:PARAmeter:COUNT <n> | 105 |
| CALCulate:PARAmeter<tr>:DEFine <char> | 106 |
| :CALCulate:PARAmeter<tr>:SElect..... | 107 |
| CALCulate:RELative[:MAGNitude]:AUTO <bool> | 108 |
| CALCulate[:SElected]:AMPLitude:MARKer:DELTA:STATe <bool> | 108 |
| CALCulate[:SElected]:AMPLitude:MARKer:STATe <bool> | 109 |
| CALCulate[:SElected]:AMPLitude:MARKer:Y1 <num> | 109 |
| CALCulate[:SElected]:AMPLitude:MARKer:Y2 <num> | 110 |
| CALCulate[:SElected]:CONVersion:FUNction <char> | 110 |
| CALCulate[:SElected]:CORRection:EDELay:TIME <num> | 111 |
| CALCulate[:SElected]:CORRection:OFFSet:PHASe <num> | 112 |
| CALCulate[:SElected]:DATA:FDATA <data> | 112 |
| CALCulate[:SElected]:DATA:FMEM <data> | 113 |
| CALCulate[:SElected]:DATA:SDATA <data> | 113 |
| CALCulate[:SElected]:DATA:SMEM <data> | 114 |
| CALCulate[:SElected]:FILTer[:GATE]:TIME:CENTer <num> | 114 |
| CALCulate[:SElected]:FILTer[:GATE]:TIME:SHAPE <char> | 114 |
| CALCulate[:SElected]:FILTer[:GATE]:TIME:SPAN <num> | 115 |
| CALCulate[:SElected]:FILTer[:GATE]:TIME:START <num> | 115 |
| CALCulate[:SElected]:FILTer[:GATE]:TIME:STATe <bool> | 116 |
| CALCulate[:SElected]:FILTer[:GATE]:TIME:STOP <num> | 116 |
| CALCulate[:SElected]:FILTer[:GATE]:TIME[:TYPE] <char> | 117 |
| CALCulate[:SElected]:FMEM:DATA? | 117 |
| CALCulate[:SElected]:FORMat <char> | 118 |
| CALCulate[:SElected]:LIMit:BEEP <bool> - Superseded | 118 |
| CALCulate[:SElected]:LIMit:DATA <data> - Superseded..... | 119 |
| CALCulate[:SElected]:LIMit:LLData <data> | 120 |
| CALCulate[:SElected]:LIMit:SOUNd <char> | 121 |
| CALCulate[:SElected]:LIMit[:STATe] | 122 |
| CALCulate[:SElected]:LIMit:WARN <bool> | 122 |
| CALCulate[:SElected]:MARKer<n>:ACTivate..... | 123 |
| CALCulate[:SElected]:MARKer:AOFF | 123 |
| CALCulate[:SElected]:MARKer:BWIDth:DATA?..... | 124 |
| CALCulate[:SElected]:MARKer:BWIDth[:STATe] <bool> | 124 |
| CALCulate[:SElected]:MARKer:COUPlEd <bool> | 125 |
| CALCulate[:SElected]:MARKer:FORMat <char>..... | 125 |
| CALCulate[:SElected]:MARKer:FUNction:BWIDth:THReshold <value> | 126 |
| CALCulate[:SElected]:MARKer<n>:FUNction:FALLtime <num> | 126 |
| CALCulate[:SElected]:MARKer<n>:FUNction:MAXimum | 127 |
| CALCulate[:SElected]:MARKer<n>:FUNction:MINimum | 127 |

| | |
|---|-----|
| CALCulate[:SElected]:MARKer:FUNction:PEXCursion <num> | 128 |
| CALCulate[:SElected]:MARKer<n>:FUNction:PNEXT | 128 |
| CALCulate[:SElected]:MARKer:FUNction:PTHReshold <num> | 129 |
| CALCulate[:SElected]:MARKer:FUNction:RISetime <num> | 129 |
| CALCulate[:SElected]:MARKer:FUNction:TARGet <value> | 130 |
| CALCulate[:SElected]:MARKer:FUNction:TDIRection <value> | 131 |
| CALCulate[:SElected]:MARKer<n>:FUNction:TRACking <bool> | 131 |
| CALCulate[:SElected]:MARKer:FUNction:ZONE <bool> | 132 |
| CALCulate[:SElected]:MARKer<n>:SET <char> | 132 |
| CALCulate[:SElected]:MARKer<n>[:STATe] <char> | 133 |
| CALCulate[:SElected]:MARKer<n>:TRACe <tnum> | 134 |
| CALCulate[:SElected]:MARKer<n>:X <num> | 135 |
| CALCulate[:SElected]:MARKer<n>:Y? | 135 |
| CALCulate[:SElected]:MATH:FUNction <char> | 136 |
| CALCulate[:SElected]:MATH:MEMorize | 136 |
| CALCulate[:SElected]:SMOothing:APERture <num> | 137 |
| CALCulate[:SElected]:SMOothing[:STATe] <bool> | 137 |
| CALCulate[:SElected]:TIME:AUX:CENTer <num> | 138 |
| CALCulate[:SElected]:TIME:AUX:PDIVision <num> | 138 |
| CALCulate[:SElected]:TIME:CENTer <num> | 139 |
| CALCulate[:SElected]:TIME:LENGth <num> | 139 |
| CALCulate[:SElected]:TIME:PDIVision <num> | 140 |
| CALCulate[:SElected]:TIME:STARt <num> | 140 |
| CALCulate[:SElected]:TRACe<n>:DATA? | 140 |
| CALCulate[:SElected]:TRANSform:DISTance:BANdpass <bool> | 141 |
| CALCulate[:SElected]:TRANSform:DISTance:FREQUency:CENTer <num> | 141 |
| CALCulate[:SElected]:TRANSform:DISTance:FREQUency:SPAN:MAXimum <num> | 142 |
| CALCulate[:SElected]:TRANSform:DISTance:FREQUency:STARt:MINimum <num> | 142 |
| CALCulate[:SElected]:TRANSform:DISTance:FREQUency:STOP:MAXimum <num> | 142 |
| CALCulate[:SElected]:TRANSform:DISTance:STARt <num> | 143 |
| CALCulate[:SElected]:TRANSform:DISTance:STOP <num> | 143 |
| CALCulate[:SElected]:TRANSform:DISTance:UNIT <char> | 143 |
| CALCulate[:SElected]:TRANSform:DISTance:WINDow <char> | 144 |
| CALCulate[:SElected]:TRANSform:FREQUency[:TYPE] <char> | 144 |
| CALCulate[:SElected]:TRANSform:TIME:CENTer <num> | 145 |
| CALCulate[:SElected]:TRANSform:TIME:IMPulse:WIDth <num> | 145 |
| CALCulate[:SElected]:TRANSform:TIME:KBESsel <num> | 146 |
| CALCulate[:SElected]:TRANSform:TIME:LPFRequency | 146 |
| CALCulate[:SElected]:TRANSform:TIME:SPAN <num> | 146 |
| CALCulate[:SElected]:TRANSform:TIME:STARt <num> | 147 |

CALCulate[:SElected]:TRANSform:TIME:STATe <bool> 147

CALCulate[:SElected]:TRANSform:TIME:STEP:RTIME <num> 148

CALCulate[:SElected]:TRANSform:TIME:STIMulus <char> 148

CALCulate[:SElected]:TRANSform:TIME:STOP <num> 149

CALCulate[:SElected]:TRANSform:TIME:TYPE <char> 149

CALibration:ZERO:TYPE:EXT 150

DISPlay:ANNOtation:FREQuency <value> 150

DISPlay:BRIGhtness <num> 151

DISPlay:DATE:FMT <char> 151

DISPlay:ENABLE <bool> 151

DISPlay:GRID <bool> 152

DISPlay:KEYWOrd[:DATA] <string1,2,3,4,5,6,7,8> 152

DISPlay:KEYWOrd:DEFault 153

DISPlay:MARKer:LARGe:STATe <char> 153

DISPlay:MARKer:LARGe:<x>:DEFine:LINE<n>:FORMat <char> 154

DISPlay:MARKer:LARGe:<x>:DEFine:LINE:MARKer<n>:STATe <char> 154

DISPlay:MARKer:LARGe:<x>:DEFine:LINE<n>:MNUMber <value> 155

DISPlay:MARKer:LARGe:<x>:DEFine:LINE<n>:STATe <bool> 156

DISPlay:MARKer:LARGe:<x>:DEFine:LINE<n>:TNUMber <value> 156

DISPlay:MARKer:LARGe:<x>:DEFine:LINE<n>:TRACKing <bool> 157

DISPlay:MARKer:LARGe:<x>:DEFine:TRACe<n>:BWIDth:STATe <value> 157

DISPlay:MARKer:LARGe:<x>:DEFine:TRACe<n>:FORMat <value> 158

DISPlay:MARKer:LARGe:<x>:DEFine:TRACe<n>:MEASurement <value> 159

DISPlay:MARKer:LARGe:<x>:FONT <char> 160

DISPlay:MARKer:LARGe:<x>:TRACe:COUNt <char> 160

DISPlay:TABLE:MARKer <bool> 161

DISPlay:TABLE:RESults:DATA? 161

DISPlay:TABLE:RESults <bool> 162

DISPlay:TIME:FMT <char> 162

DISPlay:TITLe:DATA <string> 163

DISPlay:TITLe[:STATe] <bool> 163

DISPlay:WINDow:ANALog:LOWer <num> 163

DISPlay:WINDow:ANALog:UPPer <num> 164

DISPlay:WINDow[:NUMeric]:RESolution <num> 164

:DISPlay:WINDow:SPLit <char> 165

DISPlay:WINDow:TRACe<n>:MEMory[:STATe] <bool> 165

DISPlay:WINDow:TRACe<n>:STATe <bool> 166

DISPlay:WINDow:TRACe:Y:DLINe <num> 166

DISPlay:WINDow:TRACe:Y:DLINe:STATe <bool> 167

DISPlay:WINDow:TRACe<n>:Y[:SCALE]:AUTO 167

| | |
|---|-----|
| DISPlay:WINDow:TRACe<n>:Y[:SCALe]:BOTTom <num> | 168 |
| DISPlay:WINDow:TRACe<n>:Y[:SCALe]:PDIVision <num> | 169 |
| DISPlay:WINDow:TRACe<n>:Y[:SCALe]:RLEVel <num> | 169 |
| DISPlay:WINDow:TRACe<n>:Y[:SCALe]:RPOSition <num> | 170 |
| DISPlay:WINDow:TRACe<n>:Y[:SCALe]:TOP <num> | 170 |
| DISPlay:WINDow:TRACe <value> | 171 |
| DISPlay:WINDow:ZOOM <bool> | 172 |
| FORMat:BORDER <char> | 172 |
| FORMat[:DATA] <char> | 173 |
| INITiate:CONTInuous <bool> | 174 |
| INITiate[:IMMediate] | 175 |
| INITiate:REStart | 175 |
| INSTrument:CATalog? | 175 |
| INSTrument:GTL | 176 |
| INSTrument:GTR | 176 |
| INSTrument[:SElect] <string> | 176 |
| MMEMory:CATalog? [string] | 177 |
| MMEMory:CDIRectory <string> | 178 |
| MMEMory:COpy <file1>,<file2> | 178 |
| MMEMory:DATA <filename>,<data> | 179 |
| MMEMory:DELeTe <string> | 180 |
| MMEMory:LOAD:ANTenna <string>,<char> | 180 |
| MMEMory:LOAD:CABLe <string>,<char> | 181 |
| MMEMory:LOAD:STATe <string> | 182 |
| MMEMory:MDIRectory <string> | 182 |
| MMEMory:MOVE <file1>,<file2> | 183 |
| MMEMory:RDIRectory <string>[,<recursive>] | 183 |
| MMEMory:STORe:ANTenna <string>,<char> | 184 |
| MMEMory:STORe:CABLe <string>,<char> | 185 |
| MMEM:STORe:FDATa <filename> | 185 |
| :MMEMory:STORe:IMAGe <string> | 186 |
| MMEMory:STORe:SNP[:DATA] <filename> | 186 |
| MMEMory:STORe:STATe <string> | 187 |
| :RECPlyback:ACTion:PAUSe | 187 |
| :RECPlyback:ACTion:PLAY | 187 |
| :RECPlyback:ACTion:RECOrd | 188 |
| :RECPlyback:ACTion:SPOSition <num> | 188 |
| :RECPlyback:ACTion:STOP | 188 |
| :RECPlyback:ACTion:TPOSition <num> | 188 |
| :RECPlyback:CONFIg:FMTRigger:DATA <data> - Superseded | 189 |

| | |
|---|-----|
| :RECPPlayback:CONFIg:FMTRigger:ENABLE <bool>..... | 190 |
| :RECPPlayback:CONFIg:FMTRigger:LLData <data> | 190 |
| :RECPPlayback:CONFIg:PTINterval <num> | 191 |
| :RECPPlayback:CONFIg:RSCLength <num> | 192 |
| :RECPPlayback:CONFIg:RSOource <char> | 192 |
| :RECPPlayback:CONFIg:RTINerval <num> | 192 |
| :RECPPlayback:CONFIg:RTLSeconds <num>..... | 193 |
| :RECPPlayback:SESSion:CARecords..... | 193 |
| :RECPPlayback:SESSion:CLOSE | 193 |
| :RECPPlayback:SESSion:NEW..... | 194 |
| :RECPPlayback:SESSion:OPEN? <string> | 194 |
| :RECPPlayback:SESSion:SDEvice <char>..... | 194 |
| :RECPPlayback:SESSion:TRLimit <num> | 195 |
| [:SENSe]:ACPoweR:LIMit[:STATe] <bool> | 195 |
| [:SENSe]:ACPoweR:MREFerence <num> | 195 |
| [:SENSe]:ACPoweR:MREFerence:AUTO <bool> | 196 |
| [:SENSe]:ACPoweR:MTYPE <char>..... | 196 |
| [:SENSe]:ACPoweR:OFFSet<n>:BWIDth <num>..... | 197 |
| [:SENSe]:ACPoweR:OFFSet<n>:FREQUency <num>..... | 197 |
| [:SENSe]:ACPoweR:OFFSet<n>:LLIMit <num> | 198 |
| [:SENSe]:ACPoweR:OFFSet<n>:STATe <bool> | 198 |
| [:SENSe]:ACPoweR:OFFSet<n>:ULIMit <num>..... | 199 |
| [:SENSe]:AMPLitude:ALIGNment:NOW | 199 |
| [:SENSe]:AMPLitude:ALIGNment[:STATe] <char> | 200 |
| [:SENSe]:AMPLitude:CORRections:ANTenna:DEFault..... | 200 |
| [:SENSe]:AMPLitude:CORRections:ANTenna[:STATe] <bool> | 201 |
| [:SENSe]:AMPLitude:CORRections:CABLE:DEFault..... | 202 |
| [:SENSe]:AMPLitude:CORRections:CABLE[:STATe] <bool> | 202 |
| [:SENSe]:AMPLitude:CORRections[:STATe] <bool> | 203 |
| [:SENSe]:AMPLitude:SCALE <char> | 203 |
| [:SENSe]:AMPLitude:UNIT <char> | 203 |
| [:SENSe]:AVERage:CLEar | 204 |
| [:SENSe]:AVERage:COUNt <num> | 205 |
| [:SENSe]:AVERage[:ENABLE] <value> | 205 |
| [:SENSe]:AVERage[:MODE] <char> | 206 |
| [:SENSe]:AVERage:MODE <char> | 206 |
| [:SENSe]:AVERage:SDETect <bool>..... | 207 |
| [:SENSe]:AVERage:TYPE <char> | 207 |
| [:SENSe]:BANDwidth:IF:OUT <char> | 207 |
| [:SENSe]:BANDwidth[:RESolution] <num>..... | 208 |

| | |
|--|-----|
| [[:SENSe]:BANDwidth[:RESolution]:AUTO <bool> | 208 |
| [[:SENSe]:BWIDth:VIDeo <char> | 209 |
| [[:SENSe]:BANDwidth:VIDeo <num> | 209 |
| [[:SENSe]:BANDwidth:VIDeo:AUTO <bool> | 210 |
| [[:SENSe]:BURSt:ALIGnment:NOW | 210 |
| [[:SENSe]:BURSt:ALIGnment[:STATe] <char> | 210 |
| [[:SENSe]:BWID <num> | 211 |
| [[:SENSe]:CMEasurement:AVERage:ENABLE <bool> | 211 |
| [[:SENSe]:CMEasurement:IBW <num> | 212 |
| [[:SENSe]:CMEasurement:RRCFilter <bool> | 212 |
| [[:SENSe]:CMEasurement:RRCFilter:ALPHa <num> | 213 |
| [[:SENSe]:CORRection:CALReady:TYPE <char> | 213 |
| [[:SENSe]:CORRection:COAX <char> | 214 |
| [[:SENSe]:CORRection:COEFFicient[:DATA] <char>,<resp1,<stim2>,<data> | 214 |
| [[:SENSe]:CORRection:COLLect[:ACQuire]:INT <num> | 215 |
| [[:SENSe]:CORRection:COLLect[:ACQuire]:LOAD <num> | 216 |
| [[:SENSe]:CORRection:COLLect[:ACQuire]:OPEN <num> | 216 |
| [[:SENSe]:CORRection:COLLect[:ACQuire]:SHORT <num> | 217 |
| [[:SENSe]:CORRection:COLLect[:ACQuire]:THRU <p1>,<p2> | 217 |
| [[:SENSe]:CORRection:COLLect:CKIT:LABel <port>,<ckit> | 218 |
| [[:SENSe]:CORRection:COLLect:CKIT:LABel:CATalog? | 219 |
| [[:SENSe]:CORRection:COLLect:CONNector <port>,<type -gen-,imp> | 220 |
| [[:SENSe]:CORRection:COLLect:ECAL:AORient <bool> | 221 |
| [[:SENSe]:CORRection:COLLect:ECAL:SIMPlE <bool> | 221 |
| [[:SENSe]:CORRection:COLLect:GUIDed:SCOunt? | 222 |
| [[:SENSe]:CORRection:COLLect:GUIDed:STEP:ACQuire <num> | 222 |
| [[:SENSe]:CORRection:COLLect:GUIDed:STEP:PROMpt? <num> | 223 |
| [[:SENSe]:CORRection:COLLect:METhod:ERES <p1>,<p2> | 223 |
| [[:SENSe]:CORRection:COLLect:METhod:ORESponse <p1> | 224 |
| [[:SENSe]:CORRection:COLLect:METhod:QCALibrate:CALibrate <p1>,<p2> | 224 |
| [[:SENSe]:CORRection:COLLect:METhod:QCALibrate:ERESponse <p1>,<p2> | 225 |
| [[:SENSe]:CORRection:COLLect:METhod:QSOLt <p1,p2> | 226 |
| [[:SENSe]:CORRection:COLLect:METhod[:RESPonse]:OPEN <p1> | 227 |
| [[:SENSe]:CORRection:COLLect:METhod[:RESPonse]:SHORT <p1> | 227 |
| [[:SENSe]:CORRection:COLLect:METhod[:RESPonse]:THRU <ports> | 228 |
| [[:SENSe]:CORRection:COLLect:METhod:SOLT1 <p1> | 229 |
| [[:SENSe]:CORRection:COLLect:METhod:SOLT2 <p1,p2> | 229 |
| [[:SENSe]:CORRection:COLLect:METhod:SRESponse <p1> | 230 |
| [[:SENSe]:CORRection:COLLect:METhod:TRL <p1,p2> | 230 |
| [[:SENSe]:CORRection:COLLect:METhod:TYPE? | 231 |

| | |
|--|-----|
| [[:SENSe]:CORRection:COLLect:METhod:SOLR <p1>,<p2> | 231 |
| [[:SENSe]:CORRection:COLLect:OISolation <bool> | 232 |
| [[:SENSe]:CORRection:COLLect:SAVE <num> | 233 |
| [[:SENSe]:CORRection:EXTension:PORT1 <num> | 233 |
| [[:SENSe]:CORRection:EXTension:PORT2 <num> | 234 |
| [[:SENSe]:CORRection:EXTension[:STATe] <bool> | 234 |
| [[:SENSe]:CORRection:GAIN2[:INPut][:MAGNitude] <num> | 235 |
| [[:SENSe]:CORRection:GAIN2:STATe <bool> | 235 |
| [[:SENSe]:CORRection:IMPedance[:INPut][:MAGNitude] <num> | 236 |
| [[:SENSe]:CORRection:LOSS:COAX <num> | 236 |
| [[:SENSe]:CORRection:LOSS:WAVeguide | 236 |
| [[:SENSe]:CORRection:MEDIum <char> | 236 |
| [[:SENSe]:CORRection:RVELocity:COAX <num> | 237 |
| [[:SENSe]:CORRection[:STATe] <bool> | 237 |
| [[:SENSe]:CORRection:USER:FREQuency:START:MINimum | 238 |
| [[:SENSe]:CORRection:USER:FREQuency:STOP:MAXimum | 238 |
| [[:SENSe]:CORRection:USER[:STATe] <bool> | 238 |
| [[:SENSe]:CORRection:USER:WGCutoff | 239 |
| [[:SENSe]:CORRection:WAVeguide:STANdard <char> | 239 |
| [[:SENSe]:CORRection:WGCutoff <num> | 239 |
| [[:SENSe]:CORRection:ZERO:REFerence <char> | 240 |
| [[:SENSe]:CORRection:ZERO:STATe <char> | 240 |
| [[:SENSe]:DETector:FUNCTion <char> | 240 |
| [[:SENSe]:FREQuency <num> | 241 |
| [[:SENSe]:FREQuency:CENTer <num> | 241 |
| [[:SENSe]:FREQuency:CENTer:STEP <num> | 242 |
| [[:SENSe]:FREQuency:CENTer:STEP:AUTO <bool> | 242 |
| [[:SENSe]:FREQuency:DATA? | 243 |
| [[:SENSe]:FREQuency:SPAN <num> | 243 |
| [[:SENSe]:FREQuency:SPAN:FULL | 244 |
| [[:SENSe]:FREQuency:SPAN:ZERO | 244 |
| [[:SENSe]:FREQuency:START <num> | 244 |
| [[:SENSe]:FREQuency:STEP <value> | 245 |
| [[:SENSe]:FREQuency:STOP <num> | 245 |
| [[:SENSe]:MEASurement:AOFF | 245 |
| [[:SENSe]:MEASurement:CHANnel <char> | 246 |
| SENSe:MEASurement:ERTA:PNID | 246 |
| [[:SENSe]:MEASurement:ERTA:PSTATUS | 247 |
| [[:SENSe]:MEASurement:ERTA:PVERIFY? | 247 |
| [[:SENSe]:MEASurement:ERTA:ROLE? | 247 |

| | |
|---|-----|
| [[:SENSE]:MEASUREMENT:INTERFERENCE <char> | 248 |
| [[:SENSE]:MEASUREMENT:PRESET | 248 |
| [[:SENSE]:MEAS:TALISTEN <char> | 249 |
| [[:SENSE]:OBW:PPOW <num> | 249 |
| [[:SENSE]:POINT:DWELL <value>..... | 249 |
| [[:SENSE]:POINT:READ:MAX <value>..... | 250 |
| [[:SENSE]:POWER[:RF]:ATTENUATION <num> | 250 |
| [[:SENSE]:POWER[:RF]:ATTENUATION:AUTO <bool> | 251 |
| [[:SENSE]:POWER[:RF]:EXTGAIN <num> | 251 |
| [[:SENSE]:POWER[:RF]:GAIN[:STATE] <bool> | 252 |
| [[:SENSE]:QUANTITY:TACTIVE? | 252 |
| [[:SENSE]:RADIO:CHANNEL:CENTER <num> | 252 |
| [[:SENSE]:RADIO:CHANNEL:DIIRECTION <char> | 253 |
| [[:SENSE]:RADIO:CHANNEL:START <num> | 254 |
| [[:SENSE]:RADIO:CHANNEL:STEP <num> | 254 |
| [[:SENSE]:RADIO:CHANNEL:STOP <num> | 254 |
| [[:SENSE]:RADIO[:SELECT]:STANDARD <char> - Obsolete | 255 |
| [[:SENSE]:RADIO:STANDARD[:SELECT] <string> | 256 |
| [[:SENSE]:RADIO:TEUNIT <char> | 257 |
| [[:SENSE]:RESOLUTION <char> | 257 |
| [[:SENSE]:ROSCILLATOR:SOURCE <char> | 258 |
| [[:SENSE]:ROSCILLATOR:STATUS? | 258 |
| [[:SENSE]:SPECTROGRAM:BPLEVEL <num> | 259 |
| [[:SENSE]:SPECTROGRAM:RPLEVEL <num> | 259 |
| [[:SENSE]:SPECTROGRAM:TMARKER:STATE <char> | 259 |
| [[:SENSE]:SPECTROGRAM:TMARKER:VALUE <num> | 260 |
| [[:SENSE]:SPECTROGRAM:VIEW <char> | 261 |
| [[:SENSE]:SPECTROGRAM:WANGLE <char> | 261 |
| [[:SENSE]:SWEPT:ACQUISITION <num> | 262 |
| [[:SENSE]:SWEPT:ACQUISITION:AUTO <bool> | 262 |
| [[:SENSE]:SWEPT:MTIME? | 263 |
| [[:SENSE]:SWEPT:POINTS <num> | 263 |
| [[:SENSE]:SWEPT:RX <value> | 263 |
| [[:SENSE]:SWEPT:TIME <num> | 264 |
| [[:SENSE]:SWEPT:TYPE <char> | 264 |
| [[:SENSE]:SWEPT:TYPE <value> | 265 |
| [[:SENSE]:TALISTEN:AVOLUME <num> - Obsolete | 266 |
| [[:SENSE]:TALISTEN:DSTATE <bool> | 266 |
| [[:SENSE]:TALISTEN:DTYPE <char> | 266 |
| [[:SENSE]:TALISTEN:LTIME <num> | 267 |

| | |
|---|-----|
| [:SENSe]:TAListen:TFReq <num> | 267 |
| [:SENSe]:TOL <value> | 268 |
| [:SENSe]:TRACe[:DATA]? | 268 |
| [:SENSe]:TRACe:LIMit:LOWer <num> | 269 |
| [:SENSe]:TRACe:LIMit:LOWer:STATe <bool> | 269 |
| [:SENSe]:TRACe:LIMit:UPPer <num> | 270 |
| [:SENSe]:TRACe:LIMit:UPPer:STATe <bool> | 270 |
| [:SENSe]:TRACe:MEASurement:REFerence <num>..... | 271 |
| [:SENSe]:TRACe:MEASurement <value>..... | 271 |
| SOURce:ENABle <bool> | 271 |
| SOURce:ENABle <bool> | 272 |
| SOURce:FREQuency:CENTer <value>..... | 273 |
| SOURce:FREQuency[:CW] <num> | 273 |
| SOURce:FREQuency:SPAN <value>..... | 274 |
| SOURce:FREQuency:START <value> | 274 |
| SOURce:FREQuency:STOP <value> | 275 |
| SOURce:MODE <char> | 275 |
| SOURce:NORMalize <bool> | 276 |
| SOURce:POWer <num> | 276 |
| SOURce:POWer <num>..... | 277 |
| SOURce:POWer:ALC[:MODE] <char>..... | 278 |
| SOURce:POWer:ATTenuation <num> | 279 |
| SOURce:POWer:MAXimum <bool> | 279 |
| SOURce:POWer:MEMorize..... | 280 |
| SOURce:POWer <num> | 280 |
| SOURce:POWer <num>..... | 281 |
| SOURce:RECeiver:OFFSet <value> | 282 |
| :STATus:OPERation:SAMode:CONDition?..... | 282 |
| :STATus:QUEStionable:FREQuency:CONDition? | 282 |
| :STATus:QUEStionable:INTegrity:CONDition? | 283 |
| :STATus:QUEStionable:LIMit:CONDition? | 283 |
| SYSTem:AUDio:MUTE <bool>..... | 284 |
| SYSTem:AUDio:VOLume <num> | 284 |
| SYSTem:BATTery?..... | 285 |
| SYSTem:BATTery:ABSCharge?..... | 285 |
| SYSTem:BATTery:ACURrent? | 285 |
| SYSTem:BATTery:ARTTe?..... | 285 |
| SYSTem:BATTery:CHEMistry? | 286 |
| SYSTem:BATTery:CURRent? | 286 |
| SYSTem:BATTery:CYCLes? | 286 |

| | |
|--|-----|
| SYSTem:BATTEry:DATE?..... | 286 |
| SYSTem:BATTEry:FCAPacity?..... | 287 |
| SYSTem:BATTEry:MAXError?..... | 287 |
| SYSTem:BATTEry:MFGName?..... | 287 |
| SYSTem:BATTEry:RCAPacity?..... | 287 |
| SYSTem:BATTEry:RELCharge?..... | 288 |
| SYSTem:BATTEry:RTTE?..... | 288 |
| SYSTem:BATTEry:SAVer <bool>..... | 288 |
| SYSTem:BATTEry:SN?..... | 288 |
| SYSTem:BATTEry:STATus?..... | 289 |
| SYSTem:BATTEry:TEMPerature?..... | 289 |
| SYSTem:BATTEry:VENdor?..... | 289 |
| SYSTem:BATTEry:VOLTagE?..... | 289 |
| SYSTem:DATE <year,mo,dy>..... | 290 |
| SYSTem:DCSupply?..... | 290 |
| SYSTem:ERASe <value>..... | 290 |
| SYSTem:ERRor[:NEXT]?..... | 291 |
| SYSTem:GPS:CNOise?..... | 291 |
| SYSTem:GPS:DATA?..... | 292 |
| SYSTem:GPS:DATA:LAST?..... | 292 |
| SYSTem:GPS:DISPlay:COORdinate:FORMat <char>..... | 292 |
| SYSTem:GPS:DISPlay:DISTance:UNIT <char>..... | 293 |
| SYSTem:GPS:DISPlay:STATe <bool>..... | 293 |
| SYSTem:GPS:LState?..... | 294 |
| SYSTem:GPS[:STATe] <char>..... | 294 |
| SYSTem:GPS:SYNChronize <bool>..... | 295 |
| SYSTem:PREFerences:DFLT..... | 295 |
| SYSTem:PREFerences:SAVE..... | 295 |
| :SYSTem:PRESet..... | 296 |
| :SYSTem:PRESet:MODE..... | 296 |
| SYSTem:PWR:AUTO <value>..... | 296 |
| SYSTem:PWR:SHUTdown <value>..... | 297 |
| SYSTem:PWR:SHUTdown:DLY <value>..... | 297 |
| SYSTem:PWR:SHUTdown:DURation <value>..... | 298 |
| SYSTem:PWR:SUSP <bool>..... | 298 |
| SYSTem:PWR:SUSP:DLY <value>..... | 298 |
| SYSTem:PWR:SUSP:DURation <value>..... | 299 |
| SYSTem:UPReset:FPANel[:STATe] <bool>..... | 299 |
| SYSTem:UPReset:MODE..... | 299 |
| SYSTem:UPReset:SAVE..... | 300 |

| | |
|--|-----|
| SYSTem:UPReset..... | 300 |
| SYSTem:TIME <hr,min,sec> | 300 |
| SYSTem:TZONe <string> | 300 |
| SYSTem:TZONe:CATalog? | 301 |
| SYSTem:VERSion? | 301 |
| SYSTem:VVS:CURRent? | 302 |
| SYSTem:VVS:ENABle <bool>..... | 302 |
| SYSTem:VVS:MAXCurrent? | 303 |
| SYSTem:VVS:MVOLTage? | 303 |
| SYSTem:VVS[:STATe]? | 303 |
| SYSTem:VVS:VOLTage <num> | 304 |
| TRACe<n>:DATA? <char> | 304 |
| :TRACe<n>:TYPE <char> | 305 |
| TRIGger:DELay <num> | 306 |
| TRIGger:LEVel:AUTO <bool> | 306 |
| TRIGger:LEVel <num> | 306 |
| :TRIGger[:SEQuence]:ATRigger <num> | 307 |
| :TRIGger[:SEQuence]:ATRigger:STATe <bool>..... | 307 |
| :TRIGger[:SEQuence]:DELay <num> | 308 |
| :TRIGger[:SEQuence]:DELay:STATe <bool> | 308 |
| TRIGger[:SEQuence]:FGATe:DELay <num>..... | 309 |
| TRIGger[:SEQuence]:FGATe[:STATe]..... | 309 |
| TRIGger[:SEQuence]:FGATe:VIEW[:STATe] <bool> | 310 |
| TRIGger[:SEQuence]:FGATe:VIEW:TIME <num> | 310 |
| TRIGger[:SEQuence]:FGATe:WIDTh <num> | 311 |
| TRIGger[:SEQuence]:POSition <num> | 311 |
| :TRIGger[:SEQuence]:POSition:STATe <bool> | 312 |
| :TRIGger[:SEQuence]:SLOPe <char> | 312 |
| :TRIGger[:SEQuence]:SOURce <char> | 313 |
| :TRIGger[:SEQuence]:VIDeo:LEVel <num> | 314 |
| TRIGger:SLOPe <char> | 314 |
| TRIGger:SOURce <char> | 315 |
| TRIGger:SOURce <char> | 315 |
| UNIT:POWer <string> | 316 |

- [Commands Common to All Modes](#)

- **List of Commands by Mode**

- [CAT Mode](#)
- [NA Mode](#)
- [SA Mode](#)
- [VVM Mode](#)
- [USB Power Meter Mode](#)
 - [FOPS](#)
- [Pulse Measurements](#)
- [CPM Mode](#)
- [ERTA Mode](#)
- [AM/FM Metrics](#)
- [Channel Scanner Mode](#)

**See Also**

- [Example Programs](#)
- [SCPI Concepts and Tips](#)
- [New Commands](#) with this release.
- [Instrument Console](#)
- [FieldFox User's Guides](#)
- Command Reference - See **Table of Contents**

Supports Firmware Revision: A.08.15 and A.09.15

Date: 2016-05-04

SCPI Concepts and Tips

- [FieldFox Programming Tips](#)
- [Correction Methods Explained](#)
- [Instrument Console](#)
- [The Rules and Syntax of SCPI Commands](#)

See Also

[Examples](#)

Last Modified:

29-Jan-2012

New topic

FieldFox Programming Tips

Mode-specific Programming

Although the FieldFox is a single instrument, each FieldFox mode (NA, SA, and so forth) has its own unique set of SCPI commands. Each mode is targeted separately by first issuing the command to select the mode ([INSTrument\[:SElect\]](#)).

Here is a list of commands that are common to ALL modes: [Commands Common to All Modes](#).

Perform Single Triggering

When programming the FieldFox, it is ALWAYS recommended to perform single sweep triggering: [INITiate:CONTinuous,0](#) and [INITiate\[:IMMEDIATE\]](#) followed with [*OPC?](#).

This is because after making measurement settings such as setting frequency, there is NO guarantee that a continuous sweep will complete and data will be collected at the new setting. By following a series of settings with [INIT:IMM;*OPC?](#), then all settings will be updated correctly.

Communicating with the FieldFox using sockets over LAN

Responses to SCPI commands will always be in ASCII string format unless otherwise noted. Long responses may be separated into packets of data (up to 1460 bytes long). Each response is terminated with a LF character. When receiving long responses, search for the LF character to determine that the response is complete.

Do NOT do Binary Block transfers ([FORM:DATA REAL,32](#) or [REAL,64](#)) when using over Telnet to port 5024 on FieldFox.

About Calibration Settings

A calibration session that is performed using the front-panel is completely separate from a calibration session that is performed programmatically.

Therefore, calibration settings that are made remotely (such as setting the cal kit and connectors) can NOT be observed from the front-panel user interface. Alternatively, calibration settings that are made from the FieldFox front panel (user interface) can NOT be queried programmatically.

Correction Methods Explained

The Correction (Calibration) Methods offered for the FieldFox allow you to balance higher accuracy or a faster sweep time. Several methods are available through SCPI that are NOT available using the front-panel user interface. For example, all of the Cal Methods normally available only in NA mode are also available programmatically in CAT modes.

- [Definitions](#)
- [Cal Methods](#)
 - [1-Port \(OSL\)](#)
 - [FULL 2-Port](#)
 - [SOLR](#)
 - [QSOLT](#)
 - [Enhanced Response Cal](#)
 - [Response Cals](#)
- [FieldFox Model Summary](#)

See Also

[Calibration Examples](#)

[CAT Mode Commands](#)

[NA Mode Commands](#)

About Calibration Settings

A calibration session that is performed using the front-panel is completely separate from a calibration session that is performed programmatically.

Therefore, calibration settings that are made remotely (such as setting the cal kit and connectors) can NOT be observed from the front-panel user interface. Alternatively, calibration settings that are made from the FieldFox front panel (user interface) can NOT be queried programmatically.

Definitions

Non-insertable DUT – A device whose connectors could NOT mate together. They either do not have the same type of connector or they have the same gender. This also means that the test port cables could NOT mate together as in the above diagram.

Insertable DUT – A device whose connectors could mate together. They have the same type of connector and opposite or no gender. This also means that the test port cables could mate together, as in the above diagram.

Flush THRU - When the test port cables mate together when measuring an Insertable DUT. The THRU standard has no loss and no electrical length.

Sweep Directions – Relevant to N9923A ONLY.

- Sweep in FORWARD direction means port 1 is the source port and port 2 is the receiver port. Used to measure S11 and S21. (N9912A sweeps in forward direction ONLY)
- Sweep in REVERSE direction means port 2 is the source port and port 1 is the receiver port. Used to measure S22 and S12.

Full 2-Port and **QSOLT** Cals result in correction that requires background measurement sweeps in both directions, regardless of the displayed measurements. The displayed traces are updated at a slower rate than **Enhanced Response** and **1-port** cals, which require sweeps in one direction only.

Cal Methods

1-Port (OSL)

- Insertability - Not Relevant
- S-parameters Corrected: S11 or S22 (N9923)
- Standards: OPEN, SHORT, LOAD
- Sweeps in ONE direction.

FULL 2-Port (N9923A with Opt 122)

- Mechanical or QuickCal (Opt 111 or 112)
- Corrects all S-parameters.
- Non-Insertable or Insertable DUT
- Standards: OPEN, SHORT, LOAD on BOTH ports. Known (characterized) THRU between ports.
- Sweeps in BOTH directions.

Note: Because FULL 2-Port method requires a known THRU connection between the test ports, it is better to use **SOLR**, which yields the same level of accuracy with ANY (unknown) THRU connection. SOLR is performed when calibrating both ports from the front-panel user interface.

SOLR (Short-Open-Load-Reciprocal Thru) (All models with Full 2-port option)

Also known as Unknown Thru calibration.

- Mechanical Cal ONLY
- Most comprehensive calibration. Corrects all S-parameters.
- Non-Insertable or Insertable DUT
- Standards: OPEN, SHORT, LOAD on BOTH ports. Any THRU between ports.
- Sweeps in BOTH directions.

QSOLT (All models with Full 2-port option)

- Mechanical Cal ONLY
- Quicker to perform than Full 2-port. Corrects all S-parameters.
- Insertable DUT only
- Standards: OPEN, SHORT, LOAD on ONE port. Flush THRU between ports.
- Sweeps in BOTH directions.

Enhanced Response Cal

- Forward (all models) **OR** Reverse (All models with Full 2-port option)
- Mechanical or QuickCal (Opt 111 or 112)
- Faster measurements than Full 2-Port because sweeps in one direction ONLY.
- Insertable DUT only

- S-parameters Corrected: S21 and S11 (Forward) OR S12 and S22 (Reverse)
- Standards: OPEN, SHORT, LOAD on ONE port. Flush THRU between ports.

Response Cals

- Least accurate Cal type - correct Magnitude ONLY.
- Mechanical Cal ONLY
- Perform same as Data/Memory or THRU Normalization
- Standards: OPEN or SHORT (1-port) or THRU (2-port)

Summary

N9912A - CAT and NA

| Cal Methods click to learn more | Command click to see command | Ports <p> | Req'd Options |
|--|------------------------------------|-----------|---------------|
| QuickCals | | | |
| 1-port OSL | QCAL:CAL <p> | 1 | 111 |
| Enhanced Response | QCAL:ERES <p> | 1,2 | 111, 110 |
| Mechanical Cals - specify connector and cal kit | | | |
| 1-port OSL | SOLT1 <p> | 1 | None |
| Enhanced Response | ERES <p> | 1,2 | 110 |
| Response Cals | | | |
| Open Response | OPEN <p> | 1 | None |
| Short Response | SHORT <p> | 1 | None |
| Thru Response | THRU <p> | 1,2 | 110 |

N9912A Options

- CAT Mode - Standard
- Option 110 - Adds 2-port (Fwd) measurements
- Option 111 - Adds QuickCal
- Option 303 - Adds NA Mode

All models with Full 2-port option - CAT and NA

| Cal Methods click to learn more | Command click to see command | Ports <p> | Req'd Options |
|------------------------------------|------------------------------------|-----------|---------------|
| QuickCals | | | |

| | | | |
|--|---------------|--------------|---------|
| 1-port OSL or Full 2-port | QCAL:CAL <p> | 1 (1-port) | 112 |
| | | 2 (1-port) | 122,112 |
| | | 1,2 (2-port) | 122,112 |
| Enhanced Response | QCAL:ERES <p> | 1,2 (Fwd) | 112 |
| | | 2,1 (Rev) | 122,112 |
| Mechanical Cals - specify connector and cal kit | | | |
| 1-port OSL | SOLT1 <p> | 1 | None |
| | | 2 | 122 |
| Full 2-port | SOLT2 <p> | 1,2 | 122 |
| Unknown Thru | SOLR <p> | 1,2 | 122 |
| QSOLT | QSOLT <p> | 1,2 or 2,1 | 122 |
| Enhanced Response | ERES <p> | 1,2 | None |
| | | 2,1 | 122 |
| Response Cals | | | |
| Open Response | OPEN <p> | 1 | None |
| | | 2 | 122 |
| Short Response | SHORT <p> | 1 | None |
| | | 2 | 122 |
| Thru Response | THRU <p> | 1,2 | None |

N9923A Options

- NA Mode - Standard
- Option 112 - Adds QuickCal
- Option 122 - Adds Full 2-port (Fwd and Rev) Measurements
- Option 305 - Adds CAT Mode

Options for All other N992x models

- Option 112 - Adds QuickCal
- Option 211 - Adds Full 2-port (Fwd and Rev) Measurements
- Option 305 - Adds CAT Mode

How the FieldFox Error Queue Works

Errors work as follows:

1. Errors are logged to the central logger, visible with the FieldFox GUI. Press **System 7** then **Service Diagnostics**, then **Error Log**.
2. Errors originating from a specific client (connected program) are logged to the queue for that client. Each client has its own queue. So if you have two socket connections (not recommended), and the first one sends a bad command, the second one does NOT get a 'Header not found' error logged in its queue. Only the first one will see that error on **SYST:ERR?**
3. 'Global' errors (those that occur independent of a connected client), are logged to the central logger (per #1) and to all currently connected SCPI client error queues.
4. SCPI socket (port 5025) and Telnet (port 5024) clients are independent and dynamic. If there is no current connection (or connections), then no error queue for that connection (or connections) exist(s), and no 'Global' errors are logged there because there is no place to log them.

However, the VXI parser always exists in FieldFox firmware even if no clients are connected to it. This is the connection typically used by Keysight I/O Libraries (unless 'socket' connection is checked). So it will always queue 'Global' errors that occur, and a client that connects via the VXI interface after the errors occur may still query out those errors.

You can bind a C# program to the C# VISA wrapper provided with Keysight I/O Libraries in order to use the VXI interface to FieldFox, if you plan to connect after the errors occur to query them out of the FieldFox.

In cases where a persistent error is occurring (like ADC Overload), currently, the error queue for the VXI parser (which receives these errors, as mentioned above) is unbounded, and will accumulate errors until instrument memory is exhausted. This occurs unless a VXI client connects and clears the VXI parser's error queue (using SYST:ERR?).

Instrument Console (IC)

IC is a free utility that can be used to run simple example programs to control the FieldFox.

This utility is NOT supported. Use 'As-is'.

Download Instrument Console at http://na.tm.agilent.com/fieldfox/download_files/ic.zip

Unzip, then double-click on IC.exe to install.

Note: IC requires .NET (version 2.0 or later). If IC does NOT run, then download .NET at: <http://www.microsoft.com/net/download.aspx>

Hint

IC can be used with Agilent IO libraries or by directly connecting to an IP address.

If an error is continuously returned, try increasing the timeout. (-t <time in seconds>).

Then reconnect by issuing -a <address>

IC Command Summary:

| | |
|--------------|--|
| [? help] | shows this help screen |
| -a <address> | sets a new address, e.g. 192.168.1.1 <address> can be an IP address, a VISA address or alias, LAN hostname, or InstrumentConsole alias. |
| -d | detach from currently connected instrument. |
| -clear | Clear IO stream. Experimental. |
| -r | re-attach to currently connected instrument. |

| | |
|---|--|
| -t<?> | returns current timeout |
| -t< time in secs> | sets a new timeout, e.g. "-t .010" for 10ms |
| -w <time in msecs> | wait (pause) execution for the specified amount of time |
| -err[- ?] | set/remove/query automatic SYST:ERR? after sending a command/query string |
| -visa? | List VISA instruments and aliases. |
| -alias x=[y] | Adds an alias 'x' for instrument name 'y' If y is omitted, alias x is cleared. |
| -alias? | Returns existing aliases. |
| -sp <script path> | Sets ';' delimited path to locate scripts. |
| -sp? | Returns the script path. |
| -p [Message] | Pauses execution, prints optional Message, user must press return to continue. |
| -v -verify <\$n<== !=>value > | verify value in \$n, where n=0 is most recent result (0<n<=9) e.g. "-v \$0==1" will pass after a *OPC? IC will exit with -1 if verify test fails. |
| ! <string>< td=""> <td>performs ShellExecute on <string></td> </string><> | performs ShellExecute on <string> |
| \$(filename> | opens filename and executes all lines of text Lines beginning with # in the 1st column are treated as comments |
| <string> | sends command to the instrument |
| <string>?[args] | sends a command, then reads back data |
| [exit quit] | quits the program |

Alpha support has been added for I/O redirection so that data can be read to/from files as part of sending command strings.

E.g.: SENS:FREQ:STAR < freq.txt where freq.txt contains a string such as "3e9"

or

SENS:FREQ:STAR? > freq.txt to dump the start frequency to freq.txt

This program also allows binaries to be properly redirected to a file, e.g. to save and get a screenshot PNG file, you can now do this (and it works without corrupting the PNG file):

MMEM:STOR:IMAG "my.png" this saves a png file on the FieldFox.

MMEM:DATA? "my.png" > my.png this transfers the file to the PC.

The Rules and Syntax of SCPI

Most of the commands used for controlling instruments on the GPIB are SCPI commands. The following sections will help you learn to use SCPI commands in your programs.

- [Branches on the Command Tree](#)
- [Command and Query](#)
- [Multiple Commands](#)
- [Command Abbreviation](#)
- [Bracketed \(Optional\) Keywords](#)
- [Vertical Bars \(Pipes\)](#)
- [MIN and MAX Parameters](#)

Branches on the Command Tree

All major functions on the analyzer are assigned keywords which are called ROOT commands. Under these root commands are branches that contain one or more keywords. The branching continues until each analyzer function is assigned to a branch. A root command and the branches below it is sometimes known as a subsystem.

For example, under **CALCulate** are several branch commands.

Sometimes the same keyword, such as **STATE**, is used in several branches of the command tree. To keep track of the current branch, the analyzer's command parser uses the following rules:

- **Power On and Reset** - After power is cycled or after *RST, the current path is set to the root level commands.
- **Message Terminators** - A message terminator, such as a <NL> character, sets the current path to the root command level. Many programming language output statements send message terminators automatically.
- **Colon (:)** - When a colon is between two command keywords, it moves the current path down one level in the command tree. For example, the second colon in :SOURCE:POWER specifies that POWER is one level below SOURCE. When the colon is the first character of a command, it specifies that the following keyword is a root level command. For example, the first colon in :SOURCE:POWER specifies that source is a root level command.

Note: You can omit the leading colon if the command is the first of a new program line. For example, the following two commands are equivalent:

```
SOUR:POW:ATT:AUTO
:SOUR:POW:ATT:AUTO
```

- **<WSP>** - Whitespace characters, such as <tab> and <space>, are generally ignored. There are two important exceptions:
 - Whitespace inside a keyword, such as :CALC ULATE, is not allowed.
 - Most commands end with a parameter. You must use whitespace to separate these ending parameters from commands. **Always refer to the command documentation.** In the following example, there is whitespace between STATE and ON.

CALCULATE:LIMit:STATE ON

- **Comma (,)** - If a command requires more than one parameter, you must separate adjacent parameters using a comma. For example, the **SYSTEM:TIME** command requires three values to set the analyzer clock: one for hours, one for minutes, and one for seconds. A message to set the clock to 8:45 AM would be SYSTEM:TIME 8,45,0. Commas do not affect the current path.

- **Semicolon(;) -** A semicolon separates two commands in the same message without changing the current path. See [Multiple Commands](#) later in this topic.
- **IEEE 488.2 Common Commands -** Common commands, such as *RST, are not part of any subsystem. An instrument interprets them in the same way, regardless of the current path setting.

Command and Query

A SCPI command can be an Event command, Query command (a command that asks the analyzer for information), or both. The following are descriptions and examples of each form of command. GPIB Command Finder lists every SCPI command that is recognized by the analyzer, and its form.

| Form | Examples |
|---|---|
| Event commands - cause an action to occur inside the analyzer. | :INITIATE:IMMEDIATE |
| Query commands - query only; there is no associated analyzer state to set. | :SYSTEM:ERROR? |
| Command and query - set or query an analyzer setting. The query form appends a question mark (?) to the set form | :FORMat:DATA ! Command :FORMat:DATA? ! Query |

Multiple Commands

You can send multiple commands within a single program message. By separating the commands with semicolons the current path does not change. The following examples show three methods to send two commands:

1. **Two program messages:**

```
:SENSE:FREQUENCY:START 1e9;
:SENSE:FREQUENCY:STOP 2e9
```
2. **One long message.** A colon follows the semicolon that separates the two commands causing the command parser to reset to the root of the command tree. As a result, the next command is only valid if it includes the entire keyword path from the root of the tree:

```
:SENSE:FREQUENCY:START 1e9;:SENSE:FREQUENCY:STOP 2e9
```
3. **One short message.** The command parser keeps track of the position in the command tree. Therefore, you can simplify your program messages by including only the keyword at the same level in the command tree.

```
SENSE:FREQUENCY:START 1e9;STOP 2e9
```

Common Commands and SCPI Commands

You can send Common commands and SCPI commands together in the same message. (For more information on these types of commands see GP-IB Fundamentals.) As in sending multiple SCPI commands, you must separate them with a semicolon.

Example of Common command and SCPI commands together

```
*RST;SENSE:FREQUENCY:CENTER 5MHZ;SPAN 100KHZ
```

Command Abbreviation

Each command has a long form and an abbreviated short form. The syntax used in this Help system use uppercase characters to identify the short form of a particular keyword. The remainder of the keyword is lower case to complete the long form.

SENS - Short form

SENSE - Long form

Either the complete short form or complete long form must be used for each keyword. However, the keywords used to make a complete SCPI command can be a combination of short form and long form.

The following is **unacceptable** - The first three keywords use neither short or long form.

SOURc:Powe:Atten:Auto on

The following is **acceptable** - All keywords are either short form or long form.

SOUR:POWer:ATT:AUTO on

In addition, the analyzer accepts lowercase and uppercase characters as equivalent as shown in the following equivalent commands:

source:POW:att:auto ON

Source:Pow:Att:Auto on

Optional [Bracketed] Keywords

You can omit some keywords without changing the effect of the command. These optional, or default, keywords are used in many subsystems and are identified by brackets in syntax diagrams.

Example of Optional Keywords

The **SENSE** keyword is always optional. Therefore, both of the following commands are equivalent:

:SENS:BWID 1e3

:BWID 1e3

The syntax in this Help system looks like this:

[:SENSE] :BWID

Vertical Bars | Pipes

Vertical bars, or "pipes", can be read as "**or**". They are sometimes used in syntax diagrams to separate alternative parameter options.

Example of Vertical Bars:

SOURce:POWer:ATTenuation:AUTO <on|off>

Either **ON** or **OFF** is a valid parameter option.

MIN and MAX Parameters

The special form parameters "MINimum" and "MAXimum" can be used with **commands that specify single frequency (Hz) and time (seconds)** as noted in the command documentation. **Note: Also with these commands, kHz, MHz, and GHz are accepted as suffixes/units.**

The short form (min) and long form (minimum) of these two keywords are equivalent.

- **MAX**imum refers to the largest value that the function can currently be set to
- **MIN**imum refers to the smallest value that the function can currently be set to.

For example, the following command sets the start frequency to the smallest value that is currently possible:

SENS:FREQ:START MIN

In addition, the max and min values can also be queried for these commands.

For example, the following command returns the smallest value that Start Frequency can currently be set to:

```
SENS:FREQ:START? MIN
```

An error will be returned if a numeric parameter is sent that exceeds the MAX and MIN values.

For example, the following command will return an "Out of range" error message.

```
SENS:FREQ:START 1khz
```

Last Modified:

29-Jan-2012 New topic

SCPI Errors

SCPI Errors

- [-100 to -200 Command Errors](#)
- [-200 to -299 Execution Errors](#)
- [-300 to -399 SCPI Specified Device-Specific Errors](#)
- [-400 to -800 Query and System Errors](#)
- [100 to 200 FieldFox-specific Errors](#)

See Also

[How to Query the Error Queue](#)

-100 to -200 Command Errors

A command error indicates that the test set's GPIB parser has detected an IEEE 488.2 syntax error. When one of these errors is generated, the command error bit in the event status register is set.

| | | |
|------|-----------------------|--|
| -100 | std_command | Command - This event bit (Bit 5) indicates a syntax error, or a semantic error, or a GET command was entered, see IEEE 488.2, 11.5.1.1.4. |
| -101 | std_invalidChar | Invalid character - Indicates a syntactic elements contains a character which is invalid for that type. |
| -102 | std_syntax | Syntax - Indicates that an unrecognized command or data type was encountered. For example, a string was received when the device does not accept strings. |
| -103 | std_invalidSeparator | Invalid separator - The parser was expecting a separator and encountered an illegal character. For example, the semicolon was omitted after a program message unit. |
| -104 | std_wrongParamType | Data type -The parser recognized a data element different than one allowed. For example, numeric or string data was expected but block data was encountered. |
| -105 | std_GETNotAllowed | GET not allowed - Indicates a Group Execute Trigger was received within a program message. Correct the program so that the GET does not occur within the program code. |
| -108 | std_tooManyParameters | Parameter not allowed - Indicates that more parameters were received |

than expected for the header. For example, *ESE common command only accepts one parameter, so *ESE 0,1 is not allowed.

| | | |
|------|-------------------------|---|
| -109 | std_tooFewParameters | Missing parameter - Indicates that less parameters were received than required for the header. For example, *ESE requires one parameter, *ESE is not allowed. |
| -110 | std_cmdHeader | Command header - Indicates an error was detected in the header. This error is used when the device cannot detect the more specific errors -111 through -119. |
| -111 | std_headerSeparator | Header separator - Indicates that a character that is not a legal header separator was encountered while parsing the header. |
| -112 | std_IDTooLong | Program mnemonic too long - Indicates that the header contains more than twelve characters, see IEEE 488.2, 7.6.1.4.1. |
| -113 | std_undefinedHeader | Undefined header - Indicates the header is syntactically correct, but it is undefined for this specific device. For example, *XYZ is not defined for any device. |
| -114 | std_suffixOutOfRange | Header suffix out of range - Indicates the value of a header suffix attached to a program mnemonic makes the header invalid. |
| -120 | std_numericData | Numeric data - This error, as well as errors |
| -121 | std_invalidCharInNumber | Invalid character in number - Indicates an invalid character for the data type being parsed was encountered. For example, an alpha in a decimal numeric or a "9" in octal data. |
| -123 | std_exponentTooLarge | Exponent too large - Indicates the magnitude of an exponent was greater than 32000, see IEEE 488.2, 7.7.2.4.1. |
| -124 | std_decimalTooLong | Too many digits - Indicates the mantissa of a decimal numeric data element contained more than 255 digits excluding leading zeros, see IEEE 488.2, 7.7.2.4.1. |
| -128 | std_numericNotAllowed | Numeric data not allowed - Indicates that a legal numeric data element was received, but the device does not accept one in this position for the header. |
| -130 | std_suffix | Suffix - This error, as well as errors -131 through -139, are generated when parsing a suffix. This particular error message is used if the device cannot detect a more specific error. |
| -131 | std_badSuffix | Invalid suffix - Indicates the suffix does not follow the syntax described in IEEE 488.2, 7.7.3.2, or the suffix is inappropriate for this device. |
| -134 | std_suffixTooLong | Suffix too long - Indicates the suffix contain more than 12 characters, see IEEE 488.2, 7.7.3.4. |
| -138 | std_suffixNotAllowed | Suffix not allowed - Indicates that a suffix was encountered after a numeric element that does not allow suffixes. |
| -140 | std_charData | Character data - This error, as well as errors |
| -141 | std_invalidCharData | Invalid character data - Indicates that the character data element contains an invalid character or the particular element received is not valid for the header. |
| -144 | std_charDataTooLong | Character data too long - Indicates the character data element contains |

| | |
|-------------------------------|---|
| | more than twelve characters, see IEEE 488.2, 7.7.1.4. |
| -148 std_charNotAllowed | Character data not allowed - Indicates a legal character data element was encountered where prohibited by the device. |
| -150 std_stringData | String data - This error, as well as errors |
| -151 std_stringInvalid | Invalid string data - Indicates that a string data element was expected, but was invalid, see IEEE 488.2, 7.7.5.2. For example, an END message was received before the terminal quote character. |
| -158 std_stringNotAllowed | String data not allowed - Indicates that a string data element was encountered but was not allowed by the device at this point in parsing. |
| -160 std_blockData | Block data - This error, as well as errors -161 through -169, are generated when parsing a block data element. This particular error message is used if the device cannot detect a more specific error. |
| -161 std_badBlock | Invalid block data - Indicates a block data element was expected, but was invalid, see IEEE 488.2, 7.7.6.2. For example, an END message was received before the end length was satisfied. |
| -168 std_blockNotAllowed | Block data not allowed - Indicates a legal block data element was encountered, but not allowed by the device at this point in parsing. |
| -170 std_expr | Expression - This error, as well as errors -171 through -179, are generated when parsing an expression data element. This particular error message is used if the device cannot detect a more specific error. |
| -171 std_invalidExpression | Invalid expression - Indicates the expression data element was invalid, see IEEE 488.2, 7.7.7.2. For example, unmatched parentheses or an illegal character. |
| -178 std_exprNotAllowed | Expression data not allowed - Indicates a legal expression data was encountered, but was not allowed by the device at this point in parsing. |
| -180 std_macro | Macro - This error, as well as error -181 through -189, are generated when defining a macro or execution a macro. This particular error message is used if the device cannot detect a more specific error. |
| -181 std_validOnlyInsideMacro | Invalid outside macro definition - Indicates that a macro parameter place holder was encountered outside of a macro definition. |
| -183 std_invalidWithinMacro | Invalid inside macro definition - Indicates that the program message unit sequence, sent with a *DDT or a *DMC command, is syntactically invalid, see IEEE 488.2, 10.7.6.3. |
| -184 std_macroParm | Macro parameter - Indicates that a command inside the macro definition had the wrong number or type of parameters. |

-200 to -299 Execution Errors

These errors are generated when something occurs that is incorrect in the current state of the instrument. These errors may be generated by a user action from either the remote or the manual user interface

| | |
|------------------------------|--|
| -200 std_execGen | Execution - This event bit (Bit 4) indicates a PROGRAM DATA element following a header was outside the legal input range or otherwise inconsistent with the device's capabilities, see IEEE 488.2, 11.5.1.1.5. |
| -201 std_invalidWhileInLocal | Invalid while in local |

| | | |
|------|------------------------|---|
| -202 | std_settingsLost | Settings lost due to rtl |
| -203 | std_commandProtected | Command protected - Indicates that a legal password-protected program command or query could not be executed because the command was disabled. |
| -210 | std_trigger | Trigger |
| -211 | std_triggerIgnored | Trigger ignored |
| -212 | std_armIgnored | Arm ignored |
| -213 | std_initIgnored | Init ignored |
| -214 | std_triggerDeadlock | Trigger deadlock |
| -215 | std_armDeadlock | Arm deadlock |
| -220 | std_parm | Parameter - Indicates that a program data element related error occurred. |
| -221 | std_settingsConflict | Settings conflict - Indicates that a legal program data element was parsed but could not be executed due to the current device state. |
| -222 | std_dataOutOfRange | Data out of range - Indicates that a legal program data element was parsed but could not be executed because the interpreted value was outside the legal range defined by the devices |
| -223 | std_tooMuchData | Too much data - Indicates that a legal program data element of block, expression, or string type was received that contained more data than the device could handle due to memory or related device-specific requirements. |
| -224 | std_illegalParmValue | Illegal parameter value - Indicates that the value selected was not part of the list of values given. |
| -225 | std_noMemoryForOp | Out of memory - The device has insufficient memory to perform the requested operation. |
| -226 | std_listLength | Lists not same length - Attempted to use LIST structure having individual LIST's of unequal lengths. |
| -230 | std_dataCorruptOrStale | Data corrupt or stale - Indicates invalid data, a new reading started but not completed since the last access. |
| -231 | std_dataQuestionable | Data questionable - Indicates that measurement accuracy is suspect. |
| -232 | std_invalidFormat | Invalid format |
| -233 | std_invalidVersion | Invalid version - Indicates that a legal program data element was parsed but could not be executed because the version of the data is incorrect to the device. For example, a not supported file version, a not supported instrument version. |
| -240 | std_hardware | Hardware - Indicates that a legal program command or query could not be executed because of a hardware problem in the device. |
| -241 | std_hardwareMissing | Hardware missing - Indicates that a legal program command or query could not be executed because of missing device hardware. For example, an option was not installed. |

| | | |
|------|------------------------|---|
| -250 | std_massStorage | Mass storage - Indicates that a mass storage error occurred. The device cannot detect the more specific errors described for errors -251 through -259. |
| -251 | std_missingMassStorage | Missing mass storage - Indicates that a legal program command or query could not be executed because of missing mass storage. |
| -252 | std_missingMedia | Missing media - Indicates that a legal program command or query could not be executed because of missing media. For example, no disk. |
| -253 | std_corruptMedia | Corrupt media - Indicates that a legal program command or query could not be executed because of corrupt media. For example, bad disk or wrong format. |
| -254 | std_mediaFull | Media full- Indicates that a legal program command or query could not be executed because the media is full. For example, there is no room left on the disk. |
| -255 | std_directoryFull | Directory full - Indicates that a legal program command or query could not be executed because the media directory was full. |
| -256 | std_fileNotFound | File name not found - Indicates that a legal program command or query could not be executed because the file name was not found on the media. |
| -257 | std_fileName | File name - Indicates that a legal program command or query could not be executed because the file name on the device media was in error. For example, an attempt was made to read or copy a nonexistent file. |
| -258 | std_mediaProtected | Media protected - Indicates that a legal program command or query could not be executed because the media was protected. For example, the write-protect switch on a memory card was set. |
| -260 | std_expression | Expression |
| -261 | std_math | Math in expression |
| -270 | std_macroExecution | Macro - Indicates that a macro related execution error occurred. |
| -271 | std_macroSyntax | Macro syntax - Indicates that a syntactically legal macro program data sequence, according to IEEE 488.2, 10.7.2, could not be executed due to a syntax error within the macro definition. |
| -272 | std_macroExec | Macro execution - Indicates that a syntactically legal macro program data sequence could not be executed due to some error in the macro definition, see IEEE 488.2, 10.7.6.3. |
| -273 | std_badMacroName | Illegal macro label - Indicates that the macro label was not accepted, it did not agree with the definition in IEEE 488.2, 10.7.3 |
| -274 | std_macroPlaceholderMa | cro parameter - Indicates that the macro definition improperly used a macro parameter placeholder, see IEEE 488.2, 10.7.3. |
| -275 | std_macroTooLong | Macro definition too long - Indicates that a syntactically legal macro program data sequence could not be executed because the string of block contents were too long for the device to handle, IEEE 488.2, 10.7.6.1. |
| -276 | std_macroRecursion | Macro recursion - Indicates that a syntactically legal macro program data sequence could not be executed because it would be recursive, see IEEE |

| | |
|-----------------------------|---|
| | 488.2, 10.7.6.6. |
| -277 std_cantRedefineMacro | Macro redefinition not allowed - Indicates that redefining an existing macro label, see IEEE 488.2, 10.7.6.4. |
| -278 std_macroNotFound | Macro header not found - Indicates that a legal macro label in the *GMS?, see IEEE 488.2, 10.13, could not be executed because the header was not previously defined. |
| -280 std_program | Program |
| -281 std_cantCreateProgram | Cannot create program |
| -282 std_illegalProgramName | Illegal program name |
| -283 std_illegalVarName | Illegal variable name |
| -284 std_programRunning | Program currently running |
| -285 std_programSyntax | Program syntax |
| -286 std_programRuntime | Program runtime |
| -290 std_memoryUse | Memory use |
| -291 std_execOutOfMemory | Out of memory |
| -292 std_nameNotFound | Referenced name does not exist |
| -293 std_nameAlreadyExists | Referenced name already exists |
| -294 std_incompatibleType | Incompatible type |

-300 to -399 SCPI Specified Device-Specific Errors

A device-specific error indicates that the instrument has detected an error that occurred because some operations did not properly complete, possibly due to an abnormal hardware or firmware condition. For example, an attempt by the user to set an out of range value will generate a device specific error. When one of these errors is generated, the device specific error bit in the event status register is set.

| | |
|---------------------------|---|
| -300 std_deviceSpecific | Device specific - This event bit (Bit 3) indicates that a device operation did not properly complete due to some condition, such as overrange see IEEE 488.2, 11.5.1.1.6. |
| -310 std_system | System |
| -311 std_memory | Memory - Indicates some physical fault in the devices memory, such as a parity error. |
| -312 std_PUDmemoryLost | PUD memory lost - Indicates protected user data saved by the *PUD command has been lost, see IEEE 488.2, 10.27. |
| -313 std_calMemoryLost | Calibration memory lost - Indicates that nonvolatile calibration data used by the *CAL? command has been lost, see IEEE 488.2, 10.2. |
| -314 std_savRclMemoryLost | Save/recall memory lost - Indicates that the nonvolatile data saved by the *SAV command has been lost, see IEEE 488.2, 10.33. |
| -315 std_configMemoryLost | Configuration memory lost - Indicates that nonvolatile configuration data saved by the device has been lost. |

| | | |
|------|------------------------|--|
| -320 | std_storageFault | Storage fault - Indicates that the firmware detected a fault when using data storage. This is not an indication of physical damage or failure of any mass storage element. |
| -321 | std_outOfMemory | Out of memory - An internal operation needed more memory than was available |
| -330 | std_selfTestFailed | Self-test failed - Indicates a problem with the device that is not covered by a specific error message. The device may require service. |
| -340 | std_calFailed | Calibration failed - Indicates a problem during calibration of the device that is not covered by a specific error. |
| -350 | std_queueOverflow | Queue overflow - Indicates that there is no room in the queue and an error occurred but was not recorded. This code is entered into the queue in lieu of the code that caused the error. |
| -360 | std_comm | Communication - This is the generic communication error for devices that cannot detect the more specific errors described for error -361 through -363. |
| -361 | std_parity | Parity in program message - Parity bit not correct when data received for example, on a serial port. |
| -362 | std_framing | Framing in program message - A stop bit was not detected when data was received for example, on a serial port (for example, a baud rate mismatch). |
| -363 | std_inputBufferOverrun | Input buffer overrun - Software or hardware input buffer on serial port overflows with data caused by improper or nonexistent pacing. |

-400 to -800 Query and System Errors

A Query error is generated either when data in the instrument's GPIB output queue has been lost, or when an attempt is being made to read data from the output queue when no output is present or pending.

| | | |
|------|------------------------|---|
| -400 | std_queryGen | Query - This event bit (Bit 2) indicates that an attempt to read data from the Output Queues when no output is present or pending, to data in the Output Queue has been lost see IEEE488.2, 11.5.1.1.7. |
| -410 | std_interrupted | Query INTERRUPTED - Indicates the test set has been interrupted by a new program message before it finishes sending a RESPONSE MESSAGE see IEEE 488.2, 6.3.2.3. |
| -420 | std_terminated | Query UNTERMINATED - Indicates an incomplete Query in the program see IEEE 488.2, 6.3.2.2. |
| -430 | std_deadlocked | Query DEADLOCKED - Indicates that the Input Buffer and Output Queue are full see IEEE 488.2, 6.3.1.7. |
| -440 | std_responseNotAllowed | Query UNTERMINATED after indefinite response - Indicates that a query was received in the same program message after a query requesting an indefinite response was executed see IEEE 488.2, 6.5.7.5. |
| -500 | std_powerOn | Power on |
| -600 | std_userRequest | User request |
| -700 | std_requestControl | Request control |

-800 std_operationComplete Operation complete

.

Analyzer-Specific (Positive) SCPI Errors

-115 UnexpectedNumberOfParameters The number of parameters received does not correspond to the number of parameters expected.

Last Modified:

4-Aug-2009 Cosmetic mods

Examples

FieldFox Programming Examples

- [NA Mode Setup](#)
- [Calibrations](#)
- [Markers](#)
- [VVM Mode](#)
- [FOPS](#)
- [C# Example Program](#) (Make a connection)
- [Read Block Data using C#](#)
- [Transfer Image to PC](#)

VEE Examples

- [Get NA Formatted Data as Real 32 BinBlock](#)
- [Get NA Formatted Data as ASCII Output](#)
- [Trigger Synch Sweep Complete](#)
- [SpecAn Get Data as ASCII Output](#)

See Also

[Instrument Console](#)

NA Mode

This example shows how to:

- Create a simple NA Mode setup with 4-window configuration
- Set format, scale, frequency, IFBW, Averaging
- Set triggering to Single
- Read Data
- Clear Averaging

Note: In the following example:

"-p" indicates a user prompt.

"#" indicates a comment

This example can be copied into a text editor, saved as a *.txt file, and run using the free Agilent Instrument Console program. [Learn more.](#)

```
# Preset Instrument and Hold
```

```
*RST
```

```

# Change to NA Mode and wait until changed
INST:SEL "NA";*OPC?
# 4 window configuration
DISP:WIND:SPL D12_34
#change window 4 to R1 measurement
CALC:PAR4:DEF R1
#Select window 4
CALC:PAR4:SEL
#change window 4 format to SWR
CALC:FORMat SWR
# Autoscale window 1
DISP:WIND:TRAC1:Y:AUTO
# Set Center Freq
SENS:FREQ:CENT 2e9
# Set Freq Span
SENS:FREQ:SPAN 500e6
#set IFBW to 10 kHz
BWID 10e3
# Set averaging to 5 sweeps
AVER:COUNT 5
#Select window 1
CALC:PAR1:SEL
# Set to HOLD mode; wait
INIT:CONT 0;*OPC?
# Trigger FIVE measurements
# Wait between each
INIT:IMMediate;*OPC?
INIT:IMMediate;*OPC?
INIT:IMMediate;*OPC?
INIT:IMMediate;*OPC?
INIT:IMMediate;*OPC?
#Read formatted data from selected trace (1)
CALC:DATA:FDATA?
#Clear averaging
AVER:CLEar
#And do another sweep
INIT:IMMediate;*OPC?

```

Last Modified:

23-Aug-2011

New command

Calibration Examples

The following examples show how to perform various calibrations in CAT and NA modes.

About Calibration Settings

A calibration session that is performed using the front-panel is completely separate from a calibration session that is performed programmatically.

Therefore, calibration settings that are made remotely (such as setting the cal kit and connectors) can NOT be observed from the front-panel user interface. Alternatively, calibration settings that are made from the FieldFox front panel (user interface) can NOT be queried programmatically.

Guided Cal

- [Guided Calibration](#) (separate topic)
- [ECal](#) (separate topic)

Mechanical Cals

- [1-Port OSL](#)
- [2-Port SOLR](#)
- [2-Port QSOLT](#)
- [2-Port Enhanced Response](#)
- [THRU Response](#)

QuickCals

- [1-Port QuickCal](#)
- [2-Port Non-Insertable QuickCal](#)
- [2-Port Insertable QuickCal](#)
- [Enhanced Response QuickCal](#)

Note: To Cal a VVM mode measurement, perform a Cal in CAT or NA mode, then switch to VVM mode.

See Also

[CAT Mode Commands](#)

[NA Mode Commands](#)

[See All Programming Examples](#)

Note: In the following examples:

"-p" indicates a user prompt.

"#" indicates a comment

Examples can be copied into a text editor, saved as a *.txt file, and run using the free Agilent Instrument Console program. [Learn more.](#)

1- Port OSL Cal on port 1

To perform a 1-port cal on port 2, replace all the '1' arguments with '2'.

```
# Select a Type-N male, 50 ohm connector
```

```

# as the DUT connector to be attached to port 1.
# Be careful with the dashes in -M- for the following command.
# Some editors will change the character.
CORR:COLL:CONN 1, "Type-N -M-,50"
# select the calkit to use.
CORR:COLL:CKIT:LABel 1,"85032B/E"
# Select 1-port cal (SOLT1) on port 1
CORR:COLL:METH:SOLT1 1
-p attach load to port 1
CORR:COLL:LOAD 1;*OPC?
-p attach short to port 1
CORR:COLL:SHOR 1;*OPC?
-p attach open to port 1
CORR:COLL:OPEN 1;*OPC?
# Finish and apply the cal
CORR:COLL:SAVE 0

```

2-Port SOLR Cal

```

# Setup 2-port SOLR Unknown Thru Cal between ports 1 and 2*
# Use the Type N male T kit on both ports
# Cal with either insertable or non-insertable connectors
# Do NOT use on N9912A
corr:coll:ckit:lab 1, "1250-3607"
corr:coll:ckit:lab 2, "1250-3607"
# Be careful with the dashes in -M- for the following command.
# Some editors will change the character.
corr:coll:conn 1,"Type-N -M-,50"
corr:coll:conn 2,"Type-N -M-,50"
CORR:COLL:METH:SOLR 1,2
-p Attach load to port 1
corr:coll:load 1;*OPC?
-p Attach short to port 1
corr:coll:shor 1;*OPC?
-p Attach open to port 1
corr:coll:open 1;*OPC?
-p Attach load to port 2
corr:coll:load 2;*OPC?
-p Attach short to port 2
corr:coll:shor 2;*OPC?
-p Attach open to port 2

```



```
corr:coll:open 2;*OPC?  
-p Attach thru between ports 1 and 2  
corr:coll:thru 1,2;*OPC?  
corr:coll:save 0
```

2-Port QSOLT

```
# Setup 2-port QSOLT between port 1 and 2 using the T kit on port 1*  
# OSL standards measured on port 2 - not available from the GUI  
# For insertable DUTs ONLY  
# Do NOT use on N9912A  
corr:coll:ckit:lab 1, "1250-3607"  
# Be careful with the dashes in -M- for the following command.  
# Some editors will change the character.  
corr:coll:conn 1,"Type-N -M-,50"  
corr:coll:conn 2,"Type-N -F-,50"  
corr:coll:meth:QSOL 1,2  
-p Attach load to port 1  
corr:coll:load 1;*OPC?  
-p Attach short to port 1  
corr:coll:shor 1;*OPC?  
-p Attach open to port 1  
corr:coll:open 1;*OPC?  
-p Attach thru between ports 1 and 2  
corr:coll:thru 1,2;*OPC?  
corr:coll:save 0
```

2-Port Enhanced Response

```
# Enhanced Response requires an insertable DUT  
# N9923A, calibrate measurements in either forward or reverse direction.  
# N9912A, calibrate measurements in forward direction ONLY.  
# This example is forward direction  
# Choose the 85052D kit for port 1 and also port 2  
corr:coll:ckit:lab 1, "85052D"  
corr:coll:ckit:lab 2, "85052D"  
# Choose connectors for port 1 and then port 2  
# Be careful with the dashes in -M- for the following command.  
# Some editors will change the character.  
corr:coll:conn 1,"3.5 mm -M-,50"  
corr:coll:conn 2,"3.5 mm -F-,50"  
# Choose Enhanced Response forward
```

```

# For reverse measurement, use <2,1> and measure stds on port 2
corr:coll:meth:ERES 1,2
# Start measuring standards:
-p Attach short to port 1
corr:coll:shor 1;*OPC?
-p Attach open to port 1
corr:coll:open 1;*OPC?
-p Attach load to port 1
corr:coll:load 1;*OPC?
-p Connect ports 1 and 2 with Flush Thru
corr:coll:thru 1,2;*OPC?
# Saves the finished calibration
corr:coll:save 0

```

THRU Response - Normalization

```

# Correct transmission measurements
# N9912A must have Opt 110
SENS:CORR:COLL:METH:THRU 1,2
-p Attach thru now
SENS:CORR:COLL:THRU 1,2;*OPC?
# Finish and apply the cal
SENS:CORR:COLL:SAVE 0

```

QuickCals

1-Port QuickCal

```

CORR:COLL:METH:QCAL:CAL 1
# First step required to measure internal standards
# Port 1 must be left open
CORR:COLL:INT 1;*OPC?
-p (Optional) Attach load to port
CORR:COLL:LOAD 1;*OPC?
CORR:COLL:SAVE 0

```

2-Port Non-Insertable QuickCal*

```

# Setup full 2-port cal between port 1 and 2 using QuickCal.
# For a non-insertable DUT (both Type-N -M-)- performs SOLR
# Measure INT OPEN, SHORT on BOTH ports
# The load measurement steps are optional.
# Do NOT use on N9912A
# Be careful with the dashes in -M- for the following commands.
# Some editors will change the character.

```

```
corr:coll:conn 1,"Type-N -M-,50"  
corr:coll:conn 2,"Type-N -M-,50"  
corr:coll:meth:QCAL:CAL 1,2  
-p Leave port 1 and port 2 open (no connection)  
corr:coll:int 1;*OPC?  
corr:coll:int 2;*OPC?  
-p Attach a load to port 1  
corr:coll:load 1;*OPC?  
-p Attach a load to port 2  
corr:coll:load 2;*OPC?  
-p Connect ports 1 and 2 using any adapter/thru  
corr:coll:thru 1,2;*OPC?  
corr:coll:save 0
```

2-Port Insertable QuickCal*

```
# Setup full 2-port QuickCal between port 1 and 2  
# For an Insertable DUT - performs QSOLT cal  
# Measure INT OPEN, SHORT on ONLY one port  
# Best to measure INT OPEN, SHORT on port without jumper cable  
# The load measurement steps are optional.  
# Do NOT use on N9912A  
# Be careful with the dashes in -M- for the following command.  
# Some editors will change the character.  
corr:coll:conn 1,"Type-N -M-,50"  
corr:coll:conn 2,"Type-N -F-,50"  
corr:coll:meth:QCAL:CAL 1,2  
-p Leave port 1 and port 2 open (no connection)  
corr:coll:int 1;*OPC?  
-p Attach a load to port 1  
corr:coll:load 1;*OPC?  
-p Attach a load to port 2  
corr:coll:load 2;*OPC?  
-p Connect ports 1 and 2 using any adapter/thru  
corr:coll:thru 1,2;*OPC?  
corr:coll:save 0
```

Enhanced Response QuickCal

```
# Enhanced Response requires an Insertable DUT  
# N9923A, calibrate measurements in either forward or reverse direction.
```

```

# N9912A, calibrate measurements in forward direction ONLY.
# This example is forward direction
# For reverse measurement, use <2,1> and measure stds on port 2
# Choose connectors for port 1 and then port 2
# Be careful with the dashes in -M- for the following command.
# Some editors will change the character.
corr:coll:conn 1,"3.5 mm -M-,50"
corr:coll:conn 2,"3.5 mm -F-,50"
CORR:COLL:METH:QCAL:ERES 1,2
# Step 1 - Ports 1 and 2 must be left open
-p Leave ports 1 and 2 OPEN
CORR:COLL:INT 1;*OPC?
# Step 2 - (Optional)
-p Attach load to port 1
CORR:COLL:LOAD 1;*OPC?
# Step 3 - Connect ports
-p connect port 1 and port 2
CORR:COLL:THRU 1,2;*OPC?
CORR:COLL:SAVE 0

```

Guided Calibration

The following C# example program performs a 1-port cal:

```

//
// Performs a 1-port guided cal on the specified port with the specified connector
// for that port and kit for that port.
//
// port - port number to perform the 1-port calibration on
// connector - the connector name for the DUT connector, e.g. "Type-N -M-,50"
// kitLabel - the label of the calkit to use, e.g. "1250-3607"
//
void Do1PortGuidedCal(int port, string connector, string kitLabel)
{
    Instrument.Write(string.Format("sens:corr:coll:conn {0},{1}", port, connector));
    Instrument.Write (string.Format("sens:corr:coll:ckit:lab {0},{1}",port,kitLabel));
    Instrument.Write (string.Format("sens:corr:coll:meth:SOLT1 {0}", port));

    int steps = ReadInt("SENS:CORR:COLL:GUID:SCOunt?");
    for(int s = 1; s <= steps; ++s)

```

```

{
    string steptext = Instrument.ReadString(string.Format("SENS:CORR:COLL:GUID:STEP:PROM? {0}",s));
    PromptUser(steptext); // blocks until user confirms they've performed the requested action
    Instrument.Write (string.Format("SENS:CORR:COLL:GUID:STEP:ACQ {0}",s));
    Instrument.ReadInt("*OPC?");
}
Console.Write("Saving...");
Instrument.Write ("CORR:COLL:SAVE 0");
Instrument.ReadInt("*OPC?");
Console.WriteLine("Done ");
}

```

ECal Calibration

ECal requires the use of the Guided Cal acquisition command:

[\[:SENSe\]:CORRection:COLLect:GUIDed:STEP:ACQuire](#)

The following two 'Guided' commands are optional:

[\[:SENSe\]:CORRection:COLLect:GUIDed:SCOunt](#)

[\[:SENSe\]:CORRection:COLLect:GUIDed:STEP:PROMpt](#)

Note: In the following example:

"-p" indicates a user prompt.

"#" indicates a comment

This example can be copied into a text editor, saved as a *.txt file, and run using the free Keysight Instrument Console program. [Learn more.](#)

Relevant ECal module commands:

- [\[:SENSe\]:CORRection:COLLect:CKIT:LABel](#)
- [\[:SENSe\]:CORRection:COLLect:FCAL:AORient](#)

The following program performs a **2-port** SOLR calibration using an ECal module that is connected to a FieldFox.

A 2-port ECal may have 1 or 3 three steps depending on if 'simple ECal' is set and if the ECal is insertable (can connect to both test ports simultaneously). If one of those conditions is NOT true, then the cal will require 3 steps.

If you would like to use the 3 step cal process, ensure that [CORR:COLL:FCAL:SIMP_0](#) has been set.

A **1-port ECal** would require only 1 step.

If you would like to use 1 step simple cal ensure that [CORR:COLL:FCAL:SIMP_1](#) has been set.

The Guided [SCOunt](#) command is used to query the number of steps required.

The following example is for a **2-port** SOLR cal that uses 3 steps.

```

# First setup a 2-port measurement between port 1 and 2
#
# Change the following line to your DUT/ECal module connector type and gender.
# Be careful with the dashes in -F- for the following command.
# Some editors will change the character.
corr:coll:conn 1,"Type-N -F-,50"
corr:coll:conn 2,"Type-N -F-,50"
# Change to your model ECal module
corr:coll:ckit:lab 1, "N4431A"
corr:coll:ckit:lab 2, "N4431A"
CORR:COLL:METH:SOLR 1,2
# ECal requires the use of the Guided cal acquisition
# do a For/Next loop, query the number of steps (N)
# CORR:COLL:GUID:SCO?
# CORR:COLL:GUID:STEP:PROM? <step num> // query the prompt (optional, but recommended!)
# CORR:COLL:GUID:STEP:ACQ <step num>,*OPC?
# Otherwise, measure all three stds for SOLR ECal w/o prompts
CORR:COLL:GUID:STEP:ACQ 1,*OPC?
CORR:COLL:GUID:STEP:ACQ 2,*OPC?
CORR:COLL:GUID:STEP:ACQ 3,*OPC?
# Finish
CORR:COLL:SAVE 0

```

Marker Example

This example shows how to create and move Delta Markers.

Note: In the following example:

"-p" indicates a user prompt.

"#" indicates a comment

This example can be copied into a text editor, saved as a *.txt file, and run using the free Agilent Instrument Console program. [Learn more.](#)

```
# Preset Instrument and Hold
```

```
*RST
```

```

# Change to NA Mode and wait until changed
INST:SEL "NA";*OPC?
# Set Center Freq
SENS:FREQ:CENT 2e9
# Set Freq Span
SENS:FREQ:SPAN 500e6
# Setup the instrument to measure Insertion Loss
CALC:PAR:DEF S21
# Set to single trigger
INIT:CONT 0
# Take a single sweep at new freq and measurement
INIT:IMM;*OPC?
# Create reference marker
CALC:MARK1 NORM
# Move the marker to 1.75 GHz
CALC:MARK1:X 1.75e9
# Change to Delta Marker
CALC:MARK1 DELT
# Move the delta marker to 2.0 GHz
CALC:MARK1:X 2e9
# Take a sweep
INIT:IMM;*OPC?
# Read the Y axis values of the marker
# First value is mag, second is zero
CALC:MARK1:Y?

```

FOPS Measurement

The following example sets up a VVM measurement.

Note: In the following example:

"-p" indicates a user prompt.

"#" indicates a comment

This example can be copied into a text editor, saved as a *.txt file, and run using the free Agilent Instrument Console program. [Learn more.](#)

```

# Preset Instrument
SYST:PRESet;*OPC?
#Select USB Power Meter
inst "Power Meter"

```

```

#Set the max number of ps readings and tolerance settings?
TOL 0.1
POINT:READ:MAX 2
#Select FOPS
SWE:TYPE SWEPT
#Set frequencies
SOUR:FREQ:STAR .5e9
SOUR:FREQ:STOP 1.5e9
SOUR:REC:OFFS .05e9
FREQ:STEP 50e6
#Set Forward sweep
SWE:RX FORWARD
#Set Power Level
SOUR:POW 0
#Set dwell time
POIN:DWEL .05
#Measure Source Power
-p "Connect the power sensor"
INIT:CONT 0
INITiate:IMMediate;*OPC?
SOURce:POWer:MEMorize;*OPC?
TRACe:MEASurement Gain

```

VVM Mode Example

The following example sets up a VVM measurement.

Note: In the following example:

"-p" indicates a user prompt.

"#" indicates a comment

This example can be copied into a text editor, saved as a *.txt file, and run using the free Agilent Instrument Console program. [Learn more](#).

```

# Preset Instrument
SYST:PRESet;*OPC?
# Change to VVM Mode and wait until changed
INST:SEL "VVM";*OPC?
# Set to single sweep
INIT:CONT 0;*OPC?

```



```

# Setup the instrument for 1-port cable trimming
CALC:PAR:DEF S11
# Set Center Freq
SENS:FREQ:CENT 2e9
# Take a sweep to ensure you get a valid point on your new frequency.
INIT:IMM;*OPC?
# Attach the Reference cable
-p "Attach Reference Cable"
# Zero the display
SENS:CORR:ZERO:STAT ON;*OPC?
# Take another sweep to show the zero in action
INIT:IMM;*OPC?
# Prompt to attach a cable
-p "Attach Cable to Trim"
# Put into freerun mode
INIT:CONT ON

```

VVS Example

The following example sets up the VVS (variable voltage source).

Note: In the following example:

"-p" indicates a user prompt.

"#" indicates a comment

This example can be copied into a text editor, saved as a *.txt file, and run using the free Agilent Instrument Console program. [Learn more.](#)

The following example focuses on reliable switching (On and Off) of the VVS. The key is to make sure that the query reflects the current condition. This is important because the query result is NOT always updated.

The following is **psuedo code** as the Instrument Console has limited programming capability.

```

#This section ensures that the VVS is indeed ON after being tripped.
# Send VVS query
SYST:VVS?
# If "TRIPPED" is returned, then disable VVS
SYST:VVS:ENAB 0
# Wait 50 ms, then enable.
SYST:VVS:ENAB 1
# wait 50 ms, then repeat query.
SYST:VVS?
# If ON, then finished. Otherwise, send ENABLE again, and then another

```

```

query.

#This section ensures that the VVS is indeed OFF.
# Send VVS query
SYST:VVS?
# If "TRIPPED" is returned, then disable VVS
# If OFF, then finished. Otherwise...
SYST:VVS:ENAB 0
# wait 50 ms, then repeat query.
SYST:VVS?
# wait 50 ms, then repeat query.
# If OFF, then finished. Otherwise, send ENABLE 1, then ENABLE 0, and then
another query.
SYST:VVS:ENAB 1
# Wait 50 ms.
SYST:VVS:ENAB 0
# wait 50 ms, then repeat query.
SYST:VVS?

```

C# Example Program

The following C# example demonstrates how to send SCPI commands to the FieldFox using a TCP socket connection over a LAN connection.

- It is NOT necessary that you know C# to write a SCPI program. It is ONLY necessary that you understand basic SCPI syntax. You can add or replace the SCPI commands in this example program with your own.
- If you ARE familiar with C#, you can [Download the project files here](#). (Internet connection required).

Note: You can also send single SCPI commands to the FieldFox using this free [Instrument Console program](#).

Requirements

To connect to the FieldFox and run SCPI programs, you must first download and install the Visual C# Express software from: <http://www.microsoft.com/express/download/>

Once the program is installed, search the PC hard drive for csc.exe. This file could be in the C:\Windows\Microsoft.NET directory.

NOTE: If more than one folder contains csc.exe, use the folder with the latest revision.

Write the SCPI program

The following procedure uses the example filename MyProgram.cs. You can use any filename that you like.

1. Copy the text in the shaded area below into a Notepad file and name it MyProgram.cs.
2. Write your SCPI program between the //Start your program here and //End your program here lines. Several example lines are provided to demonstrate the syntax in which the SCPI commands must be contained. See the SCPI Command Reference and Program Examples for more information.

Run the SCPI Program


Record the dynamically-assigned IP address of the FieldFox.

1. Shut down the FieldFox.
2. Connect the FieldFox to the Internet using a LAN connection.
3. Power ON the FieldFox.
4. On the FieldFox, press System, then System Configuration, then LAN.
5. Record the Current IP Address
6. Compile your program by executing `csc.exe MyProgram.cs`. This creates a file named `MyProgram.exe` in the same directory as `csc.exe`.
7. Run your SCPI program by executing `MyProgram.exe <FieldFox IP Address>`. For example:
`MyProgram.exe 192.121.1.101`


To make this process more convenient:

The following steps show how to create shortcuts on your PC desktop to compile and run `MyProgram.exe`.

1. Using Windows Explorer, navigate to the folder that contains `csc.exe`. **NOTE:** If more than one folder contains `csc.exe`, use the folder with the latest revision.
2. Right-click `csc.exe` then click **Create Shortcut**.
3. Drag the shortcut file to the PC desktop.
4. Right-click on the desktop shortcut, then click **Properties**.
5. Append a space, the full path, and filename to the end of the "Target" as in the following image. This example shows `MyProgram.cs` is saved to the `C:\` folder.



6. After performing a compile, perform the same 'shortcut' procedure for `MyProgram.exe` except, instead of appending the path and filename, append the IP address of the FieldFox.



Copy the text in the following shaded area to a Notepad file.

```
using System;
using System.Collections.Generic;
using System.Text;
using System.Net.Sockets;
using System.IO;
namespace Network.Connect
{
    class Program
    {
        static TelnetConnection tc;
        static int Main(string[] args)
```

```

    {
        // defaultHostName is host name to use if one is not specified
on the command line.
        string defaultHostName = "192.168.1.1";
        string hostName = defaultHostName;
        if( args.Length == 1 )
        {
            // If command line contains a '?' character, interpret
this as help.
            if( args[0].Contains("?"))
            {
                Console.WriteLine("Usage: N9912A_CS_Example.exe
<hostName>\n\n"+
                    "Where optional hostName is an ip address or host
name.\n" +
                    "If no hostName is supplied, the default
("+defaultHostName+") is used.\n\n"+
                    "e.g. N9912A_CS_Example.exe 10.10.1.1\n\nor\n\n" +
                    "N9912A_CS_Example.exe A-N9912A-22762");
                return 0; // exit.
            }
            // Record hostname passed in on command line.
            hostName = args[0];
        }
        try
        {
            tc = new TelnetConnection();
            tc.ReadTimeout = 10000; // 10 sec
            // open socket on hostName, which can be an IP address, or
use host name (e.g. "A-N9912A-22762") used in lieu of IP
address

            tc.Open(hostName);
            if( tc.IsOpen )
            {
                //Start your program here
                Write("SYST:PRES;*OPC?");
                Write("*IDN?");
                Write("SENS:FREQ:STAR?");
                Write("SENS:FREQ:STAR 3e9");
                Write("SENS:FREQ:STAR?");
                Write("SYST:ERR?");
                Write("SYST:HELP:HEAD?");
                //End your program here
            }
        }
    }

```

```

        tc.Dispose();
        Console.WriteLine("Press any key to exit.");
        Console.ReadKey(); // continue after reading a key
from the keyboard.
    }
    else
    {
        Console.WriteLine("Error opening " + hostName);
        return -1;
    }
    //FieldFox Programming Guide 5
}
catch(Exception e)
{
    Console.WriteLine(e.ToString());
    return -1;
}
// exit normally.
return 0;
}
/// <summary>
/// Write a SCPI command to the telnet connection.
/// If the command has a '?', then read back the response and
print
/// it to the Console.
/// </summary>
/// <remarks>
middle
/// Note the '?' detection is naive, as a ? could occur in the
query.
/// of a SCPI string argument, and not actually signify a SCPI
/// </remarks>
/// <param name="s"></param>
static void Write(string s)
{
    Console.WriteLine(s);
    tc.WriteLine(s);
    if (s.IndexOf('?') >= 0)
        Read();
}
/// <summary>
/// Read the telnet connection for a response, and print the
response to the

```

```

    /// Console.
    /// </summary>
    static void Read()
    {
        Console.WriteLine(tc.Read());
    }
}
#region TelnetConnection - no need to edit
    /// <summary>
    /// Telnet Connection on port 5025 to an instrument
    /// </summary>
    public class TelnetConnection : IDisposable
    {
        TcpClient m_Client;
        NetworkStream m_Stream;
        bool m_IsOpen = false;
        string m_Hostname;
        int m_ReadTimeout = 1000; // ms
        public delegate void ConnectionDelegate();
        public event ConnectionDelegate Opened;
        public event ConnectionDelegate Closed;
        public bool IsOpen { get { return m_IsOpen; } }
        public TelnetConnection() { }
        public TelnetConnection(bool open) : this("localhost", true) { }
        public TelnetConnection(string host, bool open)
        {
            if (open)
                Open(host);
        }
        void CheckOpen()
        {
            if (!IsOpen)
                throw new Exception("Connection not open.");
        }
        public string Hostname
        {
            get { return m_Hostname; }
        }
        public int ReadTimeout
        {
            set { m_ReadTimeout = value; if (IsOpen) m_Stream.ReadTimeout
= value; }

```

```

        get { return m_ReadTimeout; }
    }
    public void Write(string str)
    {
        //FieldFox Programming Guide 6
        CheckOpen();
        byte[] bytes = System.Text.ASCIIEncoding.ASCII.GetBytes(str);
        m_Stream.Write(bytes, 0, bytes.Length);
        m_Stream.Flush();
    }
    public void WriteLine(string str)
    {
        CheckOpen();
        byte[] bytes = System.Text.ASCIIEncoding.ASCII.GetBytes(str);
        m_Stream.Write(bytes, 0, bytes.Length);
        WriteTerminator();
    }
    void WriteTerminator()
    {
        byte[] bytes =
System.Text.ASCIIEncoding.ASCII.GetBytes("\r\n\0");
        m_Stream.Write(bytes, 0, bytes.Length);
        m_Stream.Flush();
    }
    public string Read()
    {
        CheckOpen();
        return System.Text.ASCIIEncoding.ASCII.GetString(ReadBytes());
    }
    /// <summary>
    /// Reads bytes from the socket and returns them as a byte[].
    /// </summary>
    /// <returns></returns>
    public byte[] ReadBytes()
    {
        int i = m_Stream.ReadByte();
        byte b = (byte)i;
        int bytesToRead = 0;
        var bytes = new List<byte>();
        if ((char)b == '#')
        {
            bytesToRead = ReadLengthHeader();

```

```

        if (bytesToRead > 0)
        {
            i = m_Stream.ReadByte();
            if ((char)i != '\n') // discard carriage return after
length header.
                bytes.Add((byte)i);
        }
    }
    if (bytesToRead == 0)
    {
        while (i != -1 && b != (byte)'\n')
        {
            bytes.Add(b);
            i = m_Stream.ReadByte();
            b = (byte)i;
        }
    }
    else
    {
        int bytesRead = 0;
        while (bytesRead < bytesToRead && i != -1)
        {
            i = m_Stream.ReadByte();
            if (i != -1)
            {
                bytesRead++;
                // record all bytes except \n if it is the last
char.
                if (bytesRead < bytesToRead || (char)i != '\n')
                    bytes.Add((byte)i);
            }
        }
    }
    return bytes.ToArray();
}
int ReadLengthHeader()
{
    int numDigits = Convert.ToInt32(new string(new char[] {
(char)m_Stream.ReadByte() }));
    string bytes = "";
    for (int i = 0; i < numDigits; ++i)
        bytes = bytes + (char)m_Stream.ReadByte();
}

```



```

        return Convert.ToInt32(bytes);
    }
    public void Open(string hostname)
    {
        if (IsOpen)
            Close();
        m_Hostname = hostname;
        m_Client = new TcpClient(hostname, 5025);
        m_Stream = m_Client.GetStream();
        m_Stream.ReadTimeout = ReadTimeout;
        m_IsOpen = true;
        if (Opened != null)
            Opened();
    }
    public void Close()
    {
        if (!m_IsOpen)
            //FieldFox Programming Guide 7
            return;
        m_Stream.Close();
        m_Client.Close();
        m_IsOpen = false;
        if (Closed != null)
            Closed();
    }
    public void Dispose()
    {
        Close();
    }
}
#endregion
}

```

Read Block Data using Csharp

The following example program illustrates how to parse [block data](#) using C#.

```

/// <summary>
/// Generates a IEEE block header for the specified size.
/// </summary>
/// <remarks>

```

```

/// The block header is of the form #[digit indicating number of digits to follow][length]
/// e.g. 201 bytes -> "#3201
/// 9999 bytes -> "#49999"
/// 0 bytes -> "#10"
/// </remarks>
/// <param name="size">Size of the block.</param>
/// <returns>Block header size string.</returns>
string GenerateBlockHeader(int size)
{
    string sz = size.ToString();
    return "#" + sz.Length.ToString() + sz;
}
/// <summary>
/// Parses a partially digested IEEE block length header, and returns
/// the specified byte length.
/// </summary>
/// <remarks>
/// The Stream pointer is assumed to point to the 2nd character of the block header
/// (the first digit of the actual length). The caller is assumed to have parsed the
/// first two block header characters (#?, where ? is the number of digits to follow),
/// and converted the "number of digits to follow" into the int argument to this function.
/// </remarks>
/// <param name="numDigits">Number of digits to read from the stream that make up the
/// length in bytes.</param>
/// <returns>The length of the block.</returns>
int ReadLengthHeader(int numDigits)
{
    string bytes = string.Empty;
    for (int i = 0; i < numDigits; ++i)
        bytes = bytes + (char)Stream.ReadByte();
    return Convert.ToInt32(bytes);
}

```

Transfer Image to PC

This example shows how to transfer an image (screenshot) on the FieldFox to a remote PC.

Note: In the following example:

"#" indicates a comment

This example can be copied into a text editor, saved as a *.txt file, and run using the free Agilent Instrument Console program. [Learn more.](#)

```
# Store screen to my.png into the current directory on the FieldFox
# The default directory is the userdata directory on the instrument.
MMEM:STOR:IMAG "my.png"
# Transfers the contents of my.png as a BINBLOCK
# The file data that is returned by the 2nd command depends on the
programming environment.
# Environments like VEE, Matlab, C/VISA, etc. all deal with BINBLOCK
transfers in their own way.
MMEM:DATA? "my.png"
# Optionally delete of file from instrument's local storage
MMEM:DEL "my.png"
```

VEE

Get Formatted Data as Real 32 Binary Block

The following VEE example demonstrates how to configure measurement settings, then read formatted Real 32 bit Binary Block data.

Download [N9912A_NA_Get_Fdata_as_Real32BinBlock_Output_PROGRAM.VEE](#)

The screenshot shows the Agilent VEE Pro interface for a test program titled "N9912A_NA_Get_Fdata_as_Real32BinBlock_Output_PROGRAM". The main workspace contains a flowchart with several "n9912a_fieldfox" blocks. The first block is for identification, followed by an "Option Listing" block. A dialog box titled "Advanced Instrument Properties" is open, showing the "General" tab with "Byte Ordering" set to "LSB". A red arrow points to this setting with the text "Modify from default MSB to LSB to support required FF little endian BINARY data transfer mode." Below the flowchart, there are several "Alpha" and "AlphaNumeric" blocks for data handling. A "Trace" window on the right shows a graph of the data, with a peak around 100 on the X-axis.

Last Modified:


24-Aug-2011

New topic

Get Formatted Data as ASCII Output

The following VEE example demonstrates how to configure NA measurement settings, then read formatted ASCII data from the FieldFox.

Download [N9912A_NA_Get_Fdata_as_ASCII_Output_PROGRAM.VEE](#)



Last Modified:


24-Aug-2011

New topic

Trigger Synch Sweep Complete

The following VEE example demonstrates how to configure measurement settings, set trigger to single, then notify when a sweep is complete.

Download [FieldFox_Trigger_Synchronization_Sweep_Complete_Program.VEE](#)



Last Modified:


24-Aug-2011

New topic

SpecAn Get Data as ASCII Output

The following VEE example demonstrates how to configure SA measurement settings, then read formatted ASCII data from the FieldFox.

Download [N9912A_SpecAn_Get_Data_as_ASCII_Output_PROGRAM.VEE](#)



Last Modified:

4-May-2016

New command

Commands by Mode

CAT Mode Commands

In this topic:

- [Set and select Traces](#)
- [Sweep](#)
- [Averaging](#)
- [Display](#)
- [Limit Lines](#)
- [Markers](#)
- [Math](#)
- [DTE](#)
- [DTF Cable Correction](#)
- [TDR](#)
- [Save/Recall](#)
- [Send/Read Data](#)
- [Calibration](#)

See Also

[Commands that are Common to All Modes](#)

[Correction Methods Explained](#)

[New Programming Commands](#)

Set and select Traces

| Description | Commands |
|-------------|----------|
|-------------|----------|

| | |
|-------------------------------|---|
| Set and read number of traces | CALCulate:PARAmeter:COUNt |
|-------------------------------|---|

| | |
|------------------|--|
| Change parameter | CALCulate:PARAmeter:DEFine |
|------------------|--|

| | |
|--------------|--|
| Select trace | CALCulate:PARAmeter:SElect |
|--------------|--|

Sweep Settings

| | |
|-----------------|---|
| Set center freq | [:SENSe]:FREQuency:CENTer |
|-----------------|---|

| | |
|---------------|---|
| Set freq span | [:SENSe]:FREQuency:SPAN |
|---------------|---|

| | |
|----------------|--|
| Set start freq | [:SENSe]:FREQuency:START |
|----------------|--|

| | |
|---------------|---|
| Set stop freq | [:SENSe]:FREQuency:STOP |
|---------------|---|

| | |
|--------------------|--|
| Read X-axis values | [:SENSe]:FREQuency:DATA? |
|--------------------|--|

| | |
|-----------------------------------|---------------------------------------|
| Set resolution (number of points) | [:SENSe]:SWFep:POINts |
|-----------------------------------|---------------------------------------|

| | |
|----------------|-------------------------------------|
| Set sweep time | [:SENSe]:SWFep:TIME |
|----------------|-------------------------------------|

| | |
|----------------------------------|--|
| Read sweep time | [:SENSe]:SWEp:MTIME? |
| Set manual source power | SOURce:POWer |
| Set flat source power | SOURce:POWer:ALC[:MODE] |
| Averaging | |
| Averaging | [:SENSe]:AVERage:COUNT |
| Clear Averaging | [:SENSe]:AVERage:CLear |
| Read IFBW | [:SENSe]:BWID |
| Image rejection | CALCulate:IREJection:LEVel |
| Smoothing On/Off | CALCulate[:SElected]:SMOothing[:STATe] |
| Smoothing aperture | CALCulate[:SElected]:SMOothing:APERture |
| Display Items | |
| View Memory trace | DISPlay:WINDow:TRACe:MEMory:STATe |
| View Data trace | DISPlay:WINDow:TRACe:STATe |
| Scaling - auto | DISPlay:WINDow:TRACe:Y[:SCALe]:AUTO |
| Scaling - Set bottom of scale | DISPlay:WINDow:TRACe:Y[:SCALe]:BOTTom |
| Scaling - Set per division | DISPlay:WINDow:TRACe:Y[:SCALe]:PDIVision |
| Scaling - Set reference level | DISPlay:WINDow:TRACe:Y[:SCALe]:RLEVel |
| Scaling - Set reference position | DISPlay:WINDow:TRACe:Y[:SCALe]:RPOSITION |
| Scaling - Set top of scale | DISPlay:WINDow:TRACe:Y[:SCALe]:TOP |
| Limit Lines | |
| Limit line beep | CALCulate[:SElected]:LIMit:SOUNd |
| Create limit lines | CALCulate[:SElected]:LIMit:LLData |
| Limit line testing state | CALCulate[:SElected]:LIMit[:STATe] |
| Limit line testing annotation | CALCulate[:SElected]:LIMit:WARN |
| Read Pass / Fail | STATus:QUESTionable:LIMit:CONDition? |
| Build Limit from Trace | None |
| Markers | |
| Activate a marker | CALCulate[:SElected]:MARKer:ACTivate |
| Markers - all off | CALCulate[:SElected]:MARKer:AOFF |
| Markers - coupled | CALCulate[:SElected]:MARKer:COUPlEd |
| Marker search - Max | CALCulate[:SElected]:MARKer:FUNCTion:MAXimum |

| | |
|--|--|
| Marker search - Min | CALCulate[:SElected]:MARKer:FUNction:MINimum |
| Marker search - Peak excursion | CALCulate[:SElected]:MARKer:FUNction:PEXCursion |
| Marker search - Peak Next | CALCulate[:SElected]:MARKer:FUNction:PNEXt |
| Marker search - Peak threshold | CALCulate[:SElected]:MARKer:FUNction:PTHReshold |
| Tracking On/Off | CALCulate[:SElected]:MARKer:FUNction:TRACking |
| FieldFox setting => to marker location | CALCulate[:SElected]:MARKer:SET |
| Marker On/Off | CALCulate[:SElected]:MARKer[:STATe] |
| Marker => specified trace | CALCulate[:SElected]:MARKer:TRACe |
| Marker => specified X-axis location | CALCulate[:SElected]:MARKer:X |
| Read Marker Y-axis location | CALCulate[:SElected]:MARKer:Y? |
| Math | |
| Math function | CALCulate[:SElected]:MATH:FUNction |
| Data to Memory | CALCulate[:SElected]:MATH:MEMorize |
| Distance to Fault | |
| DTF - Set bandpasss/lowpass | CALCulate:TRANSform:DIStance:BANdpass |
| DTF - Set center freq | CALCulate:TRANSform:DIStance:FREQUency:CENTer |
| DTF - Set max freq span | CALCulate:TRANSform:DIStance:FREQUency:SPAN:MAXimum |
| DTF - Set min start freq | CALCulate:TRANSform:DIStance:FREQUency:START:MINimum |
| DTF - Set max freq | CALCulate:TRANSform:DIStance:FREQUency:STOP:MAXimum |
| DTF - Set start distance | CALCulate:TRANSform:DIStance:START |
| DTF - Set stop distance | CALCulate:TRANSform:DIStance:STOP |
| DTF - Set distance units | CALCulate:TRANSform:DIStance:UNIT |
| DTF - Set window type | CALCulate:TRANSform:DIStance:WINDow |
| DTF - Set bandpasss/lowpass | CALCulate:TRANSform:FREQUency[:TYPE] |
| DTF Cable Specs | |
| Select Auto or Manual setting | [:SENSe]:CORRection:COAX |
| Set cable loss | [:SENSe]:CORRection:LOSS:COAX |
| Set velocity factor | [:SENSe]:CORRection:RVELocity:COAX |
| TDR | |
| Set resolution mode | [:SENSe]:SWEep:TDR:RES |

Max stop frequency with Res mode = AUTO [\[:SENSe\]:SWEep:TDR:AUTO:FREQuency:STOP:MAXimum](#)

TDR marker format [CALCulate\[:SElected\]:MARKer:TDR:FORMat](#)

Save / Recall Files

Recall Cable data [MMEMory:LOAD:CABLe](#)

Store Cable data [MMEMory:STORe:CABLe](#)

Save data trace to csv file [MMEMory:STORe:FDATa](#)

Save SNP data [MMEMory:STORe:SNP\[:DATA\]](#)

[See other Save / Recall commands](#)

Send / Read Data

Send and read formatted measured data [CALCulate\[:SElected\]:DATA:FDATA](#)

Send and read formatted memory data [CALCulate\[:SElected\]:DATA:EMEM](#)

Set data format for read [FORMat\[:DATA\]](#)

Calibration Commands

See Also

[Correction Methods Explained](#)

[Calibration Examples](#)

Set and read error term data [\[:SENSe\]:CORRection:COEFFicient\[:DATA\]](#)

Read number of cal steps [\[:SENSe\]:CORRection:COLLect:GUIDed:SCOUnt](#)

Measure step number [\[:SENSe\]:CORRection:COLLect:GUIDed:STEP:ACQuire](#)

Prompt for step number [\[:SENSe\]:CORRection:COLLect:GUIDed:STEP:PRoMpt](#)

Measure Quick Cal [\[:SENSe\]:CORRection:COLLect\[:ACQuire\]:INT](#)

Measure load [\[:SENSe\]:CORRection:COLLect\[:ACQuire\]:LOAD](#)

Measure open [\[:SENSe\]:CORRection:COLLect\[:ACQuire\]:OPEN](#)

Measure short [\[:SENSe\]:CORRection:COLLect\[:ACQuire\]:SHORT](#)

Measure thru [\[:SENSe\]:CORRection:COLLect\[:ACQuire\]:THRU](#)

Set Cal Kit [\[:SENSe\]:CORRection:COLLect:CKIT:LABel](#)

Catalog all cal kits [\[:SENSe\]:CORRection:COLLect:CKIT:LABel:CATalog?](#)

Set connectors [\[:SENSe\]:CORRection:COLLect:CONNector](#)

Select method - Enhanced Response [\[:SENSe\]:CORRection:COLLect:METHod:FRES](#)

| | |
|--|---|
| Select method - QuickCal | [:SENSe]:CORRection:COLLect:MEtHod:QCALibrate:CALibrate |
| Select method - QuickCal Enhanced Response | [:SENSe]:CORRection:COLLect:MEtHod:QCALibrate:ERESponse |
| Select method - Simple Open response | [:SENSe]:CORRection:COLLect:MEtHod[:RESponse]:OPEN |
| Select method - Simple Short response | [:SENSe]:CORRection:COLLect:MEtHod[:RESponse]:SHORT |
| Select method - Thru response | [:SENSe]:CORRection:COLLect:MEtHod[:RESponse]:THRU |
| Select method - Short response | [:SENSe]:CORRection:COLLect:MEtHod:SRESponse |
| Select method - Open response | [:SENSe]:CORRection:COLLect:MEtHod:ORESponse |
| Select method - 1-port SOLT | [:SENSe]:CORRection:COLLect:MEtHod:SOLT1 |
| Select method - TRL | [:SENSe]:CORRection:COLLect:MEtHod:TRL |
| Read method | [:SENSe]:CORRection:COLLect:MEtHod:TYPE? |
| Set AutoOrient for ECal | [:SENSe]:CORRection:COLLect:FCAL:AORient |
| Set simple ECal | [:SENSe]:CORRection:COLLect:FCAL:SIMPLE |
| Omit Isolation | [:SENSe]:CORRection:COLLect:OISolation |
| Select Medium | [:SENSe]:CORRection:MEDIum |
| Set Waveguide cutoff | [:SENSe]:CORRection:WGCutoff |
| Select Waveguide standard (CAT only) | [:SENSe]:CORRection:WAVEguide:STANdard |
| Finish Cal | [:SENSe]:CORRection:COLLect:SAVE |
| Turn ALL Correction ON and OFF | [:SENSe]:CORRection[:STATe] |
| Turn User Correction ON and OFF | [:SENSe]:CORRection:USER[:STATe] |
| Set system impedance | [:SENSe]:CORRection:IMPedance[:INPut][:MAGNitude] |
| Set CalReady type | [:SENSe]:CORRection:CALReady:TYPE |

Last Modified:

- 20-Jan-2015 Added 8.0 commands
- 15-Nov-2013 Added TRL
- Added new commands for A.07.25
- Added several commands (A.06.03)

Updated

NA Mode Commands

In this topic:

- [Traces](#)
- [Sweep Settings](#)
- [Averaging](#)
- [Display Items](#)
- [Limit Lines](#)
- [Markers](#)
- [Big Marker Readout](#)
- [Math](#)
- [Save / Recall Files - Data](#)
- [Port Extensions](#)
- [Calibration](#)
- [Time Domain](#) (Opt 010)
- [Time Domain Gating](#) (Opt 010)

See Also

[Commands that are Common to All Modes](#)

[Correction Methods Explained](#)

[New Programming Commands](#)

Traces

| Description | Commands |
|--------------------------------|--|
| Create Measurement | CALCulate:PARAmeter{1:4}:DEFine |
| Set and read number of traces | CALCulate:PARAmeter:COUNT |
| Select Measurement | CALCulate:PARAmeter{1:4}:SELect |
| Set trace format | CALCulate[:SELected]:FORMat |
| Multi-trace Configurations | DISPlay:WINDow:SPLit |
| Perform measurement conversion | CALCulate[:SELected]:CONVersion:FUNction |

Sweep Settings

| | |
|-----------------|---|
| Set center freq | [:SENSe]:FREQuency:CENTer |
| Set freq span | [:SENSe]:FREQuency:SPAN |
| Set start freq | [:SENSe]:FREQuency:START |

| | |
|--|--|
| Set stop freq | [:SENSe]:FREQuency:STOP |
| Read X-axis values | [:SENSe]:FREQuency:DATA? |
| Set resolution (number of points) | [:SENSe]:SWFep:POINts |
| Set sweep time | [:SENSe]:SWFep:TIME |
| Read sweep time | [:SENSe]:SWFep:MTIME? |
| Set manual source power | SOURce:POWer |
| Set flat source power | SOURce:POWer:ALC[:MODE] |
| Set trigger Internal or External | TRIGger:SOURce |
| Set polarity of external | TRIGger:SLOPe |
| IFBW / Average / Smooth / Image Rej | |
| IFBW | [:SENSe]:BWID |
| Averaging | [:SENSe]:AVERage:COUNT |
| Clear Averaging | [:SENSe]:AVERage:CLear |
| Average (Swp/Point) | [:SENSe]:AVERage:MODE |
| Smoothing ON/OFF | CALCulate[:SElected]:SMOothing[:STATe] |
| Smoothing aperture | CALCulate[:SElected]:SMOothing:APERture |
| Display Items | |
| View Memory trace | DISPlay:WINDow:TRACe:MEMory:STATe |
| View Data trace | DISPlay:WINDow:TRACe:STATe |
| Scaling - auto | DISPlay:WINDow:TRACe:Y[:SCALe]:AUTO |
| Scaling - Set bottom of scale | DISPlay:WINDow:TRACe:Y[:SCALe]:BOTTom |
| Scaling - Set per division | DISPlay:WINDow:TRACe:Y[:SCALe]:PDIVision |
| Scaling - Set reference level | DISPlay:WINDow:TRACe:Y[:SCALe]:RIEVel |
| Scaling - Set reference position | DISPlay:WINDow:TRACe:Y[:SCALe]:RPOSition |
| Scaling - Set top of scale | DISPlay:WINDow:TRACe:Y[:SCALe]:TOP |
| Electrical Delay | CALCulate[:SElected]:CORRection:EDELay:TIME |
| Phase Offset | CALCulate[:SElected]:CORRection:OFFSet:PHASe |
| Mag Offset | CALCulate[:SElected]:OFFSet[:MAGNitude] |
| Mag Slope | CALCulate[:SElected]:OFFSet:SLOPe |

Limit Lines

| | |
|--|---|
| Limit line beep | CALCulate[:SElected]:LIMit:SOUNd |
| Create limit lines | CALCulate[:SElected]:LIMit:LLData |
| Limit line testing state | CALCulate[:SElected]:LIMit[:STATe] |
| Limit line testing annotation | CALCulate[:SElected]:LIMit:WARN |
| Read Pass / Fail | STATus:QUEStionable:LIMit:CONDition? |
| Build Limit from Trace | None |
| Markers | |
| Marker On/Off | CALCulate[:SElected]:MARKer[:STATe] |
| Activate a marker | CALCulate[:SElected]:MARKer:ACTivate |
| Markers - all off | CALCulate[:SElected]:MARKer:AOFF |
| Read BW data | CALCulate[:SElected]:MARKer:BWIDth:DATA |
| Marker search - BW / Q On/Off | CALCulate[:SElected]:MARKer:BWIDth[:STATe] |
| Markers - coupled | CALCulate[:SElected]:MARKer:COUPled |
| BW search value | CALCulate[:SElected]:MARKer:FUNcTION:BWIDth:THReshold |
| Marker search - Max | CALCulate[:SElected]:MARKer:FUNcTION:MAXimum |
| Marker search - Min | CALCulate[:SElected]:MARKer:FUNcTION:MINimum |
| Marker search - Peak excursion | CALCulate[:SElected]:MARKer:FUNcTION:PEXCursion |
| Marker search - Peak Next | CALCulate[:SElected]:MARKer:FUNcTION:PNEXt |
| Marker search - Peak threshold | CALCulate[:SElected]:MARKer:FUNcTION:PTHReshold |
| Marker search - Target | CALCulate[:SElected]:MARKer:FUNcTION:TARGet |
| Marker search - Wrap/No Wrap | CALCulate[:SElected]:MARKer:FUNcTION:TDIRection |
| Tracking On/Off | CALCulate[:SElected]:MARKer:FUNcTION:TRACKing |
| FieldFox setting => to marker location | CALCulate[:SElected]:MARKer:SET |
| Marker format | CALCulate[:SElected]:MARKer:FORMat |
| Marker => specified trace | CALCulate[:SElected]:MARKer:TRACe |
| Marker => specified X-axis location | CALCulate[:SElected]:MARKer:X |
| Read Marker Y-axis location | CALCulate[:SElected]:MARKer:Y? |
| Big Marker Display States (A and B) | |
| Enable Big marker readouts | DISPlay:MARKer:LARGE:STATe |

| | |
|--|---|
| Set font size | DISPlay:MARKer:LARGE:<x>:FONT |
| Set how the marker is displayed (norm / delta) | DISPlay:MARKer:LARGE:<x>:DEFine:LINE<n>:MARKer:STATe |
| Enable a readout line | DISPlay:MARKer:LARGE:<x>:DEFine:LINE<n>:STATe |
| Assign a marker number to the readout line | DISPlay:MARKer:LARGE:<x>:DEFine:LINE<n>:MNUMBER |
| Assign a trace number to the readout line | DISPlay:MARKer:LARGE:<x>:DEFine:LINE<n>:TNUMBER |
| Set format for the readout line | DISPlay:MARKer:LARGE:<x>:DEFine:LINE<n>:FORMat |
| Set marker tracking | DISPlay:MARKer:LARGE:<x>:DEFine:LINE<n>:TRACking |
| Set number of traces | DISPlay:MARKer:LARGE:<x>:TRACe:COUNT |
| Set measurement for the trace | DISPlay:MARKer:LARGE:<x>:DEFine:TRACe<n>:MEASurement |
| Set format for the trace | DISPlay:MARKer:LARGE:<x>:DEFine:TRACe<n>:FORMat |
| Enable bandwidth search | DISPlay:MARKer:LARGE:<x>:DEFine:TRACe<n>:BWIDth:STATe |
| Math | |
| Math function | CALCulate[:SElected]:MATH:FUNCTION |
| Data to Memory | CALCulate[:SElected]:MATH:MEMorize |
| Save / Recall Files - Data | |
| Save data trace to csv file | MMEMory:STORe:FDATa |
| Save SNP data | MMEMory:STORe:SNP[:DATA] |
| See other Save / Recall commands | |
| Send and read formatted measured data | CALCulate[:SElected]:DATA:FDATa |
| Send and read formatted memory data | CALCulate[:SElected]:DATA:FMEM |
| Send and read unformatted measured data | CALCulate[:SElected]:DATA:SDATa |
| Send and read unformatted memory data | CALCulate[:SElected]:DATA:SMEM |
| Set read format | FORMat[:DATA] |
| Port Extensions | |
| Enable | [:SENSe]:CORRection:EXTension[:STATe] |
| Set port 1 | [:SENSe]:CORRection:EXTension:PORT1 |

Set port 2 [\[:SENSe\]:CORRection:EXTension:PORT2](#)

Set velocity factor [\[:SENSe\]:CORRection:RVELocity:COAX](#)

Calibration

See Also

[Correction Methods Explained](#)

[Calibration Examples](#)

| | |
|--|---|
| Set and read error term data | [:SENSe]:CORRection:COEFFicient[:DATA] |
| Read number of cal steps | [:SENSe]:CORRection:COLLect:GUIDed:SCOunt |
| Measure step number | [:SENSe]:CORRection:COLLect:GUIDed:STFP:ACQuire |
| Prompt for step number | [:SENSe]:CORRection:COLLect:GUIDed:STEP:PRoMpt |
| Measure Quick Cal | [:SENSe]:CORRection:COLLect[:ACQuire]:INT |
| Measure load | [:SENSe]:CORRection:COLLect[:ACQuire]:LOAD |
| Measure open | [:SENSe]:CORRection:COLLect[:ACQuire]:OPEN |
| Measure short | [:SENSe]:CORRection:COLLect[:ACQuire]:SHORT |
| Measure thru | [:SENSe]:CORRection:COLLect[:ACQuire]:THRU |
| Set Cal Kit | [:SENSe]:CORRection:COLLect:CKIT:LABel |
| Catalog all cal kits | [:SENSe]:CORRection:COLLect:CKIT:LABel:CATalog? |
| Set connectors | [:SENSe]:CORRection:COLLect:CONNector |
| Select method - Enhanced Response | [:SENSe]:CORRection:COLLect:METHod:ERES |
| Select method - QuickCal | [:SENSe]:CORRection:COLLect:METHod:QCALibrate:CALibrate |
| Select method - QuickCal Enhanced Response | [:SENSe]:CORRection:COLLect:METHod:QCALibrate:ERESponse |
| Select method - Simple Open response | [:SENSe]:CORRection:COLLect:METHod[:RESponse]:OPEN |
| Select method - Simple Short response | [:SENSe]:CORRection:COLLect:METHod[:RESponse]:SHORT |
| Select method - Thru response | [:SENSe]:CORRection:COLLect:METHod[:RESponse]:THRU |
| Select method - Open response | [:SENSe]:CORRection:COLLect:METHod:ORESponse |
| Select method - Short response | [:SENSe]:CORRection:COLLect:METHod:SREResponse |
| Select method - 1-port SOLT | [:SENSe]:CORRection:COLLect:METHod:SOLT1 |
| Select method - TRL | [:SENSe]:CORRection:COLLect:METHod:TRL |

| | |
|---------------------------------|---|
| Read method | [:SENSe]:CORRection:COLLect:METhod:TYPE? |
| Set AutoOrient for ECal | [:SENSe]:CORRection:COLLect:ECAL:AORient |
| Set simple ECal | [:SENSe]:CORRection:COLLect:ECAL:SIMPLe |
| Omit Isolation | [:SENSe]:CORRection:COLLect:OISolation |
| Select Medium | [:SENSe]:CORRection:MEdium |
| Set Waveguide cutoff | [:SENSe]:CORRection:WGCutoff |
| Finish Cal | [:SENSe]:CORRection:COLLect:SAVE |
| Turn ALL Correction ON and OFF | [:SENSe]:CORRection[:STATe] |
| Turn User Correction ON and OFF | [:SENSe]:CORRection:USER[:STATe] |
| Set system impedance | [:SENSe]:CORRection:IMPedance[:INPut][:MAGNitude] |
| Set CalReady type | [:SENSe]:CORRection:CALReady:TYPE |
| Time Domain (Opt 010) | |
| Enable | CALCulate[:SElected]:TRANSform:TIME:STATe |
| Start time | CALCulate[:SElected]:TRANSform:TIME:START |
| Stop time | CALCulate[:SElected]:TRANSform:TIME:STOP |
| Center time | CALCulate[:SElected]:TRANSform:TIME:CENTer |
| Span time | CALCulate[:SElected]:TRANSform:TIME:SPAN |
| Lowpass or BandPass | CALCulate[:SElected]:TRANSform:TIME: [TYPE] |
| Step or Impulse | CALCulate[:SElected]:TRANSform:TIME:STIMulus |
| Step rise time | CALCulate[:SElected]:TRANSform:TIME:STEP:RTIME |
| Impulse width | CALCulate[:SElected]:TRANSform:TIME:IMPulse:WIDTH |
| Kaiser Bessel width | CALCulate[:SElected]:TRANSform:TIME:KBESsel |
| Set Lowpass freq. | CALCulate[:SElected]:TRANSform:TIME:LPFREQuency |
| Time Domain Gating | |
| Enable | CALCulate[:SElected]:FILTer[:GATE]:TIME:STATe |
| Start time | CALCulate[:SElected]:FILTer[:GATE]:TIME:START |
| Stop time | CALCulate[:SElected]:FILTer[:GATE]:TIME:STOP |
| Center time | CALCulate[:SElected]:FILTer[:GATE]:TIME:CENTer |
| Span time | CALCulate[:SElected]:FILTer[:GATE]:TIME:SPAN |
| Gating shape | CALCulate[:SElected]:FILTer[:GATE]:TIME:SHAPE |

Bandpass or notch

[CALCulate\[:SElected\]:FILTer\[:GATE\]:TIME](#)

Last Modified:

| | |
|-------------|------------------------------|
| 13-Nov-2013 | Added TRL command |
| 6-Mar-2013 | Added new commands (A.06.25) |
| 18-Oct-2012 | Added new commands (A.06.00) |

SA Mode Commands

In this topic:

- [Frequency](#)
- [Radio Standard](#)
- [Gain/Atten](#)
- [Sweep](#)
- [Scale/Units](#)
- [Average](#)
- [Video / Res Bandwidth](#)
- [Trace Type/Detector](#)
- [InstAlign](#)
- [Limit / Display Lines](#)
- [Markers](#)
- [Read / Save Data](#)
- [Independent Source / Tracking Generator](#)
- [Source Tracking Offset](#)
- [Field Strength \(Corrections\)](#)
- [Trigger Settings](#)
- [FFT Gating](#)
- [Record/Playback Actions](#)
- [Record/Playback Configuration](#)
- [Record/Playback Sessions](#)
- [Select Channel Measurement](#)
- [Read Current Channel Measurement Data](#)
- [Channel Measurement Setup](#)
- [Adjacent Channel Power Setup](#)
- [Interference Analyzer Settings](#)

- [Tune and Listen Settings](#)
- [General Status](#)

See Also

[Commands that are Common to All Modes](#)

Frequency

| Description | Command |
|-----------------------------|--|
| Center freq | [:SENSe]:FREQUency:CENTer |
| Step size for up/down keys | [:SENSe]:FREQUency:CENTer:STEP |
| Step size auto/manual | [:SENSe]:FREQUency:CENTer:STFP:AUTO |
| Freq span | [:SENSe]:FREQUency:SPAN |
| Span to full | [:SENSe]:FREQUency:SPAN:FULL |
| Span to zero | [:SENSe]:FREQUency:SPAN:ZERO |
| Start freq | [:SENSe]:FREQUency:START |
| Stop freq | [:SENSe]:FREQUency:STOP |
| Frequency annotation method | [:SENSe]:FREQUency:ANNOtation[:SElect] |

Radio Standard

| | |
|-----------------------|--|
| Channel number center | [:SENSe]:RADio:CHANnel:CENTer |
| Uplink or Downlink | [:SENSe]:RADio:CHANnel:DIRection |
| Start channel | [:SENSe]:RADio:CHANnel:START |
| Channel step size | [:SENSe]:RADio:CHANnel:STEP |
| Stop channel | [:SENSe]:RADio:CHANnel:STOP |
| Select standard | [:SENSe]:RADio:STANdard[:SElect] |
| Freq or Chan | [:SENSe]:RADio:TEUNit |

Gain/Atten

| | |
|-------------------------|--|
| Attenuation value | [:SENSe]:POWer[:RF]:ATTenuation |
| Atten Auto/Manual | [:SENSe]:POWer[:RF]:ATTenuation:AUTO |
| Set external gain value | [:SENSe]:POWer[:RF]:EXTGain |
| Preamp ON/OFF | [:SENSe]:POWer[:RF]:GAIN[:STATe] |
| Read number of traces. | [:SENSe]:QUANtity:TACTive? |

Sweep

| | |
|---------------------------|--|
| Sweep time (Non-zerospan) | [:SENSe]:SWFep:ACQuisition |
|---------------------------|--|

| | |
|--------------------------------|--|
| Sweep time (Zerospan) | [:SENSe]:SWEEp:TIME |
| Read sweep time | [:SENSe]:SWEEp:MTIME? |
| Auto / Manual | [:SENSe]:SWEEp:ACQuisition:AUTO |
| Sweep points | [:SENSe]:SWEEp:POINts |
| Sweep Type | [:SENSe]:SWEEp:TYPe |
| Reverse sweep (Opt. 209 only) | [:SENSe]:SWEEp:FREVerse |
| Scale / Units | |
| Auto Scale trace | DISPlay:WINDow:TRACe:Y[:SCALe]:AUTO |
| Per division | DISPlay:WINDow:TRACe:Y[:SCALe]:PDIVision |
| Reference level | DISPlay:WINDow:TRACe:Y[:SCALe]:RIEVeL |
| Reference position | DISPlay:WINDow:TRACe:Y[:SCALe]:RPOSiTion |
| Log / Linear Scale | [:SENSe]:AMPLitude:SCALe |
| Set Units | [:SENSe]:AMPLitude:UNIT |
| Read ONLY - Bottom scale value | DISPlay:WINDow:TRACe{1:4}:Y[:SCALe]:BOTTOm |
| Read ONLY - Top scale value | DISPlay:WINDow:TRACe{1:4}:Y[:SCALe]:TOP |
| Average | |
| Average count | [:SENSe]:AVERAge:COUNt |
| Averaging type | [:SENSe]:AVERAge:TYPe |
| Restart trace averaging | INITiate:REStArt |
| Video / Res Bandwidth | |
| Manual Res BW value | [:SENSe]:BANDwidth[:RESolution] |
| Choose Auto or Manual Res BW | [:SENSe]:BANDwidth[:RESolution]:AUTO |
| Manual Video BW value | [:SENSe]:BANDwidth:VIDeo |
| Choose Auto or Manual Video BW | [:SENSe]:BANDwidth:VIDeo:AUTO |
| IF Output | [:SENSe]:BANDwidth:IF:OUT |
| Trace Type/Detector | |
| Set Trace Type | TRACe{1:4}:TYPe |
| Detector function | [:SENSe]:DETEctor:FUNCTion |
| InstAlign | |
| InstAlign state | [:SENSe]:AMPLitude:ALIGNment[:STATe] |
| Align now | [:SENSe]:AMPLitude:ALIGNment:NOW |
| Limit / Display Lines | |

| | |
|-------------------------------|--|
| Limit line beep | CALCulate[:SElected]:LIMit:SOUNd |
| Create limit lines | CALCulate:LIMit:LLData |
| Limit line testing state | CALCulate:LIMit[:STATe] |
| Limit line testing annotation | CALCulate:LIMit:WARN |
| Display Line level setting | DISPlay:WINDow:TRACe:Y:DI LNe |
| Display Line state | DISPlay:WINDow:TRACe:Y:DI LNe:STATe |
| Read Pass/Fail | STATus:QUEStionable:LIMit:CONDition? |
| Build Limit from Trace | None |

Markers

| | |
|---|--|
| Select a marker | CALCulate[:SElected]:MARKer:ACTivate |
| Markers - all off | CALCulate[:SElected]:MARKer:AOff |
| Audio Beep on Marker | CALCulate:MARKer:AUDio:BEFP |
| Markers - Fixed delta reference marker state. | CALCulate:MARKer:DREF:FIXed |
| Frequency counter marker ON/OFF | CALCulate:MARKer:FCOunt[:STATe] |
| Read Frequency Count | CALCulate:MARKer:FCOunt:X? |
| Set Noise Marker and Band Power Marker | CALCulate:MARKer:FUNction |
| Band power span | CALCulate:MARKer:FUNction:BAND:SPAN |
| Band power mode | CALCulate:MARKer:FUNction:BAND:SPAN:AUTO |
| Interval power span | CALCulate:MARKer:FUNction:INTerval:SPAN |
| Interval power mode | CALCulate:MARKer:FUNction:INTerval:SPAN:AUTO |
| Marker search - Max | CALCulate:MARKer{1:6}:FUNction:MAXimum |
| Marker search - Min | CALCulate:MARKer{1:6}:FUNction:MINimum |
| Marker search - Peak excursion | CALCulate:MARKer{1:6}:FUNction:PEXCursion |
| Marker search - Peak left | CALCulate:MARKer{1:6}:FUNction:PLEFt |
| Marker search - Peak Next | CALCulate:MARKer{1:6}:FUNction:PNEXt |
| Marker search - Peak right | CALCulate:MARKer{1:6}:FUNction:PRIGHt |
| Marker search - Peak threshold | CALCulate:MARKer{1:6}:FUNction:PTHReshold |
| Noise marker On/Off | CALCulate:MARKer:NOISe[:STATe] |

| | |
|----------------------------------|---|
| Marker -> Setting | CALCulate:MARKer:SET |
| Move marker to center freq | CALCulate:MARKer:SET:CENTer |
| Move marker to ref level | CALCulate:MARKer:SET:REFLevel |
| Marker On/Off | CALCulate[:SElected]:MARKer[:STATe] |
| Move marker to other trace | CALCulate[:SElected]:MARKer:TRACe |
| Move/read marker X-axis position | CALCulate[:SElected]:MARKer:X |
| Read marker Y-axis position | CALCulate[:SElected]:MARKer:Y? |

Read / Save Data

See Also: [Read Current Channel Measurement Data](#)

| | |
|--------------------------|-------------------------------------|
| Read Trace Data | TRACe{1:4}:DATA |
| Saves trace to CSV file. | MMEMory:STORe:FDATa |

Independent Source / Tracking Generator

| | |
|--|--|
| Enable | SOURce:ENABle |
| CW or S/R | SOURce:MODE |
| CW Frequency | SOURce:FREQuency[:CW] |
| Normalize | SOURce:NORMAlize |
| Power Level (All models EXCEPT N9912A) | SOURce:POWer |
| Max Power (All models EXCEPT N9912A) | SOURce:POWer:MAXimum |
| Attenuation (power) N9912A ONLY | SOURce:POWer:ATTenuation |

Source Tracking Offset

| | |
|-------------------|--|
| Enable | SOURce:TOFFset:ENABle |
| Set frequency | SOURce:TOFFset:FREQuency |
| Reverse frequency | SOURce:TOFFset:REVerse |

Field Strength (Corrections)

| | |
|--------------------|--|
| All corrections ON | [:SENSe]:AMPLitude:CORRections[:STATe] |
|--------------------|--|

Receiver (or ONLY one) Antenna/Cables

| | |
|------------------------|--|
| Antenna corrections ON | [:SENSe]:AMPLitude:CORRections:ANTenna[:STATe] |
| Cable corrections ON | [:SENSe]:AMPLitude:CORRections:CABLe[:STATe] |
| Load Antenna file | MMEMory:LOAD:ANTenna |
| Store Antenna file | MMEMory:STORe:ANTenna |

| | |
|---------------------------------|--|
| Clear Antenna correction values | [:SENSe]:AMPLitude:CORRections:ANTenna:DEFault |
| Load Cable file | MMEMory:LOAD:CABLe |
| Store Cable file | MMEMory:STORe:CABLe |
| Clear Cable correction values | [:SENSe]:AMPLitude:CORRections:CABLe:DEFault |

Source Antenna/Cables

| | |
|---------------------------------|---|
| Antenna corrections ON | [:SENSe]:AMPLitude:CORRections:SANTenna[:STATe] |
| Cable corrections ON | [:SENSe]:AMPLitude:CORRections:SCABLe[:STATe] |
| Load Antenna file | MMEMory:LOAD:SANTenna |
| Store Antenna file | MMEMory:STORe:SANTenna |
| Clear Antenna correction values | [:SENSe]:AMPLitude:CORRections:SANTenna:DEFault |
| Load Cable file | MMEMory:LOAD:SCABLe |
| Store Cable file | MMEMory:STORe:SCABLe |
| Clear Cable correction values | [:SENSe]:AMPLitude:CORRections:SCABLe:DEFault |

Trigger Settings

| | |
|---|---|
| Trigger Type (Ext/Vid/RFBurst/Freerun) | TRIGger[:SEQuence]:SOURce |
| Trigger Slope (Pos/Neg) | TRIGger[:SEQuence]:SLOPe |
| Trigger Delay | TRIGger[:SEQuence]:DELay |
| Trigger Delay ON/OFF | TRIGger[:SEQuence]:DELay:STATe |
| Trigger Level | TRIGger[:SEQuence]:VIDeo:LEVel |
| Auto trigger time | TRIGger[:SEQuence]:ATRigger |
| Auto trigger ON/OFF | TRIGger[:SEQuence]:ATRigger:STATe |
| Trigger Position | TRIGger[:SEQuence]:POSition |
| Trigger Position ON/OFF | TRIGger[:SEQuence]:POSition:STATe |

FFT Gating

| | |
|--|---|
| Enable gating | TRIGger[:SEQuence]:FGATE[:STATe] |
| Set gate delay | TRIGger[:SEQuence]:FGATE:DELay |
| Display the gating window | TRIGger[:SEQuence]:FGATE:VIEW[:STATe] |
| Set X-axis time span for the gating window | TRIGger[:SEQuence]:FGATE:VIEW:TIME |
| Set the width of the gated area | TRIGger[:SEQuence]:FGATE:WIDTh |

within the gating window

Record/Playback Actions

| | |
|----------------|--|
| Pause | RECPlayback:ACTion:PAUSE |
| Play | RECPlayback:ACTion:PLAY |
| Record | RECPlayback:ACTion:RECORD |
| Tag position | RECPlayback:ACTion:SPOSITION |
| Stop | RECPlayback:ACTion:STOP |
| Trace position | RECPlayback:ACTion:TPOSITION |

Record/Playback Configuration

| | |
|-----------------------------------|---|
| Frequency Mask Trigger (FMT) data | RECPlayback:CONFig:FMTRigger:LLData |
| FMT enable | RECPlayback:CONFig:FMTRigger:ENABLE |
| Playback Time Interval | RECPlayback:CONFig:PTInterval |
| Record Segment Counting Length | RECPlayback:CONFig:RSCLength |
| Record Source | RECPlayback:CONFig:RSOURCE |
| Record Time Interval | RECPlayback:CONFig:RTInterval |
| Record Time limit | RECPlayback:CONFig:RTLSeconds |

Record/Playback Sessions

| | |
|--------------------|--|
| Clear all records | RECPlayback:SESSion:CARecords |
| Close | RECPlayback:SESSion:CLOSE |
| Create new session | RECPlayback:SESSion:NEW |
| Open session | RECPlayback:SESSion:OPEN? |
| Storage device | RECPlayback:SESSion:SDEVICE |
| Trace record limit | RECPlayback:SESSion:TRLimit |
| Is a session open? | STATus:OPERation:SAMode:CONDition? |

Select Channel Measurement

| | |
|---|---|
| All channel meas OFF | [:SENSe]:MEASurement:AOff |
| Select channel meas | [:SENSe]:MEASurement:CHANnel |
| Select Interference Analysis (Opt 236) display. | [:SENSe]:MEASurement:INTerference |
| Preset channel meas | [:SENSe]:MEASurement:PRESet |
| Tune and Listen demod type | [:SENSe]:MEASurement:TAListen |

Power percent for Occupied Bandwidth [\[:SENSe\]:OBW:PPOW](#)

Read Current Channel Measurement Data

Channel Power, Occupied Bandwidth, or Adjacent Channel Power

Read current channel measurement data [:CALCulate:MEASurement:DATA?](#)

Channel Measurement Setup

Averaging ON/OFF [\[:SENSe\]:CMEasurement:AVERage:ENABLE](#)

Integration BW [\[:SENSe\]:CMEasurement:IBW](#)

RCC filter state [\[:SENSe\]:CMEasurement:RRCFilter](#)

RCC filter value [\[:SENSe\]:CMEasurement:RRCFilter:ALPHA](#)

Adjacent Channel Power Setup

Reference value [\[:SENSe\]:ACPower:MREference](#)

Reference method [\[:SENSe\]:ACPower:MREference:AUTO](#)

Meas Type [\[:SENSe\]:ACPower:MTYPE](#)

Limit testing On/Off [\[:SENSe\]:ACPower:LIMit\[:STATe\]](#)

Offset bandwidths [\[:SENSe\]:ACPower:OFFSet:BWIDth](#)

Offset frequencies [\[:SENSe\]:ACPower:OFFSet:FREQuency](#)

Offset states [\[:SENSe\]:ACPower:OFFSet:STATe](#)

Lower offset limits [\[:SENSe\]:ACPower:OFFSet:LLIMit](#)

Upper offset limits [\[:SENSe\]:ACPower:OFFSet:ULIMit](#)

Interference Analyzer Settings

Blue power level [\[:SENSe\]:SPEctrogram:BPLevel](#)

Red power level [\[:SENSe\]:SPEctrogram:RPLLevel](#)

Time/Delta marker state [\[:SENSe\]:SPEctrogram:TMARker:STATe](#)

Time/Delta marker location [\[:SENSe\]:SPEctrogram:TMARker:VALue](#)

Spectrogram display setting [\[:SENSe\]:SPEctrogram:VIEW](#)

Waterfall angle [\[:SENSe\]:SPEctrogram:WANGLE](#)

Tune and Listen Settings

Volume [\[:SENSe\]:TAListen:AVOLume- OBSOLETE](#)

Demod ON / OFF [\[:SENSe\]:TAListen:DState](#)

Demod type [\[:SENSe\]:TAListen:DTYPE](#)

Listen time [\[:SENSe\]:TAListen:LTIME](#)

Tune freq [\[:SENSe\]:TAListen:TFReq](#)

General Status

ADC Over-range status [CALCulate:MEASurement:WAOR?](#)

Last Modified:

25-Mar-2014 Added new commands (A.06.25)

25-Mar-2014 Added new commands (A.06.00)

USB Power Meter Mode Commands

- [Core USB Power Meter commands](#)
- [FOPS-\(Option 208\) unique commands](#)

See Also

[Commands that are Common to All Modes](#)

[Pulse Measurements \(Option 330\) commands](#)

Core USB Power Meter commands

| Description | Command |
|--|---|
| Set relative Power Meter measurements | CALCulate:RELative[:MAGNitude]:AUTO |
| Performs external power meter zeroing. | CALibration:ZERO:TYPE:EXT |
| Set Minimum scale value | DISPlay[:WINDow]:ANALog:LOWer |
| Set Maximum scale value | DISPlay[:WINDow]:ANALog:UPPer |
| Set PM resolution | DISPlay[:WINDow][:NUMeric]:RESolution |
| Set number of sweep averages. | [:SENSe]:AVERage:COUNT |
| Set averaging mode | [:SENSe]:AVERage[:MODE] |
| Set Step Detection | [:SENSe]:AVERage:SDTEct |
| Set Offset value. | [:SENSe]:CORRection:GAIN2[:INPut][:MAGNitude] |
| Set Offset ON OFF state | [:SENSe]:CORRection:GAIN2:STATe |
| Set frequency | [:SENSe]:FREQUency |
| Read measurement data | [:SENSe]:TRACe[:DATA]? |

| | |
|--------------------------------------|--|
| Set the minimum (lower) limit value. | [:SENSe]:TRACe:LIMit:LOWer |
| Set the lower ON OFF State. | [:SENSe]:TRACe:LIMit:LOWer:STATe |
| Set the maximum (upper) limit value. | [:SENSe]:TRACe:LIMit:UPPer |
| Set the upper ON OFF State. | [:SENSe]:TRACe:LIMit:UPPer:STATe |
| Set Source Enable | SOURce:ENABle |
| Set Source power level | SOURce:POWer |
| Set PM units | UNIT:POWer |

FOPS (Option 208) unique commands

- [Normalization](#)
- [Setup](#)
- [Display Annotation and Scaling](#)
- [Markers](#)
- [Trace Math](#)

See Also: [Example Program](#)

Perform Normalization

There is NO unique FOPS command to MEASURE the source power.

Instead, use the following method:

1. Prompt to connect the power sensor to port 1 RF Output reference plane.
2. Send [INIT:CONT 0](#)
3. Send [INITiate\[:IMMediate\]](#)
4. Send [SOURce:POWer:MEMorize](#) to store the data trace to memory.
5. Send [\[:SENSe\]:TRACe:MEASurement](#) to display your measurement choice.

FOPS Setup

| Description | Command |
|-------------------------|---|
| Specify swept frequency | [:SENSe]:SWFep:TYPE |
| Center frequency | SOURce:FREQuency:CENTer |
| Frequency span | SOURce:FREQuency:SPAN |
| Start frequency | SOURce:FREQuency:START |
| Stop frequency | SOURce:FREQuency:STOP |
| Offset frequency | SOURce:RECeiver:OFFSet |

| | |
|---------------------------|---|
| Number of points | [:SENSe]:SWEep:POINts |
| Frequency step size | [:SENSe]:FREQuency:STEP |
| Set dwell time | [:SENSe]:POINt:DWELL |
| Receiver sweep direction | [:SENSe]:SWEep:RX |
| Power sensor tolerance | [:SENSe]:TOL |
| Max number of PS readings | [:SENSe]:POINt:READ:MAX |

Display Annotation and Scaling

| Description | Command |
|-----------------------------------|---|
| Grid ON/OFF | DISPlay:GRID |
| Method used to annotate frequency | DISPlay:ANNotation:FREQuency |
| Autoscale the trace | DISPlay:WINDow:TRACe{1:4}:Y[:SCALe]:AUTO |
| Scaling - per division | DISPlay:WINDow:TRACe{1:4}:Y[:SCALe]:PDIVision |
| Scaling - reference position | DISPlay:WINDow:TRACe{1:4}:Y[:SCALe]:RPOStion |
| Scaling - reference level | DISPlay:WINDow:TRACe{1:4}:Y[:SCALe]:RLFVeL |

Markers

| Description | Command |
|-----------------------|--|
| Select a marker | CALCulate[:SELected]:MARKer:ACTivate |
| Marker ON/OFF | CALCulate[:SELected]:MARKer[:STATe] |
| Move a marker | CALCulate[:SELected]:MARKer:X |
| Read marker amplitude | CALCulate[:SELected]:MARKer:Y? |
| Set marker to Max | CALCulate[:SELected]:MARKer:FUNction:MAXimum |
| Set marker to Min | CALCulate[:SELected]:MARKer:FUNction:MINimum |
| Amp. markers ON/OFF | CALCulate[:SELected]:AMPLitude:MARKer:STATe |
| Amp. marker 1 | CALCulate[:SELected]:AMPLitude:MARKer:Y1 Y |
| Amp. marker 2 | CALCulate[:SELected]:AMPLitude:MARKer:Y2 |

Delta Amp. markers ON/OFF [CALCulate\[:SElected\]:AMPLitude:MARKer:DELTA:STATE](#)

Trace Math

| Description | Command |
|------------------------------|--|
| Store a data trace to memory | CALCulate[:SElected]:MATH:MEMorize |
| Read data trace | CALCulate[:SElected]:TRACe:DATA |
| Read memory trace | CALCulate[:SElected]:FMEM:DATA? |
| Show Data /Mem trace | DISPlay:WINDow:TRACe |

Built-in Power Meter (CPM) Mode Commands

- [Frequency and Power](#)
- [Radio Standards](#)
- [Read Data](#)
- [InstAlign](#)
- [Display](#)
- [Limit Lines](#)

See Also

[Commands that are Common to All Modes](#)

Frequency and Power

| Description | Command |
|----------------------------|---|
| Set frequency | [:SENSe]:FREQuency |
| Step size for up/down keys | [:SENSe]:FREQuency:CENTer:STEP |
| Freq span | [:SENSe]:FREQuency:SPAN |
| Attenuation value | [:SENSe]:POWer[:RF]:ATTenuation |

Radio Standard

| | |
|-----------------------|--|
| Channel number center | [:SENSe]:RADio:CHANnel:CENTer |
| Uplink or Downlink | [:SENSe]:RADio:CHANnel:DIRection |
| Channel step size | [:SENSe]:RADio:CHANnel:STEP |
| Select standard | [:SENSe]:RADio:STANdard[:SElect] |

| | |
|--------------------------------------|---|
| Freq or Chan | [:SENSe]:RADio:TEUNit |
| Read Data | |
| Read measurement data | [:SENSe]:TRACe[:DATA]? |
| InstAlign | |
| InstAlign state | [:SENSe]:AMPLitude:ALIGNment[:STATe] |
| Align now | [:SENSe]:AMPLitude:ALIGNment:NOW |
| Display | |
| Display units | [:SENSe]:AMPLitude:UNIT |
| Set Minimum scale value | DISPlay[:WINDow]:ANALog:LOWer |
| Set Maximum scale value | DISPlay[:WINDow]:ANALog:UPPer |
| Set PM resolution | DISPlay[:WINDow][:NUMeric]:RESolution |
| Enable averaging | [:SENSe]:AVERage[:ENABLE] |
| Set number of sweep averages. | [:SENSe]:AVERage:COUNt |
| Make relative measurements | CALCulate:RELative[:MAGNitude]:AUTO |
| Set Offset value. | [:SENSe]:CORRection:GAIN2[:INPut][:MAGNitude] |
| Set Offset ON OFF state | [:SENSe]:CORRection:GAIN2:STATe |
| Limit Lines | |
| Set the minimum (lower) limit value. | [:SENSe]:TRACe:LIMit:LOWer |
| Set the lower ON OFF State. | [:SENSe]:TRACe:LIMit:LOWer:STATe |
| Set the maximum (upper) limit value. | [:SENSe]:TRACe:LIMit:UPPer |
| Set the upper ON OFF State. | [:SENSe]:TRACe:LIMit:UPPer:STATe |

Last Modified:

1-Apr-2014 Added CPM commands (A.07.50)

VVM Mode Commands

See Also:

[VVM Cable Trimming Example](#)

[Commands that are Common to All Modes](#)

| Description | Command |
|-------------|---------|
|-------------|---------|

| | |
|------------------------|--|
| Create measurement | CALCulate:PARAmeter:DEFine |
| Averaging | [:SENSe]:AVERAge:COUNT |
| Zeroing | [:SENSe]:CORRection:ZERO:STATe [:SENSe]:CORRection:ZERO:REFerence |
| Set frequency | [:SENSe]:FREQUency:CENTer |
| Read points (always 2) | [:SENSe]:SWFep:POINTs |
| Set power | SOURce:POWer |
| Read data | TRACe:DATA |
| IF Bandwidth | [:SENSe]:BWID |
| Resolution | DISPlay[:WINDow][:NUMeric]:RESolution |

Pulse Measurements (Option 330) Commands

The following commands are part of the USB Power Meter mode.

- [Select a Measurement / Trace](#)
- [Time / Frequency](#)
- [Average and Bandwidth Video](#)
- [Scale](#)
- [Display](#)
- [Trigger](#)
- [Markers](#)
- [Limits](#)
- [Read / Save Data](#)

See Also

[USB PM Mode Commands](#)

[Commands that are Common to All Modes](#)

Select a Measurement / Trace

| Description | Command |
|------------------|-------------------------------------|
| Set measurement. | CALCulate:FFFD:MODE |

Time / Frequency

| Description | Command |
|---------------------|--|
| Center time of zoom | CALCulate[:SELected]:TIME:AUX:CENTer |

window

| | |
|----------------------------|---|
| Time/div of zoom window | CALCulate[:SElected]:TIME:AUX:PDIVision |
| Center time of trace graph | CALCulate[:SElected]:TIME:CENTer |
| Span time of trace graph | CALCulate[:SElected]:TIME:LENGth |
| Time/div of trace graph | CALCulate[:SElected]:TIME:PDIVision |
| Start time of trace graph | CALCulate[:SElected]:TIME:START |
| Frequency of meas | [:SENSe]:FREQuency |
| Number of points | [:SENSe]:RESolution |

Average and Bandwidth Video

| Description | Command |
|--------------------------|--|
| Number of averages | [:SENSe]:AVERage:COUNT |
| Averaging Auto, Man, Off | [:SENSe]:AVERage[:MODE] |
| Step detection mode | [:SENSe]:AVERage:SDETect |
| Video bandwidth | [:SENSe]:BWIDth:VIDeo |

Scale

Meter = Meter-style only; **TG** = Trace Graph only; **Both** = Meter and Trace Graph

| Description | Command |
|-----------------------------------|---|
| Meter - Relative ON/OFF | CALCulate:RELative[:MAGNitude]:AUTO |
| Meter - Min Scale | DISPlay:WINDow:ANALog:LOWer |
| Meter - Max Scale | DISPlay:WINDow:ANALog:UPPer |
| Meter - Resolution | DISPlay:WINDow[:NUMeric]:RESolution |
| TG - Autoscale | None |
| TG - Scale | None |
| TG - Ref Lv | None |
| TG - Ref Pos | None |
| Both - Scale Offset ON/OFF | [:SENSe]:CORRection:GAIN2:STATe |
| Both - Scale Offset value | [:SENSe]:CORRection:GAIN2[:INPut][:MAGNitude] |

Display

| Description | Command |
|-------------|------------------------------|
| Grid ON/OFF | DISPlay:GRID |

| | |
|-------------------------|--|
| Marker Table ON/OFF | DISPlay:TABLE:MARKer |
| Auto Analysis ON/OFF | DISPlay:TABLE:RESults |
| Read Auto Analysis data | DISPlay:TABLE:RESults:DATA |
| Zoom window ON/OFF | DISPlay:WINDow:ZOOM |

Trigger

| Description | Command |
|-----------------------------|------------------------------------|
| Internal, External, Freerun | TRIGger:SOUrce |
| Trigger delay value | TRIGger:DFLay |
| Trigger level value | TRIGger:LEVel |
| Auto or Manual level | TRIGger:LEVel:AUTO |
| Pos or Neg edge | TRIGger:SLOPe |

Markers

| Description | Command |
|--------------------------------------|---|
| Select a marker | CALCulate[:SELected]:MARKer:ACTivate |
| Marker ON/OFF | CALCulate[:SELected]:MARKer[:STATe] |
| Move a marker | CALCulate[:SELected]:MARKer:X |
| Read marker amplitude | CALCulate[:SELected]:MARKer:Y? |
| Set markers to Falltime | CALCulate[:SELected]:MARKer:FUNction:FALLtime |
| Set markers to Risetime | CALCulate[:SELected]:MARKer:FUNction:RISetime |
| Set marker to Max | CALCulate[:SELected]:MARKer:FUNction:MAXimum |
| Set marker to Min | CALCulate[:SELected]:MARKer:FUNction:MINimum |
| Peak Excursion value | CALCulate[:SELected]:MARKer:FUNction:PEXCursion |
| Peak Threshold value | CALCulate[:SELected]:MARKer:FUNction:PTHReshold |
| Find Next Peak | CALCulate[:SELected]:MARKer:FUNction:PNEXT |
| Find Target value | CALCulate[:SELected]:MARKer:FUNction:TARGet |
| Marker search - Wrap/No Wrap | CALCulate[:SELected]:MARKer:FUNction:TDIRection |
| Set marker tracking | CALCulate[:SELected]:MARKer:FUNction:TRACKing |
| Search zoom window or primary trace. | CALCulate[:SELected]:MARKer:FUNction:ZONE |

| | |
|---------------------------|---|
| Delta Amp. markers ON/OFF | CALCulate[:SElected]:AMPLitude:MARKer:DELta:STATe |
| Amp. markers ON/OFF | CALCulate[:SElected]:AMPLitude:MARKer:STATe |
| Amp. marker 1 | CALCulate[:SElected]:AMPLitude:MARKer:Y1 Y |
| Amp. marker 2 | CALCulate[:SElected]:AMPLitude:MARKer:Y2 |
| Pulse top | [SENSe]:TRACe:MEASurement:REFerence |

Read / Save Data

| Description | Command |
|------------------------|---|
| Read trace graph data. | CALCulate[:SElected]:TRACe:DATA |
| Read Meter-style data | [:SENSe]:TRACe[:DATA]? |
| Save to *.csv file | MMEMory:STORe:FDATa |

Limits (Meter-style ONLY)

| Description | Command |
|-------------------|--|
| Lower limit value | [:SENSe]:TRACe:LIMit:LOWer |
| Lower limit state | [:SENSe]:TRACe:LIMit:LOWer:STATe |
| Upper limit value | [:SENSe]:TRACe:LIMit:UPPer |
| Upper limit state | [:SENSe]:TRACe:LIMit:UPPer:STATe |

ERTA Mode Commands

ONLY ERTA specific commands are shown here.

Use [SA Mode Commands](#) for all other relevant settings not listed here. For example, Frequency range and Tracking Offset commands.

| Description | Command |
|---|--|
| Set and query the partner network identity. New | [:SENSe]:MEASurement:ERTA:PNID |
| Verify the identified partner is ERTA capable. New | [:SENSe]:MEASurement:ERTA:PVERify? |
| Set ERTA stimulus-response role. | [:SENSe]:MEASurement:ERTA:ROLE? |
| Set and read Partnership status. | [:SENSe]:MEASurement:ERTA:PSTatus |
| Trace Receiver Input, valid during ERTA partnership | TRACe:ERTA:RINPut |

See Also

[Commands that are Common to All Modes](#)

Channel Scanner Mode (Option 312) Commands - Requires SA

In this topic:

- [Data](#)
- [Display](#)
- [Edit List](#)
- [Range](#)
- [Log and Recording](#)
- [File Commands](#)
- [Radio Standards](#)
- [Search Channels](#)
- [Channel Power](#)
- [Sweep](#)
- [SA Listen](#)
- Related [MMEMory commands](#)

See Also

[Commands that are Common to All Modes](#)

[Correction Methods Explained](#)

[New Programming Commands](#)

Data

Returns a set of values [:CHSCanner:DATA?](#)

Sets the folder path to Default or System [:CHSCanner:USER:FOLDer](#)

Display

Set freq and pow [:CHSCanner:DISPlay:SORT](#)

Set up and down sort order [:CHSCanner:DISPLAy:SORT:ORDer](#)

Set display window trace Y Pow division [:CHSCanner:DISPLAy:WINDow:TRACe:Y\[:SCALe\]:PDIVsion](#)

Set display window trace Y Ref level [:CHSCanner:DISPLAy:WINDow:TRACe:Y\[:SCALe\]:RLEVel](#)

Edit List

Returns a set of values [:CHSCanner:EDIT:LIST?](#)

Add comma separated list item [:CHSCanner:EDIT:LIST:ADD](#)

Clears all items from list [:CHSCanner:EDIT:LIST:CLear](#)

Range

| | |
|--|-----------------------------|
| Reads or writes items in Range mode | :CHSCanner:EDIT:RANGe:COUNT |
| Set integration bandwidth | :CHSCanner:EDIT:RNAGE:IBW |
| Set the freq span of items in Range mode | :CHSCanner:EDIT:RANGe:SPAN |
| Set CF of first channel defined in Range mode | :CHSCanner:EDIT:RANGe:START |
| Set freq separation between channels in Range mode | :CHSCanner:EDIT:RANGe:STEP |

Log and Recording

| | |
|--|--|
| Begin recording results | :CHSCanner:LOG:ACTion:RECOrd |
| Stop recording | :CHSCanner:LOG:ACTion:STOP |
| Read and writes the distance interval | :CHSCanner:LOG:CONFIgure:INTerval:DIStance |
| Enable or disable the measurement interval | :CHSCanner:LOG:CONFIgure:INTerval:STATe |
| Read and write the time interval | :CHSCanner:LOG:CONFIgure:INTerval:TIME |
| Set type of interval | :CHSCanner:LOG:CONFIgure:INTerval:TYPe |
| Enable or disable the log file auto-save | :CHSCanner:LOG:CONFIgure:SAVe:AUTO |
| Query the state | :CHSCanner:LOG[:STATe]? |

File Commands

| | |
|--|------------------------|
| Sets the user folder path to default or system | :CHSCanner:USER:FOLDer |
|--|------------------------|

Radio Standards

| | |
|--|---|
| Read a list of comma separated radio standards | :CHSCanner:RADio:STANdard:CATalog? |
| Set the integer start channel, from 1 to the last standard defined channel | :CHSCanner:RADio:STANdard:CHANnel:START |
| Set the step count used to skip some of the standard defined channels | :CHSCanner:RADio:STANdard:CHANnel:STEP |
| Set the name of the radio standard to scan | :CHSCanner:RADio:STANdard[:SElect] |

Search Channels

Set the number of channels to scan :CHSCanner:SEARch:COUNT

Set top or bottom number of channels :CHSCanner:SEARch:TYPe

Channel Power

Set the active channel :CHSCanner[:SENSe]:CHANnel:SElect

Set the RF attenuator value manually :CHSCanner[:SENSe]:POWer[:RF]:ATTenuation

Set the RF attenuator to Auto :CHSCanner[:SENSe]:POWer[:RF]:ATTenuation:AUTO

Set the external Gain :CHSCanner[:SENSe]:POWer[:RF]:EXTGain

Enable or disable the Gain state :CHSCanner[:SENSe]:POWer[:RF]:GAIN[:STATe]

Sweep

Set the averaging count :CHSCanner:SWEEp:AVERage:COUNT

Enable or Disable the averaging state :CHSCanner:SWEEp:AVERage[:STATe]

Set the displayed sweep type :CHSCanner:SWEEp:DISPlay:TYPE

Set the sweep mode :CHSCanner:SWEEp:MODE

SA Listen

Set SA Listen D type :CHSCanner[:SENSe]:SAListen:DTYPE

Set SA Listen L Time value :CHSCanner[:SENSe]:SAListen:LTIme

Pause data recording :CHSCanner[:SENSe]:SAListen:PAUSE

Resume date recording :CHSCanner[:SENSe]:SAListen:RESume

MMEMory comands - related to Channel Scanner

Save a CSV formatted file to Channel Scanner folder :MMEMory:STORe:LOG:CSV

Save a KML formatted file to Channel Scanner folder :MMEMory:STORe:LOG:KML

Load a *.csv or *.kml log file :MMEMory:LOAD:LOG

Load a *.csv custom list file :MMEMory:LOAD:LIST

Save a *csv custom list file :MMEMory:STATe:STORe:LIST

AM/FM Metrics (Option 355) Commands - Requires SA

In this topic:

- [Metrics](#)

See Also

[Commands that are Common to All Modes](#)

[Correction Methods Explained](#)

[New Programming Commands](#)

Metrics

| | |
|---|---|
| Set the AM/FM Metrics measurement type (Select 1 of <i>n</i> measurement choices) | <code>[:SENSe]:MEASurement:ADEMod</code> |
| Set the AM demodulation window's Y axis--top amplitude | <code>[:SENSe]:ADEMod:METRics:AMTY</code> |
| Select type of metrics AM FW wideband or narrow band | <code>[:SENSe]:ADEMod:METRics:DTYPE</code> |
| Set the FM demodulation window's Y axis--top amplitude | <code>[:SENSe]:ADEMod:METRics:FMTY</code> |
| Enables/disables the Audio ON or OFF while metrics enabled | <code>[:SENSe]:ADEMod:METRics:LON</code> |
| Sets the Listen time for the measurement | <code>[:SENSe]:ADEMod:METRics:LTIMe</code> |
| Enable display of Peak+ and Peak – in the demodulation window | <code>[:SENSe]:ADEMod:METRics:MMENable</code> |
| Sets the time span of the demodulation window | <code>[:SENSe]:ADEMod:METRics:STIMe</code> |
| Sets the Tune (Center) frequency | <code>[:SENSe]:ADEMod:METRics:TFRReq</code> |
| Returns 8 doubles of the AM measurement (query only) | <code>:DISPlay:ADEMod:METRics:AM:RESults:DATA?</code> |
| Returns 8 doubles of the FM measurement (query only) | <code>:DISPlay:ADEMod:METRics:FM:RESults:DATA?</code> |

Commands that are Common to All Modes

In this topic:

- [Lockout Front-Panel Operation](#)
- [Preset / User Preset](#)
- [Display Control](#)
- [Triggering](#)
- [Data Transfer Format and Order](#)

- [Catalog and Select Mode](#)
- [Mass Memory - Files](#)
- [External Reference Source](#)
- [Status Registers](#)
- [System](#)
- [Battery information](#)
- [GPS](#)
- [Voltage Source](#)
- [Power OFF / ON](#)
- [IEEE - Common Commands](#)

Notes:

- There is NO command to set the Security Level.
- There is NO command to set Startup Mode.
- There is NO commands to set Date/Time using Internet.

See Also

- [CAT Mode Commands](#)
- [NA Mode Commands](#)
- [PM Mode Commands](#)
- [SA Mode Commands](#)
- [VVM Mode Commands](#)
- [ERTA Mode Commands](#)
- [Pulse Measurements Mode Commands](#)

Lockout Front-Panel Operation

Lockout keypresses [INSTrument:GTR](#)

Return local control [INSTrument:GTL](#)

Preset / User Preset

Preset all modes to Factory settings. [SYSTem:PRESet](#)

Preset the current mode only to Factory settings. [SYSTem:PRESet:MODE](#)

Preset all modes to User settings. [SYSTem:UPReset](#)

Preset the current mode only to User settings. [SYSTem:UPReset:MODE](#)

Save User Preset settings [SYSTem:UPReset:SAVE](#)

Display Control

| Description | Command |
|-------------|--------------------------------|
| Display OFF | DISPlay:ENABLE |

| | |
|------------------------|---|
| Set brightness | DISPlay:BRIGhtness |
| Set date format | DISPlay:DATE:FMT |
| Change keywords | DISPlay:KEYWOrd[:DATA] |
| Reset default keywords | DISPlay:KEYWOrd:DEFault |
| Display marker table | DISPlay:TABLe:MARKer |
| Set time format | DISPlay:TIME:FMT |
| Set title string | DISPlay:TITLe:DATA |
| Display title | DISPlay:TITLe:STATe |

Triggering

| | |
|-----------------------|--------------------------------------|
| Continuous triggering | INITiate:CONTInuous |
| Single trigger | INITiate[:IMMediate] |

Data Transfer Format and Order

| | |
|------------|-------------------------------|
| Format | EORMat[:DATA] |
| Byte Order | EORMat:BORDER |

Catalog and Select Mode

| | |
|----------------------|-------------------------------------|
| Read available modes | INSTrument:CATalog? |
| Set mode | INSTrument[:SElect] |

Mass Memory - Files

| | |
|---------------------------------|-------------------------------------|
| Read files | MMEMory:CATalog? |
| Change folder | MMEMory:CDIRectory |
| Copy files | MMEMory:COpy |
| Read any file | MMEMory:DATA |
| Delete file | MMEMory:DELeTe |
| Recall an instrument state file | MMEMory:LOAD:STATe |
| Make a new folder | MMEMory:MDIRectory |
| Rename a file | MMEMory:MOVE |
| Remove a folder | MMEMory:RDIRectory |
| Save a picture file | MMEMory:STORe:IMAGe |
| Save an instrument state file | MMEMory:STORe:STATe |

See Also (Mode-specific MMEM commands)

| | |
|-----------------------------|-------------------------------------|
| Save data trace to csv file | MMEMory:STORe:FDATa |
|-----------------------------|-------------------------------------|

Save SNP data [MMEMory:STORe:SNP\[:DATA\]](#)

Recall antenna data [MMEMory:LOAD:ANTenna](#)

Recall cable data [MMEMory:LOAD:CABLe](#)

Save antenna data [MMEMory:STORe:ANTenna](#)

Recall cable data [MMEMory:STORe:CABLe](#)

External Reference Source

Set external reference source [\[:SENSe\]:ROSCillator:SOURce](#)

Read external source status [\[:SENSe\]:ROSCillator:STATus?](#)

Status Registers

Read RecordPlayback status [STATus:OPERation:SAMode:CONDition?](#)

Read external source status [STATus:QUEStionable:FREQuency:CONDition?](#)

Read ADC Overrange errors. [STATus:QUEStionable:INTegrity:CONDition?](#)

Read limit line failure [STATus:QUEStionable:LIMit:CONDition?](#)

Battery Information

Read presence of battery [SYSTem:BATTery](#)

Read absolute charge [SYSTem:BATTery:ABSCharge?](#)

Read average current flow [SYSTem:BATTery:ACURrent?](#)

Read remaining run time [SYSTem:BATTery:ARTTe?](#)

Read chemistry type [SYSTem:BATTery:CHEMistry?](#)

Read current flow [SYSTem:BATTery:CURREnt?](#)

Read number of charge cycles the battery has experienced [SYSTem:BATTery:CYCLes?](#)

Read manufacture date of the battery. [SYSTem:BATTery:DATE?](#)

Read capacity [SYSTem:BATTery:FCAPacity?](#)

Read accuracy of the battery gauge [SYSTem:BATTery:MAXError?](#)

Read manufacturer name [SYSTem:BATTery:MFGname?](#)

Read remaining battery capacity [SYSTem:BATTery:RCAPacity?](#)

Read current charge compared to full capacity [SYSTem:BATTery:RELCharge?](#)

Read remaining run time [SYSTem:BATTery:RTTE?](#)

| | |
|--|---|
| Set and read battery saver state. OFF leaves the source ON between sweeps. | SYSTem:BATTery:SAVer |
| Read serial number of the battery. | SYSTem:BATTery:SN? |
| Read use status | SYSTem:BATTery:STATUs |
| Read battery temperature | SYSTem:BATTery:TEMPerature? |
| Read vendor / distributor of the battery. | SYSTem:BATTery:VENdOr? |
| Read battery voltage. | SYSTem:BATTery:VOLTage? |

System

| | |
|--|---|
| Set and read the system date | SYSTem:DATE |
| Set and read the system time | SYSTem:TIME |
| Immediately erase all user data | SYSTem:ERASe |
| Read the FieldFox error queue | SYSTem:ERRor[:NEXT]? |
| Reset default preferences | SYSTem:PREFerences:DFLT |
| Save system preferences | SYSTem:PREFerences:SAVE |
| Set time zone. | SYSTem:TZONE |
| Catalog time zones. | SYSTem:TZONE:CATalog? |
| Set and read system volume | SYSTem:AUDio:VOLume |
| Set and read system volume mute state | SYSTem:AUDio:MUTE |
| Read the SCPI version | SYSTem:VERSion? |

GPS

| | |
|--|--|
| Set and read GPS ON OFF state. | SYSTem:GPS[:STATe] |
| Query returns a string containing Carrier to Noise (C/No dBHz) data. | SYSTem:GPS:CNOise? |
| Read the locked state. | SYSTem:GPS:LSTate? |
| Set and read the display state. | SYSTem:GPS:DISPlay:STATe |
| Set and read the clock sync state. | SYSTem:GPS:SYNChronize |
| Set and read the lat/long format. | SYSTem:GPS:DISPlay:COORDinate:FORMat |
| Set and read the distance units. | SYSTem:GPS:DISPlay:DISTance:UNIT |

Read the last locked reading. [SYSTem:GPS:DATA:LAST?](#)

Read the current GPS data [SYSTem:GPS:DATA?](#)

Voltage Source

Enable Voltage Source [SYSTem:VVS:ENABle](#)

Set voltage [SYSTem:VVS:VOLTagE](#)

Read state (On/ Off/ Tripped) [SYSTem:VVS:\[STATe\]?](#)

Read measured voltage [SYSTem:VVS:MVOLtage?](#)

Current draw [SYSTem:VVS:CURRent?](#)

Max current draw [SYSTem:VVS:MAXCurrent?](#)

Power OFF / ON

Automatically turns the FieldFox ON when power is applied. [SYSTem:PWR:AUTO](#)

Turns the FieldFox OFF [SYSTem:PWR:SHUTdown](#)

Sets delay before turning the FieldFox OFF. [SYSTem:PWR:SHUTdown:DLY](#)

Set time to wait before rebooting the FieldFox [SYSTem:PWR:SHUTdown:DUration](#)

Reads whether the DC supply is connected [SYSTem:DCSupply?](#)

IEEE - Common Commands

Clear status [*CLS](#)

Event Status Enable [*ESE](#)

Event Status Enable Query [*ESR?](#)

Identify [*IDN?](#)

Operation complete command [*OPC](#)

Operation complete query [*OPC?](#)

Identify Options Query [*OPT?](#)

Reset [*RST](#)

Wait [*WAI](#)

Last Modified:

17-Jul-2012 Added many commands (5.75)

1-Feb-2011 Added GPS (5.33)

Command Reference

New Programming Commands

The following is a list of new commands for each major release:

A.08.15 and A.09.15

AM/FM Metrics

[[:SENSe]:MEASurement:ADEMod
[:SENSe]:ADEMod:METRics:AMTY
[:SENSe]:ADEMod:METRics:DTYPe
[:SENSe]:ADEMod:METRics:FMTY
[:SENSe]:ADEMod:METRics:LON
[:SENSe]:ADEMod:METRics:LTIMe
[:SENSe]:ADEMod:METRics:MMENable
[:SENSe]:ADEMod:METRics:STIMe
[:SENSe]:ADEMod:METRics:TFRReq
:DISPlay:ADEMod:METRics:AM:RESults:DATA?
:DISPlay:ADEMod:METRics:FM:RESults:DATA?

Channel Scanner

:CHSCanner:DATA?
:CHSCanner:DISPlay:SORT
:CHSCanner:DISPlay:SORT:ORDer
:CHSCanner:DISPlay:WINDow:TRACe:Y[:SCALE]:PDIVision
:CHSCanner:DISPlay:WINDow:TRACe:Y[:SCALE]:RLEVEL
:CHSCanner:EDIT:LIST?
:CHSCanner:EDIT:LIST:ADD
:CHSCanner:EDIT:LIST:CLEAr
:CHSCanner:EDIT:RANGE:COUNT
:CHSCanner:EDIT:RANGE:IBW
:CHSCanner:EDIT:RANGE:SPAN
:CHSCanner:EDIT:RANGE:START
:CHSCanner:EDIT:RANGE:STEP
:CHSCanner:LOG:ACTion:RECORD
:CHSCanner:LOG:ACTion:STOP
:CHSCanner:LOG:CONFigure:INTerval:DISTance
:CHSCanner:LOG:CONFigure:INTerval:STATe
:CHSCanner:LOG:CONFigure:INTerval:TIMe
:CHSCanner:LOG:CONFigure:INTerval:TYPe
:CHSCanner:LOG:CONFigure:SAVE:AUTO

:CHSCanner:LOG[:STATe]
 :CHSCanner:RADio:STANdard:CATalog?
 :CHSCanner:RADio:STANdard:CHANnel:STARt
 :CHSCanner:RADio:STANdard:CHANnel:STEP
 :CHSCanner:RADio:STANdard[:SElect]
 :CHSCanner:SEARch:COUNT
 :CHSCanner:SEARch:TYPE
 :CHSCanner[:SENSe]:CHANnel:SElect
 :CHSCanner[:SENSe]:POWer[:RF]:ATTenuation
 :CHSCanner[:SENSe]:POWer[:RF]:ATTenuation:AUTO
 :CHSCanner[:SENSe]:POWer[:RF]:EXTGain
 :CHSCanner[:SENSe]:POWer[:RF]:GAIN[:STATe]
 :CHSCanner:SWEEp:AVERage:COUNT
 :CHSCanner:SWEEp:AVERage[:STATe]
 :CHSCanner:SWEEp:DISPlay:TYPE
 :CHSCanner:SWEEp:MODE
 :CHSCanner:USER:FOLDer
 :CHSCanner[:SENSe]:SAListen:DTYPE
 :CHSCanner[:SENSe]:SAListen:LTime
 :CHSCanner[:SENSe]:SAListen:PAUse
 :CHSCanner[:SENSe]:SAListen:RESume
 :MMEMory:STORe:LOG:CSV
 :MMEMory:STORe:LOG:KML
 :MMEMory:LOAD:LOG
 :MMEMory:LOAD:LIST
 :MMEMory:STATe:STORe:LIST

A.08.04

ERTA Mode

[\[:SENSe\]:MEASurement:ERTA:PNID](#)
[\[:SENSe\]:MEASurement:ERTA:PVERIFY?](#)

GPS Mode

[SYSTem:GPS:CNOise?](#)

A.08.00

All Modes

SYSTem:PREFerences:SNP

CAT Mode

[CALCulate\[:SElected\]:SMOothing:APERture](#)
[CALCulate\[:SElected\]:SMOothing\[:STATe\]](#)

CAT - TDR

[CALCulate:PARAmeter:DEFine](#)

CALCulate[:SElected]:MARKer:TDR:FORMat
[:SENSe]:SWEep:TDR:AUTO:FREQuency:STOP:MAXimum
[:SENSe]:SWEep:TDR:RES

NA Mode

CALCulate[:SElected]:OFFSet:SLOPe
CALCulate[:SElected]:OFFSet[:MAGNitude]

ERTA Mode

[:SENSe]:MEASurement:ERTA:PIP
[:SENSe]:MEASurement:ERTA:VIP?
[\[:SENSe\]:MEASurement:ERTA:ROLE?](#)
[\[:SENSe\]:MEASurement:ERTA:PSTatus](#)

TRACe:ERTA:RINPut

SA Mode

Source Tracking Offset

SOURce:TOFFset:ENABLE
SOURce:TOFFset:FREQuency
SOURce:TOFFset:REVerse

Reverse sweep (Opt. 209 only)

[:SENSe]:SWEep:FREVerse

Select freq axis annotation

[:SENSe]:FREQuency:ANNotation[:SElect]

Read ADC over-range status

CALCulate:MEASurement:WAOR?

Source-side corrections

MMEMory:LOAD:SANTenna
MMEMory:LOAD:SCABle
MMEMory:STORe:SANTenna
MMEMory:STORe:SCABle
[:SENSe]:AMPLitude:CORRections:SANTenna:DEFault
[:SENSe]:AMPLitude:CORRections:SANTenna[:STATe]
[:SENSe]:AMPLitude:CORRections:SCABle:DEFault
[:SENSe]:AMPLitude:CORRections:SCABle[:STATe]

A.07.75

All Modes

[INSTrument:GTL](#)

[INSTrument:GTR](#)

NA Mode

[Big Marker Display States \(A and B\)](#)

VVM Mode

[\[:SENSe\]:CORRection:ZERO:REFerence](#)

A.07.50

[Frequency Offset Power Sensor \(FOPS\) commands](#)

[Built-in Power Meter \(CPM\) Mode Commands](#)

[MMEMory:RDIRectory](#) - Added optional argument

SA Mode

[\[:SENSe\]:SWEp:MTIME?](#)

Renamed commands:

[SOURce:ENABle](#)

[SOURce:FREQUency\[:CW\]](#)

[SOURce:MODE](#)

[SOURce:NORMalize](#)

[SOURce:POWer](#)

[SOURce:POWer:MAXimum](#)

NA Mode

[CALCulate:PARAmeter:DEFine](#) (New arguments)

[CALCulate\[:SELected\]:CONVersion:FUNCTION](#)

CAT Mode

[\[:SENSe\]:CORRection:WAVeguide:STANdard](#)

CAT and NA Mode

[\[:SENSe\]:CORRection:COLLect:METHod:SRESponse](#)

[\[:SENSe\]:CORRection:COLLect:METHod:ORESponse](#)

A.07.25

Pulse Measurement Mode Commands

CAT and NA modes

[\[:SENSe\]:CORRection:COLLect:CKIT:LABel](#) <ECal module>

[\[:SENSe\]:CORRection:COLLect:ECAL:AORient](#)

[\[:SENSe\]:CORRection:COLLect:ECAL:SIMPlE](#)

[\[:SENSe\]:CORRection:COLLect:METHod:TRL](#)

[\[:SENSe\]:CORRection:COLLect:OISolation](#)

[\[:SENSe\]:CORRection:MEDIum](#)

[\[:SENSe\]:CORRection:WGCutoff](#)

SA Mode

[CALCulate:MARKer:TZERo:FIXed](#)

USB Power Meter Mode

[SOURce:ENABle](#)

[SOURce:POWer](#)

Common to ALL Modes

[FORMat:BORDER](#)

User Preset

[SYSTem:UPReset](#)

[SYSTem:UPReset:FPANel\[:STATe\]](#)

[SYSTem:UPReset:MODE](#)

[SYSTem:UPReset:SAVE](#)

A.07.00

NA mode

[TRIGger:SOURce](#)

[TRIGger:SLOPe](#)

[CALCulate\[:SElected\]:MARKer:FORMat](#)

SA mode

[TRIGger\[:SEquence\]:SOURce](#) (New argument)

[CALCulate:MEASurement:QAMplitude](#)

[\[:SENSe\]:BURSt:ALIGnment:NOW](#)

[\[:SENSe\]:BURSt:ALIGnment\[:STATe\]](#)

[TRIGger\[:SEquence\]:POSition](#)

[TRIGger\[:SEquence\]:POSition:STATe](#)

[TRIGger\[:SEquence\]:DELay:STATe](#)

[TRIGger\[:SEquence\]:FGATe:DELay](#)

[TRIGger\[:SEquence\]:FGATe:VIEW:TIME](#)

[TRIGger\[:SEquence\]:FGATe:VIEW\[:STATe\]](#)

[TRIGger\[:SEquence\]:FGATe:WIDTh](#)

[TRIGger\[:SEquence\]:FGATe\[:STATe\]](#)

Multiple modes

[CALCulate\[:SElected\]:LIMit:SOUNd](#)

A.06.17

Multiple modes

[SYSTem:PWR:AUTO](#)

[SYSTem:DCSupply?](#)

CAT / NA mode

[\[:SENSe\]:CORRection:CALReady:TYPE](#)

[\[:SENSe\]:CORRection:COLLect:GUIDed:STEP:ACQuire](#)

[\[:SENSe\]:CORRection:COLLect:GUIDed:SCOUNt](#)

[\[:SENSe\]:CORRection:COLLect:GUIDed:STEP:PROMpt](#)

A.06.00

Multiple modes

[CALCulate:LIMit:LLData](#)

[STATus:QUEStionable:LIMit:CONDition?](#)

[SYSTem:VVS:CURRent?](#)

[SYSTem:VVS:ENABle](#)

[SYSTem:VVS:MAXCurrent?](#)

[SYSTem:VVS:MVOLtage?](#)

[SYSTem:VVS\[:STATe\]?](#)

[SYSTem:VVS:VOLTag](#)

[SYSTem:DCSupply?](#)

NA mode

[\[:SENSe\]:AVERage:MODE](#)

Time Domain Transform

[CALCulate\[:SELected\]:FILTer\[:GATE\]:TIME:CENTer](#)

[CALCulate\[:SELected\]:FILTer\[:GATE\]:TIME:SHAPE](#)

[CALCulate\[:SELected\]:FILTer\[:GATE\]:TIME:SPAN](#)

[CALCulate\[:SELected\]:FILTer\[:GATE\]:TIME:START](#)

[CALCulate\[:SELected\]:FILTer\[:GATE\]:TIME:STATe](#)

[CALCulate\[:SELected\]:FILTer\[:GATE\]:TIME:STOP](#)

[CALCulate\[:SELected\]:FILTer\[:GATE\]:TIME\[:TYPE\]](#)

[CALCulate\[:SELected\]:TRANSform:TIME: \[TYPE\]](#)

[CALCulate\[:SELected\]:TRANSform:TIME:CENTer](#)

[CALCulate\[:SELected\]:TRANSform:TIME:IMPulse:WIDTh](#)

[CALCulate\[:SELected\]:TRANSform:TIME:KBFSsel](#)

[CALCulate\[:SELected\]:TRANSform:TIME:LPFRequency](#)

[CALCulate\[:SELected\]:TRANSform:TIME:SPAN](#)

[CALCulate\[:SELected\]:TRANSform:TIME:START](#)

[CALCulate\[:SELected\]:TRANSform:TIME:STATe](#)

[CALCulate\[:SELected\]:TRANSform:TIME:STEP:RTIME](#)

[CALCulate\[:SELected\]:TRANSform:TIME:STIMulus](#)

[CALCulate\[:SELected\]:TRANSform:TIME:STOP](#)

CAT mode

[CALCulate:PARAmeter:SELect](#)

[DISPlay:WINDow:SPLit](#)

[CALCulate:MARKer:COUPLE](#)

SA mode

[[:SENSe](#)]:[AMPLitude](#):[CORRections](#):[ANTenna](#):[DEFault](#)

[[:SENSe](#)]:[AMPLitude](#):[CORRections](#):[CABLe](#):[DEFault](#)

[[:SENSe](#)]:[AMPLitude](#):[ALIGnment](#)[[:STATe](#)]

[[:SENSe](#)]:[AMPLitude](#):[ALIGnment](#):[NOW](#)

[[:SENSe](#)]:[BANDwidth](#):[IF](#):[OUT](#)

Power Meter Mode

[[:SENSe](#)]:[AVERage](#):[SDFTe](#)[ct](#)

A.05.50

[DISPlay](#):[WINDow](#):[TRACe](#):[Y](#):[DLINe](#) <level>

[DISPlay](#):[WINDow](#):[TRACe](#):[Y](#):[DLINe](#):[STATe](#) <ON/OFF>

[CALCulate](#):[MARKer](#):[BWIDth](#):[DATA](#)

[CALCulate](#):[MARKer](#):[BWIDth](#)[[:STATe](#)]

[CALCulate](#):[MARKer](#):[FUNCTion](#):[BWIDth](#):[THReshold](#)

[CALCulate](#):[MARKer](#):[FUNCTion](#):[TRACking](#)

[CALCulate](#):[MARKer](#):[FUNCTion](#):[TARGet](#)

[SYSTem](#):[AUDio](#):[MUTE](#)

[SYSTem](#):[AUDio](#):[VOLume](#)

[[:SENSe](#)]:[RADio](#):[STANdard](#)[[:SElect](#)]

[[:SENSe](#)]:[AVERage](#):[Cl Ear](#)

A.05.30

[CALCulate](#):[MARKer](#):[FUNCTion](#)

[CALCulate](#):[MARKer](#):[FUNCTion](#):[BAND](#):[SPAN](#)

[CALCulate](#):[MARKer](#):[FUNCTion](#):[BAND](#):[SPAN](#):[AUTO](#)

[CALCulate](#):[MARKer](#):[SET](#)

[CALCulate](#)[[:SElected](#)]:[SMOothing](#):[APERture](#)

[CALCulate](#)[[:SElected](#)]:[SMOothing](#)[[:STATe](#)]

[DISPlay](#)[[:WINDow](#)][[:NUMeric](#)]:[RESolution](#)

[[:SENSe](#)]:[BWID](#)

[[:SENSe](#)]:[CORRection](#):[EXTension](#):[PORT1](#)

[[:SENSe](#)]:[CORRection](#):[EXTension](#):[PORT2](#)

[[:SENSe](#)]:[CORRection](#):[EXTension](#)[[:STATe](#)]

[[:SENSe](#)]:[ISource](#):[ENABLE](#)

[[:SENSe](#)]:[ISource](#):[FREQuency](#)[[:CW](#)]

[[:SENSe](#)]:[ISource](#):[MODE](#)

[[:SENSe](#)]:[ISource](#):[POWER](#)

[SYSTem](#):[TZONE](#)

[SYSTem:TZONe:CATalog?](#)

Replacement Commands

The following is a list of commands that have been replaced.

Superseded Commands

Superseded commands will continue to work in existing programs. However, the replacement command usually has more functionality and is recommended.

| Superseded command | Replacement command |
|---|---|
| CALCulate:MARKer:NOISe[:STATe] | CALCulate:MARKer:FUNCTion |
| RECPlayback:CONFig:FMTRigger:DATA | RECPlayback:CONFig:FMTRigger:LLData |
| CALCulate[:SElected]:LIMit:DATA | CALCulate:LIMit:LLData |
| CALCulate[:SElected]:LIMit:BEEP | CALCulate[:SElected]:LIMit:SOUNd |

OBSOLETE commands

These commands will NOT continue to work in existing programs.

| Obsolete command | Replacement command |
|---|--|
| | |
| | |
| [:SENSe]:TAlisten:AVOLume (A.05.50) | SYSTem:AUDio:VOLume |
| [:SENSe]:RADio:STANdard (A.05.50) | [:SENSe]:RADio:STANdard[:SElect] |

Last Modified:

5-Aug-2011 New topic (A.05.50)

Common Commands

The following IEEE 488.2 Common Commands can be used with the FieldFox:

*CLS

Clears the instrument status byte by emptying the error queue and clearing all event registers. Also cancels any preceding *OPC command or query.

*ESE - Event Status Enable

Sets bits in the standard event status enable register.

***ESE? - Event Status Enable Query**

Returns the results of the standard event enable register. The register is cleared after reading it.

***ESR? - Event Status Enable Register**

Reads and clears event status enable register.

***IDN? - Identify**

Returns a string that uniquely identifies the FieldFox. The string is of the form "Agilent Technologies", <model number>, <serial number>, <software revision> and so forth.

***OPC - Operation complete command**

Generates the OPC message in the standard event status register when all pending overlapped operations have been completed (for example, a sweep, or a Default).

***OPC? - Operation complete query**

Returns an ASCII "+1" when all pending overlapped operations have been completed.

***OPT? - Identify Options Query**

Returns a string identifying the analyzer option configuration.

***RST - Reset**

Executes a device reset and cancels any pending *OPC command or query. All trigger features in HOLD. The contents of the FieldFox non-volatile memory are not affected by this command.

***SRE - Service Request Enable**

Before reading a status register, bits must be enabled. This command enables bits in the service request register. The current setting is saved in non-volatile memory.

***SRE? - Service Request Enable Query**

Reads the current state of the service request enable register. The register is cleared after reading it.

***WAI - Wait**

Prohibits the instrument from executing any new commands until all pending overlapped commands have been completed.

CALCulate:FEED:MODE <char>

(Read-Write) Set and query the current measurement.

Relevant Modes

Parameters [Pulse Measurements](#)

<char> Measurement parameter. Choose from:

PEAK - Peak (Meter-style)

AVER - Average (Meter-style)

PTAV - Peak to Average (Meter-style)

TMOD - Trace Graph mode

Examples CALC:FEED:MODE AVER

Query Syntax CALCulate:FEED:MODE?

Return Type Character

Default PEAK

Last Modified:

30-Oct-2013 New command

CALCulate:IREJection:LEVel <char>

(Read-Write) Set and query the Interference rejection level.

Relevant Modes CAT

Parameters

<char> Interference rejection level. Choose from:
 OFF – no interference rejection.
 LEV1 – level 1
 LEV2 – level 2
 LEV3 – level 3

Examples **CALC:IREJ:LEV LEV1**

Query Syntax CALCulate:IREJection:LEVel?

Return Type Character

Default OFF

Last Modified:

1-Aug-2011 New command

CALCulate:MARKer:AUDio:BEEP <bool>

(Read-Write) Set or return the state of an Audio Beep on the active SA mode marker. Audio Beep ON creates a marker if not already ON. Set beep volume using [SYSTem:AUDio:VOLume <num>](#).

Relevant Modes SA

Parameters

<bool> Choose from:
 ON (or 1) - Audio beep ON
 OFF (or 0) - Audio beep OFF

Examples **CALC:MARK:AUD:BEEP ON**

Query Syntax CALCulate:MARKer:AUDio:BEEP?

Return Type Boolean

Default Off

Last Modified:

1-Aug-2011 New command (A.05.50)

CALCulate:MARKer<n>:DREF:FIXed <bool>

(Read-Write) Set and query the state of fixed delta / reference markers. Created delta markers using [CALCulate:MARKer\[:STATe\]](#)

Relevant Modes SA

Parameters

<n> Existing marker to fix or let float. Choose from 1 to 6.

<bool> Choose from:

OFF or 0 - Reference marker floats with each sweep at the Y-axis position of the data trace

ON or 1 - Reference marker is fixed at the Y-axis position of the data trace when the marker was created.

Examples **CALC:MARK2:DREF:FIX OFF**

Query Syntax CALCulate:MARKer<n>:DREF:FIXed?

Return Type Boolean

Default ON

CALCulate:MARKer<n>:FCOunt[:STATe] <bool>

(Read-Write) Set and query the Frequency counter marker ON/OFF state.

Use [CALCulate:MARKer\[:STATe\]](#) to first create a marker.

Use [CALCulate:MARKer:X](#) to move the marker to the frequency of interest.

Use [CALCulate:MARKer:FCOunt:X?](#) to read the frequency counter marker.

Relevant Modes SA

Parameters

<n> Marker number to become a frequency counter marker. A marker is created if not already ON. Choose from 1 to 6. If unspecified, value is set to 1.

<bool> Frequency counter marker state. Choose from:

ON (or 1) - Frequency counter marker ON.

OFF (or 0) - Frequency counter marker OFF.

Examples **CALC:MARK2:FCO 1**

Query Syntax CALCulate:MARKer<n>:FCOunt?
Return Type Boolean
Default OFF

Last Modified:

20-Oct-2010 New command (5.30)

CALCulate:MARKer:FCOunt:X?

(Read-only) Read the frequency of the frequency counter marker in Hz. Use [CALCulate:MARKer:FCOunt\[:STATe\]](#) to make a marker a frequency counter marker.

Relevant Modes SA

Parameters None

Examples CALC:MARK:FCO:X?

Return Type Numeric

Default N/A

Last Modified:

20-Oct-2010 New command (5.30)

CALCulate:MARKer<n>:FUNCTion <char>

(Read-Write) Causes the specified marker to become one of the SA Marker functions. Also causes the specified marker to be turned ON if it is not already.

Relevant Modes SA

Parameters

<n> Existing marker to become a marker function. Choose from 1 to 6.

<char> Marker function. Choose from:

OFF - Marker is returned to it's previous state (normal or delta).

NOISe - Marker becomes a noise marker.

BPOWer - Marker becomes a Band/Interval Power marker.

For non-zero span measurements, a Band Power marker integrates total power over the Band Power Span, which is set using:

- [CALCulate:MARKer:FUNCTion:BAND:SPAN](#) and
- [CALCulate:MARKer:FUNCTion:BAND:SPAN:AUTO](#).

For Zero-span measurements, an Interval Power marker calculates the average power over the Interval Power Span, which is set using:

- [CALCulate:MARKer:FUNCTION:BAND:SPAN](#) and
- [CALCulate:MARKer:FUNCTION:BAND:SPAN:AUTO](#).

Examples `CALC:MARK1:FUNC NOIS`

Query Syntax `CALCulate:MARKer<n>:FUNCTION?`

Default OFF

Last Modified:

19-Oct-2010 New command (5.30)

CALCulate:MARKer:FUNCTION:BAND:SPAN <num>

(Read-Write) Set and read the frequency span for ALL SA mode Band Power Markers.

Set [CALCulate:MARKer:FUNCTION:BAND:SPAN:AUTO](#) to OFF.

Relevant Modes SA

Parameters

<num> Band power markers frequency span in Hz. Choose a value equal to or less than the FieldFox frequency span.

Examples `CALC:MARK:FUNC:SPAN 1e6` *'Set span to 1 MHz'*

Query Syntax `CALCulate:MARKer:FUNCTION:BAND:SPAN?`

Default 5% of existing frequency span.

Last Modified:

19-Oct-2010 New command (5.30)

CALCulate:MARKer:FUNCTION:BAND:SPAN:AUTO <bool>

(Read-Write) Set and read the method by which the frequency span for ALL SA mode Band Power Markers is set.

Relevant Modes SA

Parameters

<bool> Band power frequency span method.
ON (or 1) - Band Power frequency span is always 5% of existing frequency span.
OFF (or 0) - Set Band Power frequency span using

[CALCulate:MARKer:FUNCTION:BAND:SPAN](#)

Examples `CALC:MARK:FUNC:BAND:SPAN:AUTO 1`

Query Syntax `CALCulate:MARKer<n>:FUNCTION:BAND:SPAN:AUTO?`

Default ON

Last Modified:

19-Oct-2010 New command (5.30)

CALCulate:MARKer:FUNCTION:INTERval:SPAN <num>

(Read-Write) Set and read the time interval for ALL SA mode Interval Markers.

Set [CALCulate:MARKer:FUNCTION:INTERval:SPAN:AUTO](#) to OFF.

Relevant Modes SA

Parameters

<num> Interval span in seconds. Choose a value between 1e-9 and 100 seconds.

Examples `CALC:MARK:FUNC:INT:SPAN 1e-3 'Set span to 1 mSec`

Query Syntax `CALCulate:MARKer:FUNCTION:INTERval:SPAN?`

Default 5% of existing X-axis span.

Last Modified:

19-Oct-2010 New command (5.30)

CALCulate:MARKer:FUNCTION:INTERval:SPAN:AUTO <bool>

(Read-Write) Set and read the method by which the time span for ALL SA mode Interval Markers is set.

Relevant Modes SA

Parameters

<bool> Interval span method.
ON (or 1) - Interval time span is always 5% of X-axis.
OFF (or 0) - Set Interval time span using
[CALCulate:MARKer:FUNCTION:INTERval:SPAN](#)

Examples `CALC:MARK:FUNC:INT:SPAN:AUTO 1`

Query Syntax `CALCulate:MARKer<n>FUNCTION:INTERval:SPAN:AUTO?`

Default ON

Last Modified:

19-Oct-2010 New command (5.30)

CALCulate:MARKer<n>:FUNCtion:PLEft

(Write-Only) Causes the specified marker to find the next data point to the left that meets the 'Peak' criteria. When no data points to the left meet the Peak criteria, the marker does not move.

Relevant Modes SA

Parameters

<n> New or existing marker to move. Choose from 1 to 6.

Examples **CALC : MARK1 : FUNC : PLEF**

Query Syntax Not Applicable

Default Not Applicable

CALCulate:MARKer<n>:FUNCtion:PRIGht

(Write-Only) Causes the specified marker to search to the right of the current location for the next data point that meets the 'Peak' criteria.

Relevant Modes SA

Parameters

<n> New or existing marker to move. Choose from 1 to 6.

Examples **CALC : MARK1 : FUNC : PRIG**

Query Syntax Not Applicable

Default Not Applicable

CALCulate:MARKer<n>:NOISe[:STATe] <bool> - Superseded

Note: This command is replaced with [CALCulate:MARKer:FUNCtion](#).

(Read-Write) Set and query the ON|OFF state of the SA noise marker. A marker must first be created. This command then converts it to a Noise marker.

Relevant Modes SA

Parameters

- <n> Existing marker to make a noise marker. Choose from 1 to 6.
- <bool> Choose from:
OFF - Noise marker OFF
ON - Noise marker ON

Examples `CALC:MARK:NOIS ON`

Query Syntax `CALCulate:MARKer:NOISe:[STATe]?`

Return Type Boolean

Default OFF

CALCulate:MARKer<n>:SET:CENTer

(Write-Only) The center frequency of the measurement becomes the value of the specified marker. The frequency span is adjusted accordingly.

`CALCulate[:SElected]:MARKer:SET` performs the same operation.

Relevant Modes SA

Parameters

- <n> Existing marker from which the center frequency will be set. Choose from 1 to 6.

Examples `CALC:MARK1:SET:CENT`

Query Syntax Not Applicable

Default Not Applicable

CALCulate:MARKer<n>:SET:REFLevel

(Write-Only) The reference level of the current window becomes the value of the specified marker.

`CALCulate[:SElected]:MARKer:SET` performs the same operation.

Relevant Modes SA

Parameters

- <n> Existing marker for which reference level will be set. Choose from 1 to 6.

Examples `CALC:MARK1:SET:REFL`

Query Syntax Not Applicable

Default Not Applicable

CALCulate:MARKer:TZERO:FIXed <bool>

(Read-Write) Set and query the ON|OFF state of the Time Zero Fixed setting.

This feature was created to allow recall of vintage instrument states (older than Rev. 7.0) that included Zero span sweep with a trigger delay and at least one marker. Before Rev. 7.0, these instrument states were saved and recalled with the equivalent of the ON state of this setting.

Relevant Modes SA

Parameters

<bool> Choose from:
OFF - Time zero fixed setting OFF
ON - Time zero fixed setting ON

Examples **CALC:MARK:TZER:FIX ON**

Query Syntax CALCulate:MARKer:TZERo:FIXed?

Return Type Boolean

Default OFF

Last Modified:

2-Apr-2014 New command

CALCulate:MEASure:DATA?

(Read-Only) Reads data from the current channel measurement (Channel Power, Occupied Bandwidth, or Adjacent Channel Power).

- The number of values that are returned depends on the type of channel measurement.
- The units for the values depend on the currently displayed units.
- Offsets that are not defined return invalid data.

Data is returned in the following format:

Main channel - main channel power in dBm.

Main channel - main channel Power Spectral Density (PSD) in dBm/Hz.

Main channel - relative power to main channel power (this value is always zero).

Lower Offset Frequency (1) - channel power for lower offset 1 in dBm.

Lower Offset Frequency (1) - PSD for lower offset 1 in dBm/Hz.

Lower Offset Frequency (1) - relative power of lower ACPR for offset 1 in dBc or dB.

Upper Offset Frequency (1) - channel power for upper offset 1 in dBm.

Upper Offset Frequency (1) - PSD for upper offset 1 in dBm/Hz.

Upper Offset Frequency (1) - relative power of upper ACPR for offset 1 in dBc or dB.

Lower Offset Frequency (2) - channel power for lower offset 2 in dBm.

Lower Offset Frequency (2) - PSD for lower offset 2 in dBm/Hz.

Lower Offset Frequency (2) - relative power of lower ACPR for offset 2 in dBc or dB.

Upper Offset Frequency (2) - channel power for upper offset 2 in dBm.

Upper Offset Frequency (2) - PSD for upper offset 2 in dBm/Hz.

Upper Offset Frequency (2) - relative power of upper ACPR for offset 2 in dBc or dB.

Lower Offset Frequency (3) - channel power for lower offset 3 in dBm.

Lower Offset Frequency (3) - PSD for lower offset 3 in dBm/Hz.

Lower Offset Frequency (3) - relative power of lower ACPR for offset 3 in dBc or dB.

Upper Offset Frequency (3) - channel power for upper offset 3 in dBm.

Upper Offset Frequency (3) - PSD for upper offset 3 in dBm/Hz.

Upper Offset Frequency (3) - relative power of upper ACPR for offset 3 in dBc or dB.

Relevant Modes SA

Examples The following data is returned for an ACPR channel measurement.

Offsets that are not defined return invalid data.

CALC:MEAS:DATA?

'With only one defined offset, returns

```
-6.73047890E+01,-1.303150890E+02,0.0000000E+00,
-6.78255554E+01,-1.308358553E+02,-5.207664E-01,
-6.77824583E+01,-1.307927583E+02,-4.776693E-01,
-9.876543210E+04,-9.393939111E+06,-9.876543210E+04,
-9.876543210E+04,-9.393939111E+06,-9.876543210E+04,
-9.876543210E+04,-9.393939111E+06,-9.876543210E+04,
-9.876543210E+04,-9.393939111E+06,-9.876543210E+04
```


Return Type Block data
Default Not Applicable

Last Modified:

18-May-2011 Modified description text

CALCulate:MEASurement:QAMPLitude?

(Read-Only) Returns the current Amplitude Alignment (InstAlign) status.

Relevant Modes SA

Examples CALC:MEAS:QAMP?

Return Type Boolean

0 - Alignment is current

1 - Alignment is questionable because Amplitude Alignment is in Hold or OFF.

See [\[:SENSe\]:AMPLitude:ALIGNment\[:STATE\]](#)

Default Not Applicable

Last Modified:

28-Mar-2013 New command

:CALCulate:PARAmeter:COUNT <n>

(Read-Write) Sets and returns the number of traces on the screen. All traces are displayed in separate windows. Use [DISPlay:WINDow:SPLit](#) to set overlay (traces in same window) configurations.

Change the measurement parameter using [CALCulate:PARAmeter:DEFine](#).

Relevant Modes NA

Parameters

<n> Number of traces.
 For NA mode, choose from 1 to 4.

Examples CALC:PAR:COUNT 2

Query Syntax CALCulate:PARAmeter:COUNT?

Default 1

Last Modified:

15-Aug-2012 New command

CALCulate:PARAmeter<tr>:DEFine <char>

(Read-Write) Set and query the current measurement.

Relevant Modes CAT, NA, VVM

Parameters

<tr> Trace number (NA mode ONLY). Choose from 1 to 4. Choices 2, 3, 4 require that the appropriate multi-trace configuration first be created using [:DISPlay:WINDow:SPLit](#).

All other modes, do NOT specify.

<char> Measurement parameter. Choose from:

For CAT Mode:

- **RLOSs** - Return Loss
- **DTF1** - Distance To Fault
- **DTF2** - DTF + Return Loss
- **DTF3** - DTF (VSWR)
- **DTF4** - DTF Linear
- **CLOSs** - Cable loss 1 port
- **ILOSs** - 2-port Insertion loss
- **VSWR** - SWR

Available ONLY with Opt. 215

- **TDR** - Linear Rho
- **STEP** - TDR Ohm

For NA Mode:

Reverse measurements are available ONLY with full S-parameter option.

- **S11** - Forward reflection measurement
- **S21** - Forward transmission measurement
- **S12** - Reverse transmission
- **S22** - Reverse reflection
- **A** - A receiver measurement
- **B** - B receiver measurement
- **R1** - Port 1 reference receiver measurement
- **R2** - Port 2 reference receiver measurement

Available ONLY with Opt. 212

- **SCC11** - Common reflect/common incident for logical port 1
- **SDD11** - Differential reflect/differential incident for logical port 1
- **SDC11** - Differential reflect/common incident for logical port 1.
- **SCD11** - Common reflect/differential incident for logical port 1.

For VVM Mode:

- **S11** - 1-port cable trimming
- **S21** - 2-port transmission
- **AB** A/B ratio (NOT available on N9912A)
- **BA** B/A ratio (NOT available on N9912A)

Examples CALC:PAR:DEF DTF2
 'NA mode
 CALC:PAR2:DEF S21

Query Syntax CALCulate:PARAmeter<tr>:DEFine?

Return Type Character

Default Cat Mode: S11
 NA Mode: S11 (trace 1)
 VVM Mode:S11

Last Modified:

| | |
|-------------|-------------------------|
| 22-Jan-2015 | Added Opt 215 |
| 24-Mar-2014 | Added Opt 212 |
| 16-Jul-2013 | Edited VVM mode choices |
| 18-Oct-2012 | Edited for new models |

:CALCulate:PARAmeter<tr>:SELEct

(Write-only) Select (make active) the current trace. You can only select a displayed trace. For CAT and NA, change the measurement parameter using [CALCulate:PARAmeter:DEFine](#).

Relevant Modes CAT, NA

Parameters

<tr> Trace number.
 For NA mode, choose from 1 to 4.
 For CAT and Pulse modes, choose from 1 or 2.

Examples CALC:PAR2:SEL

Query Syntax Not Applicable

Default 1

Last Modified:

| | |
|-------------|-------------------------|
| 26-Apr-2012 | Modified for CAT (5.75) |
|-------------|-------------------------|

CALCulate:RELative[:MAGNitude]:AUTO <bool>

(Read-Write) Set and query state of relative Power Meter measurements.

Relevant Modes [Power Meter](#), [Pulse Measurements](#), [CPM](#)

Parameters

<bool> Choose from:
0 or **OFF** - Relative measurements OFF
1 or **ON** - Relative measurements ON

Examples CALC:REL:AUTO 1

Query Syntax CALCulate:RELative[:MAGNitude]:AUTO?

Return Type Boolean

Default 0

Last Modified:

1-Apr-2014 Added CPM

31-Oct-2013 Added Pulse

CALCulate[:SElected]:AMPLitude:MARKer:DELTA:STATe <bool>

(Read-Write) Set or query the state of the Delta Amplitude Markers. To be used as Delta markers, Amplitude Markers must first be enabled using [CALCulate\[:SElected\]:AMPLitude:MARKer:STATe](#).

Relevant Modes [Pulse Measurements](#), [FOPS](#)

Parameters

<bool> Choose from:
OFF or **0** - Delta Amplitude markers OFF
ON or **1** - Delta Amplitude markers OFF

Examples **CALC:AMPL:MARK:DELT:STAT 1**

Query Syntax CALCulate[:SElected]:AMPLitude:MARKer:DELTA STATE?

Return Type Boolean

Default Off

Last Modified:

21-Mar-2014 Added FOPS
29-Oct-2013 New command

CALCulate[:SElected]:AMPLitude:MARKer:STATe <bool>

(Read-Write) Set or query the state of the two Amplitude Markers.

Relevant Modes [Pulse Measurements](#), [FOPS](#)

Parameters

<bool> Choose from:
OFF or 0 - Amplitude markers OFF
ON or 1 - Amplitude markers OFF

Examples **CALC:AMPL:MARK:STAT 1**

Query Syntax CALCulate[:SElected]:AMPLitude:MARKer:STATe?

Return Type Boolean

Default Off

Last Modified:

21-Mar-2014 Added FOPS
29-Oct-2013 New command

CALCulate[:SElected]:AMPLitude:MARKer:Y1 <num>

(Read-Write) Set or query the Y-axis location of the Amplitude Marker 1.

Relevant Modes [Pulse Measurements](#), [FOPS](#)

Parameters

<num> Y-axis location in dBm.

Examples **CALC:AMPL:MARK:Y1 -1.5**

Query Syntax CALCulate[:SElected]:AMPLitude:MARKer:Y1?

Return Type Numeric

Default 0

Last Modified:

21-Mar-2014 Added FOPS
29-Oct-2013 New command

CALCulate[:SElected]:AMPLitude:MARKer:Y2 <num>

(Read-Write) Set or query the Y-axis location of the Amplitude Marker 2.

Relevant Modes [Pulse Measurements](#), [FOPS](#)

Parameters

<num> Y-axis location in dBm.

Examples `CALC:AMPL:MARK:Y2 -1.5`

Query Syntax CALCulate[:SElected]:AMPLitude:MARKer:Y2?

Return Type Numeric

Default 0

Last Modified:

21-Mar-2014 Added FOPS

29-Oct-2013 New command

CALCulate[:SElected]:CONVersion:FUNctIon <char>

(Read-Write) Set and query measurement conversion function for the selected measurement.

First select a measurement using [CALCulate:PARAmeter:SElect](#).

Relevant Modes NA

Parameters

- <char> Conversion function. Choose from:
- OFF** - No conversion
 - ZAUTO** - The displayed S-parameter is converted to the appropriate Z parameter: Refl for S11 and S22; Trans for S21 and S12.
 - YAUTO** - The displayed S-parameter is converted to the appropriate Y parameter: Refl for S11 and S22; Trans for S21 and S12.
 - ZREflection** - The displayed S-parameter is converted to Z reflection, regardless of whether the S-parameter is reflection (S11 or S22) or transmission (S21 or S12).
 - YREflection** - The displayed S-parameter is converted to Y reflection, regardless of whether the S-parameter is reflection (S11 or S22) or transmission (S21 or S12)
 - ZTRansmissio** - The displayed S-parameter is converted to Z transmission, regardless of whether the S-parameter is reflection (S11 or S22) or transmission (S21 or S12).
 - YTRansmissio** - The displayed S-parameter is converted to Y transmission, regardless of whether the S-parameter is reflection (S11 or S22) or transmission (S21 or S12).
 - INVersion** - The displayed S-parameter is converted to 1/S-parameter.

Examples **CALC:CONV:FUNC ZAUT**

Query Syntax CALCulate[:SElected]:CONVersion:FUNction?

Return Type Character

Default OFF

Last Modified:

25-Mar-2014 New command (A.07.50)

CALCulate[:SElected]:CORRection:EDELay:TIME <num>

(Read-Write) Set and query the electrical delay for the selected trace. Use [CALCulate:PARAmeter:SElect](#) to select a trace.

Relevant Modes NA

Parameters

<num> Electrical Delay in seconds. Choose a value between 0 and 10 seconds.

Examples **CALC:CORR:EDEL:TIME 5e-10**

Query Syntax CALCulate[:SElected]:CORRection:EDELay:TIME?

Return Type Numeric

Default 0

Last Modified:

19-Oct-2010 New command (5.30)

CALCulate[:SElected]:CORRection:OFFSet:PHASe <num>

(Read-Write) Set and query the phase offset for the selected trace. Use [CALCulate:PARAmeter:SElect](#) to select a trace.

Relevant Modes NA

Parameters

<num> Phase offset in degrees. Choose a value between 0 and 360 degrees.

Examples **CALC:CORR:OFFS:PHAS 20**

Query Syntax CALCulate[:SElected]:CORRection:OFFSet:PHASe?

Return Type Numeric

Default 0

Last Modified:

19-Oct-2010 New command (5.30)

CALCulate[:SElected]:DATA:FDATa <data>

(Write-Read) Send and read the selected trace data in the current display format - one value per data point. Undefined behavior for Smith or Polar formats.

Select a trace with [CALCulate:PARAmeter:SElect](#)

Set format with [CALCulate:FORMat](#)

Relevant Modes NA

CAT - Read-only

Parameters

<data> Comma-separated data to send.

Examples **'send three data points**

CALC:DATA:FDAT 1,1,1

Query Syntax CALCulate[:SElected]:DATA:FDATa?

If correction is ON, then the returned data is corrected.

Return Type Comma-separated numeric

Default Not Applicable

CALCulate[:SElected]:DATA:FMEM <data>

(Write-Read) Send and read the selected memory trace data in the current display format - one value per data point.

Select a trace with [:CALCulate:PARAmeter:SFLect](#)

Set format with [CALCulate:FORMat](#)

Relevant Modes NA

Parameters

<data> Comma-separated data to send.

Examples `'send three data points
CALC:DATA:FMEM 1,1,1`

Query Syntax CALCulate[:SElected]:DATA:FMEM?

A memory trace must first be stored using [CALCulate:MATH:MEMorize](#)

If correction is ON, then the returned data is corrected.

Return Type Comma-separated numeric

Default Not Applicable

CALCulate[:SElected]:DATA:SDATA <data>

(Write-Read) Send and read the selected trace data - unformatted - two values per data point (Real, Imaginary).

Select a trace with [:CALCulate:PARAmeter:SFLect](#)

Relevant Modes NA

Parameters

<data> Comma-separated data to send.

Examples `'send three data points
CALC:DATA:SDAT 1,1,1`

Query Syntax CALCulate[:SElected]:DATA:SDATA?

If correction is ON, then the returned data is corrected.

If imaginary data is not available, 0 is returned.

Return Type Comma-separated numeric

Default Not Applicable

CALCulate[:SElected]:DATA:SMEM <data>

(Write-Read) Send and read the selected memory trace data - unformatted - two value per data point (Real, Imaginary).

Select a trace with [:CALCulate:PARAmeter:SElect](#)

Relevant Modes NA

CAT - Read-only

Parameters

<data> Comma-separated data to send.

Examples `'send three data points`

`CALC:DATA:SMEM 1,1,1`

Query Syntax CALCulate[:SElected]:DATA:SMEM?

A memory trace must first be stored using [CALCulate:MATH:MEMorize](#)

If correction is ON, then the returned data is corrected.

If imaginary data is not available, 0 is returned.

Return Type Comma-separated numeric

Default Not Applicable

CALCulate[:SElected]:FILTer[:GATE]:TIME:CENTer <num>

(Read-Write) Set and query the gate filter center time.

Relevant Modes ~~NA~~

Parameters

<num> Center time in seconds. Choose any number between: \pm (number of points-1) / frequency span.

Examples `CALC:FILT:TIME:CENT 1e-9`

Query Syntax CALCulate[:SElected]:FILTer[:GATE]:TIME:CENTer?

Return Type Numeric

Default 0

Last Modified:

24-Jan-2012

New command

CALCulate[:SElected]:FILTer[:GATE]:TIME:SHAPE <char>

(Read-Write) Set and query the gating filter shape.

Relevant Modes [NA](#)

Parameters

<char> Choose from
MAXimum - the widest gate filter available
WIDE -
NORMal -
MINimum - the narrowest gate filter available

Examples CALC:FILT:TIME:SHAP NORM

Query Syntax CALCulate[:SElected]:FILTer[:GATE]:TIME:SHAPE?

Return Type Character

Default NORMal

Last Modified:

25-Jan-2012 New command

CALCulate[:SElected]:FILTer[:GATE]:TIME:SPAN <num>

(Read-Write) Set and query the gate filter span time.

Relevant Modes [NA](#)

Parameters

<num> Span time in seconds. Choose any number between:
0 and $2 * [(number\ of\ points - 1) / frequency\ span]$

Examples CALC:FILT:TIME:SPAN 5ns

Query Syntax CALCulate[:SElected]:FILTer[:GATE]:TIME:SPAN?

Return Type Numeric

Default 20 ns

Last Modified:

24-Jan-2012 New command

CALCulate[:SElected]:FILTer[:GATE]:TIME:START <num>

(Read-Write) Set and query the gate filter start time.

Relevant Modes [NA](#)

Parameters

<num> Start time in seconds. Choose any number between:
± (number of points-1) / frequency span

Examples CALC:FILT:TIME:START 5ns

Query Syntax CALCulate[:SElected]:FILTer[:GATE]:TIME:START?

Return Type Numeric

Default 10 ns

Last Modified:

24-Jan-2012 New command

CALCulate[:SElected]:FILTer[:GATE]:TIME:STATe <bool>

(Read-Write) Set and query the ON | OFF gating state for the active trace. Select a trace using [CALCulate:PARAmeter:SElect](#).

Relevant Modes [NA](#)

Parameters

<bool> Gating state. Choose from:
0 or OFF - Gating is OFF
1 or ON - Gating is ON

Examples CALC:FILT:TIME:STAT 1

Query Syntax CALCulate[:SElected]:FILTer[:GATE]:TIME:STATe?

Return Type Boolean

Default OFF

Last Modified:

24-Jan-2012 New command

CALCulate[:SElected]:FILTer[:GATE]:TIME:STOP <num>

(Read-Write) Set and query the gate filter Stop time.

Relevant Modes [NA](#)

Parameters

<num> Stop time in seconds. Choose any number between:
± (number of points-1) / frequency span

Examples CALC:FILT:TIME:STOP 5ns

Query Syntax CALCulate[:SElected]:FILTer[:GATE]:TIME:STOP?

Return Type Numeric

Default 10 ns

Last Modified:

24-Jan-2012 New command

CALCulate[:SElected]:FILTer[:GATE]:TIME[:TYPE] <char>

(Read-Write) Set and query the gate filter type.

Relevant Modes [NA](#)

Parameters

<char> Choose from:
BPASs - Includes (passes) the range between the start and stop times.
NOTCh - Excludes (attenuates) the range between the start and stop times.

Examples CALC:FILT:TIME BPAS

Query Syntax CALCulate[:SElected]:FILTer[:GATE]:TIME[:TYPE]?

Return Type Character

Default BPAS

Last Modified:

25-Jan-2012 New command

CALCulate:[SElected]:FMEM:DATA?

(Read-only) Read the data from a memory trace. A memory trace must first be stored using [CALCulate\[:SElected\]:MATH:MEMorize](#).

Relevant Modes [FOPS](#)

Parameters None

Examples **CALC : FMEM : DATA ?**

Return Type Numeric

Default Not Applicable

Last Modified:

21-Mar-2014 New command

CALCulate[:SElected]:FORMat <char>

(Read-Write) Set and query displayed data format of the NA mode measurement.

Relevant Modes NA

Parameters

<char> Data format. Choose from:

- MLOGarithmic** – Log magnitude
- MLINear** – Linear magnitude
- SWR** – Standing Wave Ratio
- PHASe** - Phase in degrees. The trace wraps every 360 degrees, from +180 to – 180
- UPHase** - Unwrapped phase in degrees.
- SMITH** – Smith chart; series resistance and reactance.
- POLar** - Magnitude and phase of the reflection coefficient.
- GDELay** – Group delay (N9912A - S11 ONLY)
- ZMAG** - Impedance, magnitude only.
- REAL** - Resistive portion of the measured complex data.
- IMAGinary** - Reactive portion of the measured data.

Examples **CALC:FORMat SWR**

Query Syntax CALCulate[:SElected]:FORMat?

Return Type Character

Default Depends on model and measurement.

Last Modified:

22-Sep-2014 Added Real, imag, Zmag

1-Aug-2011 Added unwrapped phase (A.05.50)

CALCulate[:SElected]:LIMit:BEEP <bool> - Superseded

This command is replaced with [CALCulate\[:SElected\]:LIMit:SOUNd](#). Learn about [superseded commands](#).

(Read-Write) Set and query whether the FieldFox beeps when a limit line failure occurs.

For NA and CAT mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Relevant Modes CAT, NA, SA

Parameters

<bool> Beep state. Choose from:
OFF - No beeping
ON - Beep on Fail

Examples **CALC:LIM:BEEP ON**

Query Syntax CALCulate[:SElected]:LIMit:BEEP?

Return Type Boolean

Default OFF

Last Modified:

16-Apr-2013 Replaced (6.25)

CALCulate[:SElected]:LIMit:DATA <data> - Superseded

This command is replaced with [CALCulate:LIMit:LLData](#) which can also set Relative Limits.

(Read-Write) Set and query the data to complete the limit line table.

For NA and CAT mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

For **ACP** measurements, use [CALCulate:ACPower:OFFSet:LIST:LIMit:NEGative\[:UPPer\]:DATA](#) and [CALCulate:ACPower:OFFSet:LIST:LIMit:POSitive\[:UPPer\]:DATA](#).

Relevant Modes SA, CAT, NA

Parameters

<data> Data for all limit segments in the following format:

- **n** = number of segments, followed by segment data.
- each segment: **State, Type, BegStim, EndStim, BegResp, EndResp**
- Where:

| | |
|----------------|--|
| State | 0 for limit line disabled 1 for limit line enabled. |
| Type | Type of limit segment. Choose from 0 - Upper limit 1 - Lower limit |
| BegStim | Start of X-axis value (freq, power, time) |
| EndStim | End of X-axis value |
| BegResp | Y-axis value that corresponds with Start of X-axis value |
| EndResp | Y-axis value that corresponds with End of X-axis value |

Subsequent segments are appended to the data in the same manner.

Examples **' The following writes three upper limit segments for a 40 MHz bandpass filter.**
' individual segments are highlighted for readability.
CALC:LIM:DATA 3,1,0,2e7,3e7,-
30,0,1,0,3e7,5e7,0,0,1,0,5e7,6e7,0,-30

Query Syntax CALCulate:LIMit:DATA?

Return Type Block data

Default 0 - Limit line data off

CALCulate[:SElected]:LIMit:LLData <data>

This command replaces [CALCulate:LIMit:DATA](#) which can be used ONLY with Fixed limit lines. This command can also be used with Relative Limit Lines.

(Read-Write) Set and query the data to complete the limit line table.

For NA and CAT mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

For ACP measurements, use [CALCulate:ACPower:OFFSet:LIST:LIMit:NEGative\[:UPPer\]:DATA](#) and [CALCulate:ACPower:OFFSet:LIST:LIMit:POSitive\[:UPPer\]:DATA](#).

Relevant Modes SA, CAT, NA

Parameters

- <data> Data for all limit segments in the following format:
- **n** = number of segments, followed by segment data.
 - Where:
 - <nL>** number of limit line segments to follow
 - State** 0 - limit line disabled
1 - limit line enabled.
 - Fixed/Rel** 0 - Relative
1 - Fixed
 - Upper/Lower** 0 - Upper limit
1 - Lower limit
 - <nP>** Number of points to follow
 - Freq value** X-axis value
 - Amp value** Y-axis value

Subsequent points are appended to the data in the same manner.

Examples 'The following writes one relative, upper limit segment with 4 points for a 40 MHz bandpass filter.
'Blue-shaded numbers are values for one segment.
'following are X/Y points
CALC:LIM:LLDATA 1,1,0,0,4,-30e6,-20,-20e6,-10,-10e6,0,10e6,0,20e6,-10,30e6,-20

Query Syntax CALCulate[:SElected]:LIMit:LLData?

Return Type Block data

Default 0 - Limit line data off

Last Modified:

17-Jul-2012 New command

CALCulate[:SElected]:LIMit:SOUND <char>

Note: This command replaces [CALCulate\[:SElected\]:LIMit:BEEP](#).

(Read-Write) Set and query the conditions with which the FieldFox beep occurs during limit line testing.

For NA and CAT mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Relevant Modes CAT, NA, SA

Parameters

<char> Beep state. Choose from:

OFF - No beeping

OPASS - Beep on Pass

OFAil - Beep on Fail

Examples **CALC:LIM:SOUN OPA**

Query Syntax CALCulate[:SElected]:LIMit:SOUNd?

Return Type Character

Default OFF

Last Modified:

16-Apr-2013

New command (6.25)

CALCulate[:SElected]:LIMit[:STAtE]

(Read-Write) Set and query whether limit testing occurs.

For NA and CAT mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Relevant Modes CAT, NA, SA

Parameters

<bool> Testing state. Choose from:

0 or **OFF** - No limit line testing

1 or **ON** - Do limit line testing

Examples **CALC:LIM ON**

Query Syntax CALCulate[:SElected]:LIMit[STAtE]?

Return Type Boolean

Default OFF

CALCulate[:SElected]:LIMit:WARN <bool>

(Read-Write) Set and query whether the Pass and Fail warning is displayed on the FieldFox screen.

For NA and CAT mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Relevant Modes CAT, NA, SA

Parameters

<bool> Testing state. Choose from:

0 or OFF- Do NOT display onscreen warning.

1 or ON - Display onscreen warning.

Examples **CALC:LIM:WARN ON**

Query Syntax CALCulate[:SElected]:LIMit:WARN?

Return Type Boolean

Default OFF

CALCulate[:SElected]:MARKer<n>:ACTivate

(Write-Only) Makes the selected marker active.

For NA and CAT mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Relevant Modes CAT, NA, SA, [Pulse Measurements](#), [FOPS](#)

Note: SA mode does NOT recognize the optional [:SElected] node.

Parameter

<n> Marker number to activate. Each trace can contain up to six markers.

Examples **CALC:MARK2:ACTivate**

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

| | |
|-------------|-------------|
| 20-Mar-2014 | Added FOPS |
| 29-Oct-2013 | Added Pulse |
| 16-Aug-2012 | New command |

CALCulate[:SElected]:MARKer:AOFF

(Write-Only) Turns OFF all markers.

Relevant Modes CAT, NA, SA

Note: SA mode does NOT recognize the optional [:SElected] node.

Examples **CALC:MARK:AOFF**

Query Syntax Not Applicable

Default Not Applicable

CALCulate[:SElected]:MARKer:BWIDth:DATA?

(Read-only) Read the results of the bandwidth marker search. Returns Bandwidth, Center Frequency, Q, and Loss. Use [CALCulate:MARKer:BWIDth\[:STATE\]](#) to create bandwidth markers.

This command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Relevant Modes NA

Parameters

Examples CALC:MARK:BWID:DATA?

Return Type 4 Numeric values separated by commas.

Default Not Applicable

Last Modified:

13-Aug-2012 Added select

2-Aug-2011 New command A.05.50

CALCulate[:SElected]:MARKer:BWIDth[:STATE] <bool>

(Read-Write) Set or return the state of a bandwidth marker search.

This command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Use [CALCulate:MARKer:FUNcTion:BWIDth:THReshold](#) to set the bandpass or notch value to be used in the search.

Use [CALCulate:MARKer:BWIDth:DATA](#) to read the data.

Relevant Modes NA

Parameters

<bool> Choose from:

ON (or 1) - Uses markers 1 through 4 to perform a bandwidth search.

OFF (or 0) - Turns OFF the BW search. Use [CALCulate:MARKer:AOff](#) to turn the markers OFF.

Examples CALC:MARK:BWID ON

Query Syntax CALCulate[:SElected]:MARKer:BWIDth[:STATE]?

Return Type Boolean

Default Off

Last Modified:

13-Aug-2012 Added select

1-Aug-2011

New command (A.05.50)

CALCulate[:SElected]:MARKer:COUPled <bool>

(Read-Write) Set and query the state of marker coupling. Marker coupling is used in multi-trace configurations. This setting affects all NA mode markers.

Relevant Modes NA

Parameters

<bool> Choose from:
OFF or **0** - Markers are uncoupled.
ON or **1** - Markers are coupled.

Examples **CALC:MARK:COUP OFF**

Query Syntax CALCulate[:SElected]:MARKer:COUPled?

Return Type Boolean

Default ON

Last Modified:

10-Aug-2012 Edited Coupled

30-Mar-2012 Removed marker specific

CALCulate[:SElected]:MARKer:FORMat <char>

(Read-Write) Set and query marker format that appears in the upper-right of the screen and in the marker table. This format can be different from the displayed format.

All of the markers on the selected trace change to the specified format.

Use **CALC:MARK:Y?** to read the Y-axis values that are on the screen.

Relevant Modes NA

Parameters

<char> Marker format. Choose from:
DEF - (Default) Same as displayed format.
IMPedance - R+jX format
PHASe - Phase in degrees.
ZMAGnitude - Impedance Magnitude
MAGPhase - Magnitude and Phase
REAL
IMAGinary

Examples `CALC:MARK:FORM IMP`

Query Syntax `CALCulate[:SElected]:MARKer:FORMat?`

Return Type Character

Default Depends on model and measurement.

Last Modified:

4-Jun-2013 New topic (A.07.00)

CALCulate[:SElected]:MARKer:FUNCtion:BWIDth:THReshold <value>

(Read-Write) Set or return the value used to find the bandwidth of a bandpass or notch filter response.

Use `CALCulate:MARKer:BWIDth[:STATe]` to turn BW search On/Off.

Use `CALCulate:MARKer:BWIDth:DATA` to read the data.

Relevant Modes NA

Parameters

- <value> BW search value. Specify the level in dB from the peak or valley where bandwidth is measured.
- Negative numbers search for a Peak bandpass, such as a filter S21 response. Either of the following TWO methods can be used to search for a Valley or Notch filter, such as the S11 response of a bandpass filter.
- Negative values search down from the TOP (MAX) of the response.
 - Positive values search up from the BOTTOM (MIN) of the notch.

Examples `CALC:MARK1:FUNC:BWID:THR 3`

Query Syntax `CALCulate[:SElected]:MARKer:FUNCtion:BWIDth:THReshold?`

Return Type Numeric

Default -3

Last Modified:

13-Aug-2012 Added selected
 1-Aug-2011 New command (A.05.50)

CALCulate[:SElected]:MARKer<n>:FUNCtion:FALLtime <num>

(Write-Read) Set and query pulse drop in dBm. Marker 1 is created as a delta marker and placed at the first instance of the peak value and the specified fall on the trace. Read the fall time using

[CALCulate\[:SElected\]:MARKer:X?](#)

Relevant Modes [Pulse Measurements](#)

Parameters

<num> Pulse Fall in dBm.

Examples `CALC:MARK:FUNC:FALL -5`

Query Syntax `CALCulate[:SElected]:MARKer<n>:FUNction:FALLtime?`

Default -3 dBm

Last Modified:

29-Oct-2013 New command

CALCulate[:SElected]:MARKer<n>:FUNction:MAXimum

(Write-Only) Causes the specified marker to find the highest (maximum) amplitude of the trace. For NA and CAT mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Relevant Modes CAT, NA, SA, [Pulse Measurements](#), [FOPS](#)

Note: SA mode does NOT recognize the optional [:SElected] node.

Parameters

<n> New or existing marker to move. Choose from 1 to 6.

Examples `CALC:MARK1:FUNC:MAX`

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

21-Mar-2014 Added FOPS

29-Oct-2013 Added Pulse

CALCulate[:SElected]:MARKer<n>:FUNction:MINimum

(Write-Only) Causes the specified marker to find the lowest (minimum) amplitude of the trace. For NA and CAT mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Relevant Modes CAT, NA, SA, [Pulse Measurements](#), [FOPS](#)

Note: SA mode does NOT recognize the optional [:SElected] node.

Parameters

<n> New or existing marker to move. Choose from 1 to 6.

Examples `CALC:MARK1:FUNC:MIN`

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

21-Mar-2014 Added FOPS

29-Oct-2013 Added Pulse

CALCulate[:SElected]:MARKer:FUNCtion:PEXCursion <num>

(Read-Write) Set and query the excursion value. This is the vertical distance (dB) between the peak and the valleys on both sides. To be considered a peak for subsequent marker search commands, data values must "fall off" from the peak on both sides by the excursion value.

For NA and CAT mode, this command operates on the selected trace. First select a trace using `CALC:PAR<tr>:SElect`.

Peak Excursion and Threshold settings apply to all markers on each trace.

These settings remain through an instrument preset, but are reset to the default values when the FieldFox power is shutdown.

Relevant Modes CAT, NA, SA, [Pulse Measurements](#)

Note: SA mode does NOT recognize the optional [:SElected] node.

Parameters

<num> Excursion value in dB.

Examples `CALC:MARK:FUNC:PEXC 1`

Query Syntax `CALCulate[:SElected]:MARKer:FUNCtion:PEXCursion?`

Return Type Numeric

Default 0.5 dB

Last Modified:

29-Oct-2013 Added Pulse

CALCulate[:SElected]:MARKer<n>:FUNCtion:PNEXT

(Write-Only) Causes the specified marker to find the next lower amplitude peak from where it currently

resides. This command is usually preceded with the [MARK:FUNC:MAX](#) command which finds the highest peak.

For NA and CAT mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Relevant Modes CAT, NA, SA, [Pulse Measurements](#)

Note: SA mode does NOT recognize the optional [:SElected] node.

Parameters

<n> New or existing marker to move. Choose from 1 to 6.

Examples `CALC:MARK1:FUNC:PNEX`

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

29-Oct-2013 Added Pulse

CALCulate[:SElected]:MARKer:FUNCtion:PTHReshold <num>

(Write-Only) The minimum amplitude used to find peaks in subsequent marker search commands. To be considered valid, the peak must be **above** the threshold level. The valley on either side can be below the threshold level.

For NA and CAT mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Peak Excursion and Threshold settings apply to all markers on each trace.

These settings remain through an instrument preset, but are reset to the default values when the FieldFox power is shutdown.

Relevant Modes CAT, NA, SA, [Pulse Measurements](#)

Note: SA mode does NOT recognize the optional [:SElected] node.

Parameters

<num> Threshold value in dB.

Examples `CALC:MARK:FUNC:PTHR -10`

Query Syntax CALCulate[:SElected]:MARKer:FUNCtion:PTHReshold?

Default -190 dB

Last Modified:

29-Oct-2013 Added Pulse

CALCulate[:SElected]:MARKer:FUNCtion:RISetime <num>

(Write-Read) Set and query pulse rise in dBm. Marker 1 is created as a delta marker and placed at the first instance of the peak value and the specified rise on the trace. Read the rise time using [CALCulate\[:SElected\]:MARKer:X?](#)

Relevant Modes [Pulse Measurements](#)

Parameters

<num> Pulse Rise in dBm.

Examples `CALC:MARK:FUNC:RIS 5`

Query Syntax `CALCulate[:SElected]:MARKer<n>:FUNCTION:RISetime?`

Default dBm

Last Modified:

29-Oct-2013 Added Pulse

CALCulate[:SElected]:MARKer:FUNCTION:TARGet <value>

(Read-Write) Set and query the marker target search value.

This command operates on the selected trace AND the active marker.

First select a trace using [CALC:PAR<tr>:SElect](#).

Then activate a marker using [CALCulate\[:SElected\]:MARKer:ACTivate](#)

Relevant Modes NA, [Pulse Measurements](#)

Parameters

<value> Target search value in dB.

Examples `CALC:MARK:FUNC:TARG -1`

Query Syntax `CALCulate[:SElected]:MARKer:FUNCTION:TARGet?`

Return Type Numeric

Default -3 dB

Last Modified:

17-Dec-2013 Active marker

29-Oct-2013 Added Pulse

23-Jan- Removed CAT

2013

2-Aug-2011 New command

CALCulate[:SElected]:MARKer:FUNCtion:TDIRection <value>

(Read-Write) Set and query whether the target search will 'wrap' when it gets to the end of the range. This command operates on the selected trace, AND the active marker, AND only a 'Target' search.

Note: There is NO front-panel GUI equivalent for this command.

1. Select a trace using [CALC:PAR<tr>:SElect](#).
2. Then activate a marker using [CALCulate\[:SElected\]:MARKer:ACTivate](#)
3. Then start a search using [CALCulate\[:SElected\]:MARKer:FUNCtion:TARGet](#).

Relevant Modes NA, [Pulse Measurements](#)

Parameters

<value> Choose from:

Default - Search from the current marker position to the right. Wrap around to the beginning and continue search.

LEFT - Search to the left from the current position. When the range start is reached, end the search (no wrap).

RIGHT - Search to the right from the current position. When the range stop is reached, end the search (no wrap)

Examples `CALC:MARK:FUNC:TDIR LEFT`

Query Syntax `CALCulate[:SElected]:MARKer:FUNCtion:TDIRection?`

Return Type Character

Default Default

Last Modified:

6-Nov-2014 New command

CALCulate[:SElected]:MARKer<n>:FUNCtion:TRACking <bool>

(Read-Write) Set and query the marker tracking ON/OFF state. Marker tracking can be used with all search functions.

For NA mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Relevant Modes NA, [Pulse Measurements](#)

Parameters

- <n> Marker number for which tracking is to be set. A marker is created if not already ON. Choose from 1 to 6. If unspecified, value is set to 1.
- <bool> Marker tracking state. Choose from:
ON (or 1) - Marker Tracking ON.
OFF (or 0) - Marker Tracking OFF.

Examples CALC:MARK2:FUNC:TRAC 1

Query Syntax CALCulate[:SElected]:MARKer<n>:FUNction:TRACking?

Return Type Boolean

Default OFF

Last Modified:

| | |
|-------------|--------------------|
| 29-Oct-2013 | Added Pulse |
| 2-Aug-2011 | New command (5.50) |

CALCulate[:SElected]:MARKer:FUNction:ZONE <bool>

(Write-Read) Set and query whether marker function searches occur on the entire primary trace graph or within the zoom window time span.

Relevant Modes [Pulse Measurements](#)

Parameters

- <bool> Choose from:
OFF or 0 - Marker function searches occur on the entire primary trace graph
ON or 1 - Marker function searches occur within the zoom window time span.

Examples **CALC : MARK : FUNC : ZONE 1**

Query Syntax CALCulate[:SElected]:MARKer:FUNction:ZONE?

Default OFF

Last Modified:

| | |
|-------------|-------------|
| 29-Oct-2013 | New command |
|-------------|-------------|

CALCulate[:SElected]:MARKer<n>:SET <char>

(Write-Only) Sets the FieldFox setting <char> to the location of the specified marker.

For NA and CAT mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Note: SA mode does NOT recognize the optional [:SElected] node.

Relevant Modes The following <char> arguments are valid in each mode:
An error is returned if <char> is not valid.

| Mode/function | Valid <char> Arguments |
|----------------------|-----------------------------|
| CAT (non-DTF) | START, STOP, CENTer, RLEVel |
| CAT (DTF) | START, STOP, RLEVel |
| NA | START, STOP, CENTer, DEL |
| SA (Non-Zerospan) | START, STOP, CENTer, RLEVel |
| SA (Zerospan) | RLEVel |
| SA (Tune and Listen) | TLFRequency |

Parameters

- <n> Existing marker location from which <char> will be set. Choose from 1 to 6.
- <char> **START** - Sets the sweep Start value to the marker X-axis value.
- STOP** - Sets the sweep Stop value to the marker X-axis value.
- CENTer** - Sets the center frequency of the sweep to the marker X-axis value.
- DELay** - Sets the electrical delay to that of the current marker group delay value.
- RLEVel** - Sets the reference level value to the marker Y-axis value.
- TLFRequency** - Sets the SA Mode Tune and Listen frequency to the marker X-axis value.

Examples `CALC:MARK1:SET CENT`

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

19-Oct-2010

Updated with DEL (5.30)

CALCulate[:SElected]:MARKer<n>[:STATE] <char>

(Read-Write) Create, change, or remove a marker.

For NA and CAT mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Relevant Modes CAT, NA, SA, [Pulse Measurements](#), [FOPS](#)

Note: SA mode does NOT recognize the optional [:SElected] node.

Parameters

- <n> New or existing marker to create, change, or remove. Choose from 1 to 6.
- <char> Choose from:
- NORM** - Marker is a Normal marker
 - DELT** - Marker is a Delta marker pair.
 - OFF** - Marker is disabled.
- To create and move a delta marker:**
1. Create a normal marker using this command.
 2. Move the marker to the reference position using [CALCulate:MARKer:X](#)
 3. Change the marker to a delta marker using this command.
 4. Move the delta marker to the delta position using [CALCulate:MARKer:X](#)

Examples `CALC:MARK1 NORM`

Query Syntax `CALCulate[:SElected]:MARKer<n>[:STATe]?`

Return Type Character

Default Off

Last Modified:

20-Mar-2014 Added FOPS

29-Oct-2013 Added Pulse

CALCulate[:SElected]:MARKer<n>:TRACe <tnum>

(Write-Only) Moves an existing marker to the specified trace number. The marker and the CAT or NA trace must exist already. This feature is called Marker Trace in the User's Guide.

For NA and CAT mode, this command moves the selected trace. First select a trace using [CALC:PAR<tr>:SFlect](#).

Relevant Modes CAT, NA, SA

Note: SA mode does NOT recognize the optional [:SElected] node.

Parameters

- <n> Existing marker to assign to trace. Choose from 1 to 6.
- <tnum> Trace number. Choose from:
- CAT and NA:
- **0** - Auto. Marker resides on data trace when it is visible. Marker resides on memory trace when only IT is visible.

- 1 - Data Trace
- 2 - Memory Trace

SA:

- 1, 2, 3, 4

Examples CALC:MARK1:TRAC 1

Query Syntax CALCulate[:SElected]:MARKer<n>:TRACe?

Default 1

CALCulate[:SElected]:MARKer<n>:X <num>

(Read-Write) Set and query the X-axis location for the specified marker. See [To Create and Move a Delta Marker](#)

For NA and CAT mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Relevant Modes CAT, NA, SA, [Pulse Measurements](#), [FOPS](#)

Note: SA mode does NOT recognize the optional [:SElected] node.

Parameters

<n> Existing marker for which to set X-axis location. Choose from 1 to 6.

<num> X-axis location. Choose any value currently displayed on the X-axis.

Note: In CAT or NA mode, units of **time** (Freq span of zero Hz.) are NOT accepted

Examples CALC:MARK1:X 4e9

Query Syntax CALCulate[:SElected]:MARKer<n>:X?

Return Type Numeric

Default When created, markers appear at the center of the X-axis.

Last Modified:

20-Mar-2014

Added FOPS

CALCulate[:SElected]:MARKer<n>:Y?

(Read-Only) Reads the Y-axis value for the specified marker.

For NA and CAT mode, this command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Note: SA mode does NOT recognize the optional [:SElected] node.

Relevant Modes CAT - Two values are returned: Magnitude and zero.

NA - Format depends on [CALCulate\[:SElected\]:MARKer:FORMat](#)

SA - One value is returned: Magnitude
 FOPS - Two values are returned: Magnitude and zero.

Parameters

<n> Existing marker for which to read Y-axis value. Choose from 1 to 6.

Examples CALC:MARK1:Y?

Return Type Numeric

Default Not Applicable

Last Modified:

20-Mar-2014 Added FOPS

4-Jun-2013 Added NA mode format (A.07.00)

CALCulate[:SElected]:MATH:FUNctIon <char>

(Read-Write) Set and query the math function. A trace must already be stored into memory (CALC:MATH:MEM) for a setting other than NORM.

This command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Relevant Modes NA, CAT

Parameters

<char> Choose from:
NORM - Math Off
ADD - (Data + Memory)
SUBTract - (Data - Memory)
DIVide - (Data / Memory)

Examples CALC:MATH:FUNC DIV

Query Syntax CALCulate[:SElected]:MATH:FUNctIon?

Return Type Character

Default NORM

CALCulate[:SElected]:MATH:MEMorize

(Write-Only) Stores the current data trace into memory.

This command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Relevant Modes NA, CAT, [FOPS](#)

Examples CALC:MATH:MEM

Query Syntax Not Applicable

Default Not Applicable

Last modified:

19-Mar-2014 Added FOPS

CALCulate[:SElected]:SMOothing:APERture <num>

(Read-Write) Set and query the smoothing aperture for the selected trace.

This command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Use [CALCulate\[:SElected\]:SMOothing\[:STATe\]](#) to enable and disable smoothing.

Relevant Modes NA, CAT

Parameters

<num> Trace smoothing in percent. Choose a value between 0 and 25.

Examples **CALC:SMO:APER 5**

Query Syntax CALCulate[:SElected]:SMOothing:APERture?

Return Type Numeric

Default 1.5

Last Modified:

20-Jan-2015 Added CAT

19-Oct-2010 New command (5.30)

CALCulate[:SElected]:SMOothing[:STATe] <bool>

(Read-Write) Set and query whether trace smoothing occurs on the selected trace. Not available with Polar or Smith Chart formats.

This command operates on the selected trace. First select a trace using [CALC:PAR<tr>:SElect](#).

Use [CALCulate\[:SElected\]:SMOothing:APERture](#) to set aperture.

Relevant Modes NA, CAT

Parameters

<bool> Testing state. Choose from:
0 or **OFF** - Smoothing disabled.
1 or **ON** - Smoothing enabled.

Examples `CALC:SMO 1`

Query Syntax `CALCulate[:SElected]:SMOothing[:STATE]?`

Return Type Boolean

Default OFF

Last Modified:

20-Jan-2015 Added CAT

19-Oct-2010 New command (5.30)

CALCulate[:SElected]:TIME:AUX:CENTer <num>

(Read-Write) Set and query the center time of the zoom window.

Relevant Modes [Pulse Measurements](#)

Parameters

<num> Center time in seconds.

Examples `CALC:TIME:AUX:CENT 5e-5`

Query Syntax `CALCulate[:SElected]:TIME:AUX:CENTer?`

Return Type Numeric

Default 5e-5

Last Modified:

29-Oct-2013 New command

CALCulate[:SElected]:TIME:AUX:PDIVision <num>

(Read-Write) Set and query the Time per division of the zoom window.

Relevant Modes [Pulse Measurements](#)

Parameters

<num> Per division time in seconds.

Examples `CALC:TIME:AUX:PDIV 10e-6`

Query Syntax `CALCulate[:SElected]:TIME:AUX:CENTer?`

Return Type Numeric

Default 5e-5

Last Modified:

29-Oct-2013 New command

CALCulate[:SELEcted]:TIME:CENTer <num>

(Read-Write) Set and query the center time of the primary trace graph window.

Relevant Modes [Pulse Measurements](#)

Parameters

<num> Center time in seconds.

Examples CALC:TIME:CENT 5e-5

Query Syntax CALCulate[:SELEcted]:TIME:CENTer?

Return Type Numeric

Default 5e-5

Last Modified:

29-Oct-2013 New command

CALCulate[:SELEcted]:TIME:LENGth <num>

(Read-Write) Set and query the time span of the primary trace graph window.

Relevant Modes [Pulse Measurements](#)

Parameters

<num> Time span in seconds.

Examples CALC:TIME:LENG 5e-5

Query Syntax CALCulate[:SELEcted]:TIME:LENGth?

Return Type Numeric

Default 100e-6

Last Modified:

29-Oct-2013 New command

CALCulate[:SElected]:TIME:PDIVision <num>

(Read-Write) Set and query the Time per division of the primary trace graph window.

Relevant Modes [Pulse Measurements](#)

Parameters

<num> Per division time in seconds.

Examples CALC:TIME:PDIV 1e-6

Query Syntax CALCulate[:SElected]:TIME:PDIVision?

Return Type Numeric

Default 10e-6

Last Modified:

29-Oct-2013 New command

CALCulate[:SElected]:TIME:STARt <num>

(Read-Write) Set and query the start time of the primary trace graph window.

Relevant Modes [Pulse Measurements](#)

Parameters

<num> Start time in seconds.

Examples CALC:TIME:STAR 1e-9

Query Syntax CALCulate[:SElected]:TIME:STARt?

Return Type Numeric

Default 0

Last Modified:

29-Oct-2013 New command

CALCulate[:SElected]:TRACe<n>:DATA?

(Read-only) Read the data from a Trace Graph measurement.

Relevant Modes [Pulse Measurements](#), [FOPS](#)

Parameters

<n> Trace number.
 For Pulse, choose from the following:
 1 - Primary trace graph
 2 - Zoom window
 For FOPS, choose 1 or unspecify.

Examples **CALC : TRAC : DATA ?**

Query Syntax CALCulate[:SElected]:TRACe:DATA?

Return Type Numeric

Default Not Applicable

Last Modified:

| | |
|-------------|-------------|
| 21-Mar-2014 | Added FOPS |
| 29-Oct-2013 | New command |

CALCulate[:SElected]:TRANSform:DISTance:BANDpass <bool>

(Read-Write) Set and query Bandpass mode for Distance to Fault measurements. This command performs the same function as [CALCulate:TRANSform:FREQuency\[:TYPE\]](#).

Relevant Modes CAT

Parameters

<bool> Bandpass mode. Choose from:
0 or **OFF** - Lowpass mode
1 or **ON** - Bandpass mode

Examples CALC:TRAN:DIST:BAND 1

Query Syntax CALCulate[:SElected]:TRANSform:DISTance:BANDpass?

Return Type Boolean

Default 1 - ON

CALCulate[:SElected]:TRANSform:DISTance:FREQuency:CENTer <num>

(Read-Write) Set and query the bandpass center frequency for Distance to Fault measurements. Set Bandpass mode using [CALC:TRAN:DIST:BANDpass ON](#).

Relevant Modes CAT

Parameters

<num> Bandpass center frequency in Hz.

| | |
|---------------------|---|
| Examples | CALC:TRAN:DIST:FREQ:CENT 1e9 |
| Query Syntax | CALCulate[:SElected]:TRANSform:DISTance:FREQuency:CENTer? |
| Return Type | Numeric |
| Default | Dependent on DTF distance. |

CALCulate[:SElected]:TRANSform:DISTance:FREQuency:SPAN:MAXimum <num>

(Read-Write) Set and query the bandpass maximum frequency span for Distance to Fault measurements. Set Bandpass mode using [CALC:TRAN:DIST:BANDpass ON](#).

| | |
|-----------------------|---|
| Relevant Modes | CAT |
| Parameters | |
| <num> | Bandpass maximum frequency span in Hz. |
| Examples | CALC:TRAN:DIST:FREQ:SPAN:MAX 100e6 |
| Query Syntax | CALCulate[:SElected]:TRANSform:DISTance:FREQuency:SPAN:MAXimum? |
| Return Type | Numeric |
| Default | Dependent on DTF distance. |

CALCulate[:SElected]:TRANSform:DISTance:FREQuency:STARt:MINimum <num>

(Read-Write) Set and query the start frequency value in Bandpass mode for a Distance to Fault measurement.

Use [CALCulate:TRANSform:DISTance:BANDpass](#) to set Bandpass mode.

| | |
|-----------------------|--|
| Relevant Modes | CAT |
| Parameters | |
| <num> | Start value in hertz. This command will accept MIN and MAX as arguments. |
| Examples | CALC:TRAN:DIST:FREQ:STAR:MIN 1GHz |
| Query Syntax | CALCulate[:SElected]:TRANSform:DISTance:FREQuency:STARt:MINimum? |
| Return Type | Numeric |
| Default | 2 MHz |

CALCulate[:SElected]:TRANSform:DISTance:FREQuency:STOP:MAXimum <num>

(Read-Write) Set and query the stop frequency value in Bandpass mode for a Distance to Fault measurement.

Use [CALCulate:TRANSform:DISTance:BANDpass](#) to set Bandpass mode.

| | |
|-----------------------|-----|
| Relevant Modes | CAT |
|-----------------------|-----|

Parameters

<num> Stop value in hertz. This command will accept MIN and MAX as arguments.

Examples CALC:TRAN:DIST:FREQ:STOP:MAX 2GHz

Query Syntax CALCulate[:SElected]:TRANSform:DISTance:FREQuency:STOP:MAXimum?

Return Type Numeric

Default FieldFox maximum frequency

CALCulate[:SElected]:TRANSform:DISTance:START <num>

(Read-Write) Set and query the X-axis start value in a Distance to Fault measurement.

Relevant Modes CAT

Parameters

<num> Start value in meters. Choose a value between the MIN distance and the Stop distance. (This command will accept MIN and MAX as arguments.)

Examples CALC:TRAN:DIST:STAR 10

Query Syntax CALCulate[:SElected]:TRANSform:DISTance:START?
This value is always returned in meters - never in feet.

Return Type Numeric

Default 0

CALCulate[:SElected]:TRANSform:DISTance:STOP <num>

(Read-Write) Set and query the X-axis stop value in Distance to Fault measurement.

Relevant Modes CAT

Parameters

<num> Stop value in meters. Choose a value between the Start distance and the MAX distance. (This command will accept MIN and MAX as arguments.)

Examples CALC:TRAN:DIST:STOP .20

Query Syntax CALCulate[:SElected]:TRANSform:DISTance:STOP?
This value will always be returned in meters - never in feet.

Return Type Numeric

Default 100 meters

CALCulate[:SElected]:TRANSform:DISTance:UNIT <char>

(Read-Write) Set and query the X-axis units in Distance to Fault measurement.

Note: DTF [Start](#) and [Stop](#) settings always return distance in meters.

Relevant Modes CAT

Parameters

<char> X-axis units. Choose from:

- METers
- FEET

Examples CALC:TRAN:DIST:UNIT

Query Syntax CALCulate[:SElected]:TRANSform:DISTance:UNIT?

Return Type Character

Default METers

Last Modified:

14-Feb-2013

Added note

CALCulate[:SElected]:TRANSform:DISTance:WINDow <char>

(Read-Write) Set and query the DTF window setting.

Relevant Modes CAT

Parameters

<char> DTF window setting. Choose from:

- RECT** - Minimum window setting.
- HAMM** - Medium window setting.
- KBES** - Maximum window setting.

Examples CALC:TRAN:DIST:WIND KBES

Query Syntax CALCulate[:SElected]:TRANSform:DISTance:WINDow?

Return Type Character

Default KBES

CALCulate[:SElected]:TRANSform:FREQuency[:TYPE] <char>

(Read-Write) Set and query the DTF Frequency mode. This command performs the same function as [CALCulate:TRANSform:DISTance:BANDpass](#).

Relevant Modes CAT

Parameters

<char> DTF frequency mode. Choose from:
BPASs - Bandpass mode.
LPASs - Lowpass mode.

Examples CALC:TRAN:FREQ BPAS

Query Syntax CALCulate[:SElected]:TRANSform:FREQuency[:TYPE]?

Return Type Character

Default BPASs

CALCulate[:SElected]:TRANSform:TIME:CENTer <num>

(Read-Write) Set and query the center time for time domain measurements.

Relevant Modes NA

Parameters

<num> Center time in seconds. Choose any number between: \pm (number of points-1) / frequency span

Examples CALC:TRAN:TIME:CENt 1e-9

Query Syntax CALCulate[:SElected]:TRANSform:TIME:CENTer?

Return Type Numeric

Default 0

Last Modified:

24-Jan-2012 New command

CALCulate[:SElected]:TRANSform:TIME:IMPulse:WIDth <num>

(Read-Write) Set and query the impulse width for the transform window.

Relevant Modes NA

Parameters

<num> Impulse width in seconds; Choose any number between: **.6 / frequency span** and **1.39 / frequency span**

Examples CALC:TRAN:TIME:IMP:WIDt 10

Query Syntax CALCulate[:SElected]:TRANSform:TIME:IMPulse:WIDth?

Return Type Numeric

Default .98 / Default Span

Last Modified:

24-Jan-2012 New command

CALCulate[:SElected]:TRANSform:TIME:KBESsel <num>

(Read-Write) Set and query the width for the Kaiser Bessel window.

Relevant Modes *NA*

Parameters

<num> Window width for Kaiser Bessel in seconds; Choose any number between **0.0** and **13.0**

Examples CALC:TRAN:TIME:KBES 10

Query Syntax CALCulate[:SElected]:TRANSform:TIME:KBESsel?

Return Type Numeric

Default 6

Last Modified:

24-Jan-2012 New command

CALCulate[:SElected]:TRANSform:TIME:LPFRequency

(Write-only) Sets the start frequencies in LowPass Mode.

Relevant Modes *NA*

Parameters None

Examples CALC:TRAN:TIME:LPFR

Query Syntax Not applicable

Default Not applicable

Last Modified:

24-Jan-2012 New command

CALCulate[:SElected]:TRANSform:TIME:SPAN <num>

(Read-Write) Set and query the span (stop - start) time for time domain measurements. Use [CALCulate\[:SElected\]:TRANSform:TIME:CENTer](#) to set the center time.

Relevant Modes [NA](#)

Parameters

<num> Span time in seconds. Choose any number between: 0 and 2* [(number of points-1) / frequency span].

Examples CALC:TRAN:TIME:SPAN 1e-9

Query Syntax CALCulate[:SElected]:TRANSform:TIME:SPAN?

Return Type Numeric

Default 20 ns

Last Modified:

24-Jan-2012 New command

CALCulate[:SElected]:TRANSform:TIME:START <num>

(Read-Write) Set and query the start time for time domain measurements. Use [CALCulate\[:SElected\]:TRANSform:TIME:STOP](#) to set the stop time.

Relevant Modes [NA](#)

Parameters

<num> Start time in seconds. Choose any number between: ± (number of points-1) / frequency span

Examples CALC:TRAN:TIME:STAR 1e-9

Query Syntax CALCulate[:SElected]:TRANSform:TIME:START?

Return Type Numeric

Default -10 ns

Last Modified:

24-Jan-2012 New command

CALCulate[:SElected]:TRANSform:TIME:STATE <bool>

(Read-Write) Set and query the ON |OFF Time Domain transform state for the active trace. Select a trace using [CALCulate:PARAMeter:SElect](#).

Relevant Modes [NA](#)

Parameters

<num> Transform state. Choose from:
ON (or 1) - turns time domain ON.
OFF (or 0) - turns time domain OFF.

Examples CALC:TRAN:TIME:STAT 1

Query Syntax CALCulate[:SElected]:TRANSform:TIME:STATE?

Return Type Boolean

Default OFF (or 0).

Last Modified:

24-Jan-2012 New command

CALCulate[:SElected]:TRANSform:TIME:STEP:RTIME <num>

(Read-Write) Set and query the step rise time for the transform window.

Relevant Modes **NA**

Parameters

<num> Rise time in seconds. Choose any number between:
.45 / frequency span and 1.48 / frequency span

Examples CALC:TRAN:TIME:STEP:STEP:RTIM 1e-8

Query Syntax CALCulate[:SElected]:TRANSform:TIME:STEP:RTIME?

Return Type Numeric

Default .99 / Default Span

Last Modified:

24-Jan-2012 New command

CALCulate[:SElected]:TRANSform:TIME:STIMulus <char>

(Read-Write) Set and query the type of simulated stimulus that will be incident on the DUT.

Relevant Modes **NA**

Parameters

<char> Choose from:

- **STEP** - simulates a step DUT stimulus (will automatically set [CALC:TRAN:TIME:TYPE](#) to **LPASs**)
- **IMPulse** - simulates a pulse DUT stimulus.

Examples CALC:TRAN:TIME:STIM STEP

Query Syntax CALCulate[:SElected]:TRANSform:TIME:STIMulus?

Return Type Character

Default IMPulse

Last Modified:

24-Jan-2012 New command

CALCulate[:SElected]:TRANSform:TIME:STOP <num>

(Read-Write) Set and query the stop time for time domain measurements. Use [CALCulate\[:SElected\]:TRANSform:TIME:START](#) to set the start time.

Relevant Modes [NA](#)

Parameters

<num> Stop time in seconds. Choose any number between: \pm (number of points-1) / frequency span

Examples CALC:TRAN:TIME:STOP 1e-9

Query Syntax CALCulate[:SElected]:TRANSform:TIME:STOP?

Return Type Numeric

Default 10 ns

Last Modified:

24-Jan-2012 New command

CALCulate[:SElected]:TRANSform:TIME:TYPE <char>

(Read-Write) Set and query the transform type.

Relevant Modes [NA](#)

Parameters

<num> Type of measurement. Choose from:

- **LPASs** - Lowpass; Must also send [CALC:TRAN:TIME:LPFRequency](#)

before calibrating.

- **BPASs** - Bandpass; can **only** be used when `CALC:TRAN:TIME:STIM` is set to `IMPulse`.

Examples `CALC:TRAN:TIME:STEP:TYPE LPAS`

Query Syntax `CALCulate[:SElected]:TRANSform:TIME:TYPE?`

Return Type Character

Default BPASs

Last Modified:

24-Jan-2012 New command

CALibration:ZERO:TYPE:EXT

(Write-Only) Performs external power meter zeroing.

Relevant Modes Power meter

Parameters None

Examples `CAL:ZERO:TYPE:EXT`

Query Syntax Not applicable

Default Not applicable

DISPlay:ANNotation:FREQuency <value>

(Read-Write) Set and query the method used to annotate frequency on the screen.

Relevant Modes `FOPS`

Parameters

<value> Choose from the following:

CSPan - Center and Span

SSTop - Start and Stop

Examples `DISP:ANN:FREQ CSP`

Query Syntax `DISPlay:ANNotation:FREQuency?`

Return Type Character

Default CSPan

Last modified:

19-Mar-2014 New command (A.07.50)

DISPlay:BRIGhtness <num>

(Read-Write) Set and query the brightness of the FieldFox display.

Relevant Modes ALL

Parameters

<num> Display brightness. Choose a number from 0 to 100. A zero setting is dim, but still viewable.

Examples **DISP:BRIG 50**

Query Syntax DISPlay:BRIGhtness?

Return Type Numeric

Default 0

DISPlay:DATE:FMT <char>

(Read-Write) Set and query the format of the system date. Set the date using [SYST:DATE](#).

Relevant Modes ALL

Parameters

<char> System date format. Choose from:
Argument -- Example
HIDE - Date is not shown on screen.
SHORT - 10/17/2008
LONG - Fri, 17 Oct 2008
FULL - Friday, October 17, 2008
SORTABLE - 2008-10-17
MONTHDAY - October 17

Examples **DISP:DATE:FMT Long**

Query Syntax DISPlay:DATE:FMT?

Return Type Character

Default Long

DISPlay:ENABLE <bool>

(Read-Write) Turns the FieldFox display ON and OFF. The OFF (0) setting causes faster SCPI operation.

Relevant Modes ALL

Parameters

<bool> Choose from:
 0 or OFF - Display OFF. Send [Preset](#) or *RST to re-enable the display.
 1 or ON - Display ON

Examples **DISP:ENAB 1**

Query Syntax DISPlay:ENABle?

Return Type Boolean

Default ON (1)

Last Modified:

20-Oct-2010 New command (5.30)

DISPlay:GRID <bool>

(Read-Write) Set and query the visibility of the 10 x 10 grid on trace graph measurements.

Relevant Modes USB PM: [Pulse Measurements](#), [FOPS](#)

Parameters

<bool> Choose from:
 OFF or 0 - Grid OFF
 ON or 1 - Grid ON

Examples **DISP:GRID 1**

Query Syntax DISPlay:GRID?

Default OFF

Last modified:

19-Mar-2014 Added FOPS
 31-Oct-2013 New command

DISPlay:KEYWord[:DATA] <string1,2,3,4,5,6,7,8>

(Read-Write) Set and query the FieldFox keywords that can be used to create filenames.

Relevant Modes All

Parameters

<string1,2,3,4,5,6,7,8> All 8 keywords, separated with commas, enclosed in individual quotes.

Examples Disp:KEYW "Tower A","Tower B","Tower C","Tower D","Tower E","Tower F","Tower G","Tower H","Tower I","Tower J"

Query Syntax DISPlay:KEYWord[:DATA]?

Return Type String data, separated with commas, enclosed in individual quotes.

Default See [DISPlay:KEYWord:DEFault](#)

DISPlay:KEYWord:DEFault

(Read-Only) Reset the FieldFox keywords to their default settings (listed below).

Relevant Modes All

Parameters None

Examples DISPlay:KEYWord:DEFault

Query Syntax Not Applicable

Default "FILE","SITE","TOWER","TRACE","DATE","ANTENNA1","ANTENNA2","COMPANY1","COMPANY2","COMPANY3"

DISPlay:MARKer:LARGe:STATe <char>

(Read-Write) Set and query the display state of large marker readouts.

Relevant Modes NA

Parameters

<char> Large marker readout state. Choose from:
OFF - No large marker readout.
A - The A display state is recalled. If none have been defined, then the default A display state is recalled.
B - The B display state is recalled. If none have been defined, then the default B display state is recalled.

Examples **DISP:MARK:LARG:STAT A**

Query Syntax DISPlay:MARKer:LARGe:STATe?

Return Type Character

Default OFF

Last Modified:

22-Sept-2014 New command

DISPlay:MARKer:LARGe:<x>:DEFine:LINE<n>:FORMat <char>**(Read-Write)** Set and query the format for the specified readout line on the large marker display state.**Relevant Modes** **NA****Parameters**

<x> Large Marker Display State to edit.

Choose from: **A** or **B****Note:** This is a SCPI node and not an argument. See example below.

<n> Readout line number. Choose from 1, 2, or 3.

<char> Large marker readout format. Choose from:

DEFault - same format as the trace on which the marker resides.**MAGPhase** - magnitude and phase**IMPedance** - Complex impedance format: R + jX**ZMAGnitude** - Impedance; magnitude only**PHASe****REAL****IMAGinary****FREQuency** - displays ONLY the frequency of the marker**Examples** **DISP:MARK:LARG:A:DEF:LINE1:FORM phase****Query Syntax** DISPlay:MARKer:LARGe:<x>:DEFine:LINE<n>:FORMat?**Return Type** Character**Default** DEFault

Last Modified:

22-Sept-2014 New command

DISPlay:MARKer:LARGe:<x>:DEFine:LINE:MARKer<n>:STATe <char>**(Read-Write)** Set and query how the specified marker is displayed.**Relevant Modes** **NA****Parameters**

<x> Display state. Choose from:

A - Display state A

B - Display state B

<n> Marker number. Choose from:
1, 2, or 3

<char> Marker display state. Choose from:
OFF - Specified marker is set OFF.
NORMAL - Specified marker is a normal marker.
DELTA - Specified marker is a delta marker.

Examples **DISP:MARK:LARG:B:DEF:LINE:MARK2:STAT NORM**

Query Syntax DISPlay:MARKer:LARGe:<x>:DEFine:LINE:MARKer<n>:STATe?

Return Type Character

Default NORMAl

Last Modified:

8-Sept-2014 New command

DISPlay:MARKer:LARGe:<x>:DEFine:LINE<n>:MNUMber <value>

(Read-Write) Set and query the marker number to assign to the specified marker readout line.

Relevant Modes **NA**

Parameters

<x> Large Marker Display State to edit.
Choose from: **A** or **B**

Note: This is a SCPI node and not an argument. See example below.

<n> Readout line number. Choose from 1, 2, or 3.

<value> Marker number. Choose a marker from 1 through 6.

Examples **DISP:MARK:LARG:A:DEF:LINE1:MNUM 6**

Query Syntax DISPlay:MARKer:LARGe:<x>:DEFine:LINE<n>:MNUMber?

Return Type Numeric

Default Marker 1 is assigned to all three readouts, different traces.

Last Modified:

22-Sept-2014 New command

DISPlay:MARKer:LARGe:<x>:DEFine:LINE<n>:STATe <bool>

(Read-Write) Set and query the ENABLE state for the specified readout line.

Relevant Modes **NA**

Parameters

<x> Large Marker Display State to edit.

Choose from: **A** or **B**

Note: This is a SCPI node and not an argument. See example below.

<n> Readout line number. Choose from 1, 2, or 3.

<bool> Enable state. Choose from:

OFF or **0** - Specified readout line is OFF.

ON or **1** - Specified readout line is ON.

Examples **DISP:MARK:LARG:A:DEF:LINE1:STAT 1**

Query Syntax DISPlay:MARKer:LARGe:<x>:DEFine:LINE<n>:STATe?

Return Type Boolean

Default Readout line 1 is ON when the display state is first recalled.

Readout lines 2 and 3 are OFF when the display state is first recalled.

Last Modified:

22-Sept-2014

New command

DISPlay:MARKer:LARGe:<x>:DEFine:LINE<n>:TNUMber <value>

(Read-Write) Set and query the trace number to assign to the specified marker readout line.

Relevant Modes **NA**

Parameters

<x> Large Marker Display State to edit.

Choose from: **A** or **B**

Note: This is a SCPI node and not an argument. See example below.

<n> Readout line number. Choose from 1, 2, or 3.

<value> Trace number. Choose a trace from 1 through 3.

Examples **DISP:MARK:LARG:A:DEF:LINE1:TNUM 3**

Query Syntax DISPlay:MARKer:LARGe:<x>:DEFine:LINE<n>:TNUMber?

Return Type Numeric

Default Traces 1, 2, and 3 are assigned to the corresponding readouts (1, 2, 3)

Last Modified:

22-Sept-2014 New command

DISPlay:MARKer:LARGe:<x>:DEFine:LINE<n>:TRACking <bool>

(Read-Write) Set and query the marker tracking state for the specified readout line.

Select the parameter to track on the standard Marker Search menu.

When set to ON, Peak tracking is set by default.

To set a different marker search function, use the standard [Calc:Mark:Function](#) commands.

Relevant Modes [NA](#)

Parameters

<x> Large Marker Display State to edit.

Choose from: **A** or **B**

Note: This is a SCPI node and not an argument. See example below.

<n> Readout line number. Choose from 1, 2, or 3.

<bool> Marker tracking state. Choose from:

OFF or **0** - Tracking disabled.

ON or **1** - Tracking enabled.

Examples **DISP:MARK:LARG:A:DEF:LINE1:TRACking 1**

Query Syntax DISPlay:MARKer:LARGe:<x>:DEFine:LINE<n>:TRACking?

Return Type Boolean

Default OFF

Last Modified:

22-Sept-2014 New command

DISPlay:MARKer:LARGe:<x>:DEFine:TRACe<n>:BWIDth:STATe <value>

(Read-Write) Set and query the marker bandwidth search state for the specified trace.

Relevant Modes [NA](#)

Parameters

<x> Large Marker Display State to edit.

Choose from: **A** or **B**

Note: This is a SCPI node and not an argument. See example below.

<n> Trace number. Choose from 1, 2, or 3.

<value> Marker bandwidth search state. Choose from:

OFF or **0** - BW search is OFF.

ON or **1** - BW search is ON.

Examples **DISP:MARK:LARG:A:DEF:TRAC1:BWID:STAT ON**

Query Syntax DISPlay:MARKer:LARGe:<x>:DEFine:TRACe<n>:BWIDth:STATe?

Return Type Boolean

Default OFF

Last Modified:

22-Sept-2014

New command

DISPlay:MARKer:LARGe:<x>:DEFine:TRACe<n>:FORMat <value>

(Read-Write) Set and query the display format for the specified trace.

Relevant Modes **NA**

Parameters

<x> Large Marker Display State to edit.

Choose from: **A** or **B**

Note: This is a SCPI node and not an argument. See example below.

<n> Trace number. Choose from 1, 2, or 3.

<value> Display format. Choose from:

MLOGarithmic - Log magnitude

MLINear - Linear magnitude

SWR - Standing Wave Ratio

PHASe - Phase in degrees. The trace wraps every 360 degrees, from +180 to -180

UPHase - Unwrapped phase in degrees.

SMITH - Smith chart; series resistance and reactance.

POLar - Magnitude and phase of the reflection coefficient.

GDELay - Group delay

Examples **DISP:MARK:LARG:A:DEF:TRAC1:FORM MLIN**
Query Syntax DISPlay:MARKer:LARGe:<x>:DEFine:TRACe<n>:FORMat?
Return Type Character
Default MLOG

Last Modified:

22-Sept-2014 New command

DISPlay:MARKer:LARGe:<x>:DEFine:TRACe<n>:MEASurement <value>

(Read-Write) Set and query the measurement to display for the specified trace.

Relevant Modes NA

Parameters

<x> Large Marker Display State to edit.

Choose from: **A** or **B**

Note: This is a SCPI node and not an argument. See example below.

<n> Trace number. Choose from 1, 2, or 3.

<value> Measurement. Choose from:

- **S11** - Forward reflection measurement
- **S21** - Forward transmission measurement
- **S12** - Reverse transmission
- **S22** - Reverse reflection
- **A** - A receiver measurement
- **B** - B receiver measurement
- **R1** - Port 1 reference receiver measurement
- **R2** - Port 2 reference receiver measurement

Examples **DISP:MARK:LARG:A:DEF:TRAC1:MEAS S11**

Query Syntax DISPlay:MARKer:LARGe:<x>:DEFine:TRACe<n>:MEASurement?

Return Type Character

Default Trace1=S11
 Trace2=S21
 Trace1=S12

Last Modified:

22-Sept-2014

New command

DISPlay:MARKer:LARGe:<x>:FONT <char>**(Read-Write)** Set and query the font size for the large marker readouts.**Relevant Modes** NA**Parameters**

<x> Large Marker Display State to edit.

Choose from: **A** or **B****Note:** This is a SCPI node and not an argument. See example below.

<char> Font size. Choose from:

BIG - Big size.**SUP** - Super big size.**Examples****DISP:MARK:LARG:A:FONT SUP****Query Syntax** DISPlay:MARKer:LARGe:<x>:FONT?**Return Type** Character**Default** BIG

Last Modified:

22-Sept-2014

New command

DISPlay:MARKer:LARGe:<x>:TRACe:COUNT <char>**(Read-Write)** Set and query the number of traces to include in the large marker display state.**Relevant Modes** NA**Parameters**

<x> Display state. Choose from:

A - Display state A**B** - Display state B

<char> Trace configuration. Choose from:

D1 - One trace.

D2 - Two traces overlaid on one graticule.

D3 - Three traces overlaid on one graticule.

Examples **DISP:MARK:LARG:B:TRAC:COUN D3**

Query Syntax DISPlay:MARKer:LARGe:<x>:TRACe:COUNt?

Return Type Character

Default D1

Last Modified:

22-Sept-2014 New command

DISPlay:TABLE:MARKer <bool>

(Read-Write) Set and query the display of the marker table.

Relevant Modes CAT, NA, SA, [Pulse Measurements](#)

Parameters

<bool> Marker table display state. Choose from:

0 or OFF - Table OFF

1 or ON - Table ON

Examples **DISP:TABL:MARK ON**

Query Syntax DISPlay:TABLE:MARKer?

Return Type Boolean

Default OFF

Last modified:

31-Oct-2013 Added Pulse

DISPlay:TABLE:RESults:DATA?

(Read-Only) Read the 10 Auto Analysis results.

Relevant Modes [Pulse Measurements](#)

Parameters None

Examples **DISP:TABLE:RES:DATA?**

Default N/A

Last modified:

31-Oct-2013 New command

DISPlay:TABLE:RESults <bool>

(Read-Write) Set and query the visibility of the of both the Marker table and the Auto Analysis table.

Relevant Modes [Pulse Measurements](#)

Parameters

<bool> Choose from:
OFF or 0 - Tables OFF
ON or 1 - Tables ON

Examples **DISP:TABLE:RES 1**

Query Syntax DISPlay:TABLE:RESults?

Default OFF

Last modified:

31-Oct-2013 New command

DISPlay:TIME:FMT <char>

(Read-Write) Set and query the format of the system time on the screen. Set the time using SYST:TIME

Relevant Modes ALL

Parameters

<char> System time format. Choose from:
 Argument - Example
HIDE - time is not shown on screen.
SHORT - 10:31 PM
LONG - 10:31:25 PM
SH24 - 22:31
LO24 - 22:31:25

Examples **DISP:TIME:FMT Long**

Query Syntax DISPlay:TIME:FMT?

Return Type Character

Default Long

DISPlay:TITLe:DATA <string>

(Read-Write) Set and query the title that appears in the upper-left corner of the FieldFox screen. The title can contain up to approximately 65 alpha-numeric characters. Display the title using [DISPlay:TITLe:STATe](#).

Relevant Modes ALL

Parameters

<num> Title. Choose any string.

Examples **DISP:TITL:DATA "My title"**

Query Syntax DISPlay:TITLe:DATA?

Return Type String

Default "User Title"

DISPlay:TITLe[:STATe] <bool>

(Read-Write) Set and query display state of the title string. Change the title using [DISPlay:TITLe](#)

Relevant Modes ALL

Parameters

<bool> Choose from:
 0 or OFF - Title OFF
 1 or ON - Title ON

Examples **DISP:TITL 1**

Query Syntax DISPlay:TITLe[:STATe]?

Return Type Boolean

Default 0 - Off

DISPlay:WINDow:ANALog:LOWer <num>

(Read-Write) Set and query the Minimum scale value of the Power Meter display.

Relevant Modes [Power Meter](#), [Pulse Measurements](#), [CPM](#)

Parameters

<num> Minimum scale value. Choose a number between -100 and the upper (Max) scale value.

Examples **DISP:WIND:ANAL:LOW -70**

Query Syntax DISPlay:WINDow:ANALog:LOWer?

Default -100

Last modified:

1-Apr-2014 Added CPM
31-Oct-2013 Added Pulse

DISPlay:WINDow:ANALog:UPPer <num>

(Read-Write) Set and query the Maximum scale value of the Power Meter display.

Relevant Modes [Power Meter](#), [Pulse Measurements](#), [CPM](#)

Parameters

<num> Maximum scale value. Choose a number between the upper (Max) scale value and 100.

Examples **DISP:WIND:ANAL:UPP -10**

Query Syntax DISPlay:WINDow:ANALog:UPPer?

Default 0

Last modified:

1-Apr-2014 Added CPM
31-Oct-2013 Added Pulse

DISPlay:WINDow[:NUMeric]:RESolution <num>

(Read-Write) Set and query the number of digits of resolution to display after the decimal point.

Relevant Modes [VVM](#), [Power Meter](#), [Pulse Measurements](#), [CPM](#)

Parameters

<num> Number of digits of resolution.
For PM and Pulse modes, choose from: 0, 1, 2, 3.
For VVM mode, choose from 1,2

Examples **DISPlay:RES 1**

Query Syntax DISPlay:WINDow[:NUMeric]:RESolution?

Default 2 for PM and Pulse
1 for VVM

Last modified:

- 1-Apr-2014 Added CPM
- 31-Oct-2013 Added Pulse
- 3-Aug-2010 Added VVM mode (A.05.30)

:DISPlay:WINDow:SPLit <char>

(Read-Write) Set and query the multi-trace configuration.

Select a trace using [:CALCulate:PARAmeter:SElect](#)

Change the measurement in each plot using [:CALCulate:PARAmeter:DEFine](#)

Change the format in each plot using [CALCulate SElected FORMat](#)

Relevant Modes NA

Parameters

<char> Dual/Multi-trace configuration. Not case-sensitive. Choose from:

D1 - (x1)

D2 - (x2)

D12H - (x2H)

D1123 - (x3H) - NA mode ONLY

D12_34 - (x4) - NA mode ONLY

Examples DISP:WIND:SPL D2

Query Syntax DISPlay:WINDow:SPLit?

Default D1

Last Modified:

1-Nov-2012 removed CAT for (6.06)

26-Apr-2012 Modified for CAT (6.0)

DISPlay:WINDow:TRACe<n>:MEMory[:STATe] <bool>

(Read-Write) Set and query the display state of a memory trace. A memory trace must already be stored using [CALC:MATH:MEMorize](#).

To display both data and memory, set both to ON. [DISPlay:WINDow:TRACe:STATe](#) sets the data trace ON.

Relevant Modes CAT, NA

Parameters

<n> Trace number. If unspecified, value is set to 1.

For CAT mode Choose from 1 to 2.

For NA mode Choose from 1 to 4.

<bool> Choose from:
0 or **OFF** - Memory trace NOT displayed
1 or **ON** - Memory trace displayed

Examples `DISPlay:WINDow:TRAC1:MEM 1`

Query Syntax `DISPlay:WINDow:TRACe<n>:MEMory:STATe?`

Default 0 - Not displayed

Last Modified:

26-Apr-2012 Modified for CAT (5.75)

DISPlay:WINDow:TRACe<n>:STATe <bool>

(Read-Write) Set and query the display state of the data trace. To display both data and memory, set both to ON. `DISPlay:WINDow:TRACe{1:4}:MEMory[:STATe]` sets the memory trace ON.

Relevant Modes CAT, NA

Parameters

<n> Trace number. If unspecified, value is set to 1.
 For CAT mode Choose from 1 to 2.
 For NA mode Choose from 1 to 4.

<bool> Choose from:
0 or **OFF** - Data trace NOT displayed
1 or **ON** - Data trace displayed

Examples `DISPlay:WINDow:TRAC1:STAT 1`

Query Syntax `DISPlay:WINDow:TRACe<n>:STATe?`

Default 1 -Displayed

Last Modified:

26-Apr-2012 Modified for CAT (5.75)

DISPlay:WINDow:TRACe:Y:DLINe <num>

(Read-Write) Set and query the display line Y-axis amplitude level. To turn ON/OFF display line, use `DISPlay:WINDow:TRACe:Y:DLINe:STATe`.

Relevant Modes SA

Parameters

<num> Y-axis amplitude level. Units depend on the selected setting. See [\[:SENSe\]:AMPLitude:UNIT](#)

Examples DISP:WIND:TRAC:Y:DLIN -50

Query Syntax DISPlay:WINDow:TRACe:Y:DLINe?

Return Type Numeric

Default Depends on current units setting.

Last Modified:

1-Aug-2011 New command (A.05.50)

DISPlay:WINDow:TRACe:Y:DLINe:STATe <bool>

(Read-Write) Set and query the ON/OFF state of the Display Line. Use [DISPlay:WINDow:TRACe:Y:DLINe](#) to set the display level.

Relevant Modes SA

Parameters

<bool> Choose from:
0 or **OFF** - Display Line OFF.
1 or **ON** - Display Line ON.

Examples DISPlay:WINDow:TRAC:Y:DLIN:STAT 1

Query Syntax DISPlay:WINDow:TRACe:Y:DLINe:STATe?

Default 0 - OFF

Last Modified:

1-Aug-2011 New command

DISPlay:WINDow:TRACe<n>:Y[:SCALE]:AUTO

(Write-Only) Autoscale the trace.

Relevant Modes CAT, NA, SA, [FOPS](#)

CAT mode: this command always acts on the selected trace. Select a trace using [CALCulate:PARAmeter:SElect](#)

SA mode: this command autoscales all displayed traces.

Parameters

<n> For NA mode Only: Specify the displayed trace number. Choose from 1 to 4.
If unspecified, value is set to 1.

Examples DISPlay:WINDow:TRAC1:Y:AUTO

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

| | |
|-------------|-------------------------|
| 19-Mar-2014 | Added FOPS |
| 23-Jan-2013 | Modified again for CAT |
| 26-Apr-2012 | Modified for CAT (5.75) |

DISPlay:WINDow:TRACe<n>:Y[:SCALe]:BOTTom <num>

(Read-Write) Set and query the bottom (lower) Y-axis scale value.

Relevant Modes CAT, NA, SA

CAT mode: this command always acts on the selected trace. Select a trace using [CALCulate:PARAmeter:SElect](#)
SA - Read ONLY

Parameters

<n> NA mode Only: Specify the displayed trace number.
Choose from 1 to 4.
If unspecified, value is set to 1.

<num> Bottom scale value. Units depend on the selected format.

Examples DISP:WIND:TRAC1:Y:BOTT -50

Query Syntax DISPlay:WINDow:TRAC<n>:Y[:SCALe]:BOTTom?

Return Type Numeric

Default Depends on Mode

Last Modified:

| | |
|-------------|-------------------------|
| 23-Jan-2013 | Modified again for CAT |
| 26-Apr-2012 | Modified for CAT (5.75) |

DISPlay:WINDow:TRACe<n>:Y[:SCALe]:PDIVision <num>

(Read-Write) Set and query the Y-axis scale per division value. Use this command with [DISPlay:WINDow:TRACe:Y\[:SCALe\]:RPOSition](#) and [DISPlay:WINDow:TRACe:Y\[:SCALe\]:RLEVel](#) which establish the reference position and level.

Relevant Modes CAT, NA, SA, [FOPS](#)

CAT mode: This command always acts on the selected trace. Select a trace using [CALCulate:PARAmeter:SFLect](#)

SA mode: Applicable ONLY when [\[:SENSe\]:AMPLitude:SCALe](#) = LOG; (Units are always "dB")

Parameters

<n> NA mode Only: Specify the displayed trace number. Choose from 1 to 4.
If unspecified, value is set to 1.

<num> Scale value. Units depend on the selected format.

Examples DISP:WIND:TRAC1:Y:PDIV -.25

Query Syntax DISPlay:WINDow:TRACe<n>:Y[:SCALe]:PDIVision?

Return Type Numeric

Default Depends on Mode

Last Modified:

| | |
|-------------|-------------------------|
| 19-Mar-2014 | Added FOPS |
| 11-Nov-2013 | Modified again |
| 26-Apr-2012 | Modified for CAT (5.75) |

DISPlay:WINDow:TRACe<n>:Y[:SCALe]:RLEVel <num>

(Read-Write) Set and query the Y-axis value of the reference line. Use this command with [DISPlay:WINDow:TRACe:Y\[:SCALe\]:RPOSition](#) which sets the position of the reference.

Relevant Modes CAT, NA, SA, [FOPS](#)

CAT mode: This command always acts on the selected trace. Select a trace using [CALCulate:PARAmeter:SFLect](#)

SA mode: This command acts on all displayed traces.

Parameters

<n> NA mode Only: Specify the displayed trace number. Choose from 1 to 4.
If unspecified, value is set to 1.

<num> Y-axis reference level. Units depend on the selected format.

Examples DISP:WIND:TRAC1:Y:RLEV -50

Query Syntax DISPlay:WINDow:TRACe<n>:Y[:SCALe]:RLEVel?

Return Type Numeric

Default Depends on Mode

Last Modified:

| | |
|-------------|-------------------------|
| 20-Mar-2014 | Added FOPS |
| 23-Jan-2013 | Modified again |
| 26-Apr-2012 | Modified for CAT (5.75) |

DISPlay:WINDow:TRACe<n>:Y[:SCALe]:RPOStion <num>

(Read-Write) Set and query the position of the Y-axis reference line. Use this command with [RLEVel](#) which sets the Y-axis value of the reference line.

Relevant Modes CAT, NA, SA, [FOPS](#)

CAT mode: this command always acts on the selected trace.

SA mode: this command acts on all displayed traces.

Parameters

<n> NA mode Only: Specify the displayed trace number. Choose from 1 to 4.
If unspecified, value is set to 1.

<num> Reference position. Choose a value from 0 to 10.

Examples DISP:WIND:TRAC1:Y:BOTT -50

Query Syntax DISPlay:WINDow:TRACe<n>:Y[:SCALe]:BOTTom?

Return Type Numeric

Default Depends on Mode

Last Modified:

| | |
|-------------|-------------------------|
| 20-Mar-2014 | Added FOPS |
| 23-Jan-2013 | Modified again |
| 26-Apr-2012 | Modified for CAT (5.75) |

DISPlay:WINDow:TRACe<n>:Y[:SCALe]:TOP <num>

(Read-Write) Set and query the top (upper) Y-axis scale value.

Relevant Modes CAT, NA, SA
 CAT mode: this command always acts on the selected trace.
 SA mode: Read ONLY

Parameters

<n> NA mode Only: Specify the displayed trace number.
 Choose from 1 to 4.
 If unspecified, value is set to 1.

<num> Top scale value. Units depend on the selected format.

Examples DISP:WIND:TRAC1:Y:TOP 0

Query Syntax DISPlay:WINDow:TRACe<n>:Y[:SCALe]:TOP?

Return Type Numeric

Default Depends on Mode

Last Modified:

| | |
|-------------|-------------------------|
| 23-Jan-2013 | Modified again |
| 26-Apr-2012 | Modified for CAT (5.75) |

DISPlay:WINDow:TRACe <value>

(Read-Write) Set and query the trace to show on the screen after storing a memory trace.

Relevant Modes **FOPS**

Parameters

<value> Choose from the following:
DATA - Meas Data only
MEM - Memory only
DAM - Data and memory
DDM - Data divided by Memory (Data/Mem)

Examples **DISPlay:WINDow:TRACe dam**

Query Syntax DISPlay:WINDow:TRACe?

Return Type Character

Default DATA

Last modified:

19-Mar-2014 New command (A.07.50)

DISPlay:WINDow:ZOOM <bool>**(Read-Write)** Set and query the zoom window ON / OFF state.**Relevant Modes** [Pulse Measurements](#)**Parameters**

<bool> Choose from:
OFF or 0 - Zoom window OFF
ON or 1 - Zoom window ON

Examples `DISP:WIND:ZOOM 1`**Query Syntax** DISPlay:WINDow:ZOOM?**Default** OFF

Last modified:

31-Oct-2013 New command

FORMat:BORDER <char>**(Read-Write)** Set the byte order used for data transfer. This command is only implemented if [FORMAT:DATA](#) is set to :REAL. If FORMAT:DATA is set to :ASCII, the swapped command is ignored.**Relevant Modes** ALL**Parameters**

<char> Choose from:
NORMAL - LSB first; for "x86 or "Little Endian" computers .
SWAPped - MSB first. Use when your controller is anything other than an IBM compatible computers. Use **SWAPped** if you are using VEE, LabView, or T&M Tool kit.

NOTE: These descriptions may be reversed from other Agilent Instruments, but compliant with IEE 488.2.**Examples** FORM:BORD NORM[See example parsing program in C#.](#)**Query Syntax** FORMat:BORDER?**Default** NORMAl

Last Modified:

31-Oct-2013

New command

FORMat[:DATA] <char>

(Read-Write) Set and query the format (binary or ASCII) by which FieldFox data is read.

Data is read using the following commands:

- SA Mode: [TRACe:DATA?](#)
- NA and CAT modes: [CALCulate:DATA:FDATA?](#), [CALCulate:DATA:FMEM?](#), [CALCulate:DATA:SDATA?](#), [CALCulate:DATA:SMEM?](#)
- Calibration data (NA, CAT, and VVM modes): [\[:SENSe\]:CORRection:COEFFicient\[:DATA\]](#)

Note: Do NOT do Binary Block transfers (REAL, 32 or REAL, 64) when using over Telnet to port 5024 on FieldFox.

Relevant Modes ALL

Parameters

<char> Choose from:

- **REAL,32** - Best for transferring large amounts of measurement data.(Binary data)
- **REAL,64** - Slower but has more significant digits than REAL,32. Use REAL,64 if you have a computer that doesn't support REAL,32. (Binary data)
- **ASCIi,0** - The easiest to implement, but very slow. Use when you have small amounts of data to transfer. ASCII,0 returns a carriage return (“\n”) terminated, comma-separated list of numbers, which might be re,im pairs, or could be scalar numbers corresponding to the current instrument format (such as LogMag) for FDATA?

Notes:


The REAL,32 and REAL,64 arguments transfer data in block format. The byte order is **little endian**. FORM:BORDER, which reverses the byte order, is NOT supported.

Block Data

The following graphic shows the syntax for definite block data.

Only the **Data Byte** is sent in either Binary or ASCII format.

All other characters are ASCII format.



<num_digits> specifies how many digits are contained in <byte_count>

<byte_count> specifies how many data bytes will follow in <data bytes>

Example of Definite Block Data

```
#17ABC+XYZ<n1><end>
```

Where:

- # - always sent before definite block data (ascii format)
- 1 - specifies that the byte count is one digit (7) (ascii format)
- 7 - specifies the number of data bytes that will follow, not counting <NL><END> (ascii format)
- ABC+XYZ - Data (binary or ascii format)
- <NL><END> - always sent at the end of block data (ascii format)

Binary Data Notes:

The format is described by either REAL,32 (which indicates that each number takes 4 bytes) or REAL,64 (which indicates that each number takes 8 bytes). No separator is necessary between the numbers.

For a trace with 1001 complex points (real, imag) in REAL,64 format, the header would describe a $1001*2*8=16016$ byte block, so it would be: #516016 followed by 16016 bytes of data.

For a trace with 5 data points in LogMag format in REAL,32 format, the header would describe a $5*1*4=20$ byte block, so it would be: #220 followed by 20 bytes of data.

| | |
|--------------|--|
| Examples | FORM REAL,32 See example parsing program in C#. |
| Query Syntax | FORMat[:DATA]? |
| Default | AScii,0 |

Last Modified:

| | |
|-------------|--------------------|
| 28-Oct-2011 | Added more |
| 30-Nov-2010 | Added explanations |
| 22-Oct-2010 | New command (5.30) |

INITiate:CONTInuous <bool>

(Read-Write) Specify sweep mode for the FieldFox.

The OFF setting for this command is overlapped. This means that it will execute and also accept new commands while switching to single sweep mode.

Follow this command with [*OPC2](#) to cause the FieldFox to wait before accepting subsequent commands.

Relevant Modes ALL

Parameters

<bool> Sweep mode. Choose from:
0 or **OFF** - Single sweep mode. Use [INIT:IMM](#) to trigger a sweep.
1 or **ON** - Continuous sweep mode

Examples INIT:CONT 0;*OPC?
[See example in VVM mode](#)

Query Syntax INITiate:CONTinuous?

Return Type Boolean

Default ON - Continuous

INITiate[:IMMEDIATE]

(Write-Only) Causes the FieldFox to perform a single sweep, then hold. Use this sweep mode for reading trace data. First send [INIT:CONT 0](#) to set single sweep mode.

When in Continuous sweep mode, this command is ignored.

This command is overlapped. This means that it will execute and, while the FieldFox performs a single sweep, it will also accept new commands. Follow this command with [*OPC?](#) to cause the FieldFox to wait before accepting subsequent commands.

Relevant Modes ALL

Examples **INIT ; *OPC?**

Query Syntax Not Applicable

Default Not Applicable

INITiate:REStart

(Write-Only) Causes the FieldFox to restart trace averaging at count of 1. When in Single sweep mode, the SA will perform a complete set of averages before going to the hold state again.

This command is overlapped. This means that it will execute and, while the FieldFox performs a single sweep, it will also accept new commands. Follow this command with [*OPC?](#) to cause the FieldFox to wait before accepting subsequent commands.

Relevant Modes SA

Examples INIT:REST;*OPC?

Query Syntax Not Applicable

Default Not Applicable

INSTrument:CATalog?

(Read-Only) Read the modes available on the FieldFox.

Relevant Modes ALL

Examples Inst:Cat?
Returns:
 NA,SA,Power Meter,CAT

Return Type Comma-separated list of strings.

Default Not Applicable

INSTrument:GTL

(Write-Only) Returns front panel key press control. To lockout front panel operation, send [INST:GTR](#).

Relevant Modes ALL

Examples **INST : GTR**

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

20-Nov-2014 New command (7.75)

INSTrument:GTR

(Write-Only) Locks out the front panel key presses. **RMT** is displayed on the screen. To return to front panel operation, press **ESC** or send [INST:GTL](#).

Relevant Modes ALL

Examples **INST : GTR**

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

20-Nov-2014 New command (7.75)

INSTrument[:SElect] <string>

(Read-Write) Set and query the current operating mode. Use [Inst:CAT?](#) to read the available modes on the FieldFox.

This command is overlapped. This means that it will execute and, while the FieldFox changes mode, it will also accept new commands. Follow this command with [*OPC?](#) to cause the FieldFox to wait before accepting subsequent commands.

Relevant Modes ALL

Parameters

<string> Operating Mode. **Case-sensitive**. Choose from the modes that are installed on your FieldFox:

- "CAT"
- "NA"
- "SA"
- "Power Meter"
- "VVM"
- "Pulse Measurements"
- "ERTA"

Examples INST "NA";*OPC?

Query Syntax INSTrument[:SElect]?

Default Depends on FieldFox model

MMEMory:CATalog? [string]

(Read-Only) Returns a comma-separated string of file names.

[See ALL MMEM commands.](#)

Relevant Modes ALL

Parameters

[string] String. Optional argument. FieldFox drive/folder to catalog.
 If unspecified, the active drive/folder is cataloged.
 Use [MMEMory:CDIRectory](#) to change the active drive/folder and to learn how to specify a drive/folder.

Examples 'Read the files in the internal root folder.
 MMEM:CAT? "[INTERNAL]:"
 'Read the files in the internal Keywords folder
 MMEM:CAT? "[INTERNAL]:\Keywords"
 'Read the files in the default folder
 mmemory:catalog?

Return Type Comma-separated list of strings.

Default Not Applicable

Last Modified:

23-Apr-2012

Major modifications

MMEMory:CDIRectory <string>

(Read-Write) Change the active drive/folder. All subsequent MMEM commands will use this drive/folder as the default.

[See ALL MMEM commands.](#)

Relevant Modes ALL

Parameters

<string> Folder name enclosed in quotes. Case-sensitive. Include brackets, and colon.

Specify the following drives:

- "[INTERNAL]:" - FieldFox internal drive.
- "[SDCARD]:" - External SD card.
- "[USBDISK]:" or "[USBDISK1]:" - The first USB flash drive to be plugged into either of the FieldFox USB slots.
- "[USBDISK2]:" - The second USB flash drive to be plugged into either of the FieldFox USB slots.

Specify a folder on the drive by appending the folder name within the quotes. See examples.

The following arguments are superseded (but still accepted):

- An SD card is specified as "\Storage Card"
- A USB flash drive is specified as "\Hard Disk"
- The internal memory is specified as "\UserData"

Examples

```
'Change active drive to internal
MMEM:CDIR "[INTERNAL]:"
'On the internal drive, specify the Keywords folder
MMEM:CDIR "[INTERNAL]:\Keywords"
'Change active drive to the USB flash disk
mmemory:cdirectory "[USBDISK]:"
```

Query Syntax MMEMory:CDIRectory?

Folders on the active drive are shown in brackets as **[My Folder]**

Return Type String

Default "[INTERNAL]:"

Last Modified:

23-Apr-2012

Major modifications

MMEMory:COPY <file1>,<file2>

(Write-Only) Copies file1 to file2. Extensions must be specified.

See [MMEM:CDIR](#) to learn how to set the active drive and how to specify a drive/folder.

See [ALL MMEM commands](#).

Relevant Modes ALL

Parameters

<file1> String - Drive, folder, filename, and extension of the file to be copied. If drive and folder are unspecified, the active drive/folder is used.

<file2> String - Drive, folder, filename, and extension to be created from <file1>. If unspecified, the active drive/folder is used.

Examples

```
'Copies the existing file to the same folder with a new file name.
MMEM:COPY "MyFile.sta", "MyFile.sta"
'Copies the existing file from the active drive to the USB drive with the same file name.
MMEM:COPY "MyFile.sta", "[USBDISK]:\MyFile.sta"
```

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

23-Apr-2012 Major modifications

MMEMory:DATA <filename>,<data>

(Read-Write) Read and store <data> into the file <filename>. Because this is block data, any file format can be read.

See [MMEM:CDIR](#) to learn how to set the active drive and how to specify a drive/folder.

See [ALL MMEM commands](#).

Relevant Modes ALL

Parameters

<filename> String - Drive, folder, filename, and extension into which data will be loaded. If drive and folder are unspecified, the active drive/folder is used.

<data> Data in 488.2 block format.

Examples

```
'Stores data into "MyFile"
MMEM:DATA "MyFile",<data>
'Stores data into "MyFile" on USB
MMEM:DATA "[USBDISK]:\MyFile",<data>
See an example using this command.
```

Query Syntax MMEMory:DATA? <filename>

Default Not Applicable

Last Modified:

| | |
|-------------|-----------------------|
| 17-Dec-2013 | Added link to example |
| 23-Apr-2012 | Major modifications |

MMEMory:DELeTe <string>

(Write-Only) Deletes the specified file.

See [MMEM:CDIR](#) to learn how to set the active drive and how to specify a drive/folder.

See [ALL MMEM commands](#).

Relevant Modes ALL

Parameters

<string> String - Drive, folder, filename, and extension to delete. If unspecified, the active drive/folder is used.

Examples

```
'Delete file from active drive/folder
MMEM:DEL "MyOldFile.sta"
'Delete file from USB
MMEM:DEL "[USBDISK]:\MyOldFile.sta"
```

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

| | |
|-------------|---------------------|
| 23-Apr-2012 | Major modifications |
|-------------|---------------------|

MMEMory:LOAD:ANTenna <string>,<char>

(Write-only) Load a receiver antenna file from the specified device. If using only one antenna file, use this command.

To load a source antenna file, use MMEMory:LOAD:SANTenna.

- All SA mode Antenna files are saved and recalled as *.csv files, which allows them to also be read by spreadsheet programs.
- The FieldFox can also read *.ANT (Antenna) files that were created from older Agilent Spectrum Analyzers.
- Antenna files are saved and recalled from the "Antenna" folder. If the folder does not already exist on a USB or SD card, it is created automatically before storing the file.

See [ALL MMEM commands](#).

Relevant Modes SA

Parameters

- <string> For *.csv files, provide filename of the antenna file WITHOUT an extension.
For *.ant files, provide filename and .ant extension.
- <char> Memory device where the Antenna file is stored. Choose from the following:
 - **INT**ernal - internal storage device
 - **USB** - first USB device
 - **SD** - SD storage card

Examples `MMEM:LOAD:ANT "MyAntenna",INT`
`mmemory:load:antenna "demo_antenna_26m_3g.ant",internal`

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

- 26-Jan-2015 Modified for source
- 16-Dec-2014 Fixed .ant recall
- 29-Oct-2010 New command (5.30)

MMEMory:LOAD:CABLe <string>,<char>

(Read-Write) Loads a receiver cable file from the specified device. If using only one cable file, use this command.

To load a source cable file, use MMEMory:LOAD:SCABLE

- SA Cable files are saved as *.csv files, which allows them to also be read by spreadsheet programs.
- DTF Cable files are saved as *.xml files.
- Cable files are saved and recalled from the "Cables" folder. If the folder does not already exist on a USB or SD card, it is created automatically before storing the file.

[See ALL MMEM commands.](#)

Relevant Modes CAT, SA

Parameters

- <string> Filename of the cable file WITHOUT an extension.
- <char> Memory device where the cable file is stored. Choose from:
 - **INT**ernal - internal storage device
 - **USB** - first USB device
 - **SD** - SD storage card

Examples `MMEM:LOAD:CABL "MyCable",INT`

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

26-Jan-2015 Modified for source

29-Oct-2010 New command (5.30)

MMEMory:LOAD:STATe <string>

(Write-Only) Loads an instrument state file.

This command CAN be used with [*OPC?](#).

Relevant Modes ALL

Parameters

<string> Filename and extension of the state file.

Examples `MMEMory:LOAD:STATe "AutoSave1.sta"`

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

11-Nov-2013 Linked to Q

28-Mar-2013 Removed OPC? limitation

26-Jul-2012 Added note about *OPC?

MMEMory:MDIRectory <string>

(Write-Only) Makes a new folder.

See [MMEM:CDIR](#) to learn how to set the active drive/folder and how to specify a drive/folder.

See [ALL MMEM commands](#).

Relevant Modes ALL

Parameters

<string> Drive/folder to create. If unspecified, the folder is created in the active drive/folder.

Examples `'Folder is created in the active drive/folder`

```
MMEMory:MDIRectory "MyFolder"
'Folder is created on the USB drive.
MMEMory:MDIRectory "[USBDISK]:\MyFolder"
```

Query Syntax Not Applicable
 Default Not Applicable

Last Modified:

23-Apr-2012 Major modifications

MMEMory:MOVE <file1,<file2>

(Write-Only) Renames <file1> to <file2>. File extensions must be specified.
 See [MMEM:CDIR](#) to learn how to set the active drive/folder and how to specify a drive/folder.
 See [ALL MMEM commands](#).

Relevant Modes ALL

Parameters

- <file1> String - Drive, folder, filename, and extension of the file to be renamed. If unspecified, the active drive/folder is used.
- <file2> String - Drive, folder, filename, and extension of the new file. If unspecified, the active drive/folder is used.

Examples

```
'Rename file from/to active drive/folder.
MMEM:MOVE "OldFile.sta", "NewFile.sta"
'Rename file from active drive/folder to USB drive.
MMEM:MOVE "OldFile.sta", "[USBDISK]:\NewFile.sta"
```

Query Syntax Not Applicable
 Default Not Applicable

Last Modified:

23-Apr-2012 Major modifications

MMEMory:RDIRectory <string>[,<recursive>]

(Write-Only) Removes the specified folder if it is empty. If the folder is NOT empty, a 'Media Protected' message appears.
 See [MMEM:CDIR](#) to learn how to set the active drive/folder and how to specify a drive/folder.
 See [ALL MMEM commands](#).

Relevant Modes ALL

Parameters

- <string> String - Drive, folder from which folder is to be removed. If unspecified, the active drive/folder is used.
- <recursive> String - Optional. Case-sensitive.
- "recursive"** - Removes everything in the specified folder and all sub-folders and their contents.

Examples

```
'Removes 'oldfolder' from active drive if it is empty.
MMEMory:RDIR "OldFolder"
'Removes 'oldfolder' from USB drive
MMEMory:RDIR "[USBDISK]:\OldFolder"
'Removes 'oldfolder' and all sub-folders
MMEMory:RDIR "OldFolder","recursive"
```

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

1-Apr-2014 Added optional argument

23-Apr-2012 Major modifications

MMEMory:STOR:ANTenna <string>,<char>

(Write-only) Saves the currently-loaded receiver antenna table to a file on the specified device.

- All SA mode Antenna files are saved and recalled as *.csv files, which allows them to also be read by spreadsheet programs.
- The FieldFox can also read, but NOT save, *.ANT (Antenna) files. These files were created from older Agilent Spectrum Analyzers.
- Antenna files are saved and recalled from the "Antenna" folder. If the folder does not already exist on a USB or SD card, it is created automatically before storing the file.

[See ALL MMEM commands.](#)

Relevant Modes SA

Parameters

- <string> Filename of the antenna file WITHOUT an extension.
- <char> Memory device where the antenna file is to be stored. Choose from:
- **INTernal** - internal storage device
 - **USB** - first USB device
 - **SD** - SD storage card

Examples

```
MMEM:STOR:ANT "MyAntenna_1",USB
```


Query Syntax Not Applicable

Default Not Applicable

Last Modified:

| | |
|-------------|---------------------|
| 16-Dec-2014 | Edit to *.ant files |
| 22-Aug-2012 | Fixed example |
| 22-Oct-2010 | New command (5.30) |

MMEMory:STORe:CABLe <string>,<char>

(Read-Write) Saves the currently-loaded receiver cable table to a file at the specified location and device.

SA Cable files are saved as *.csv files, which allows them to also be read by spreadsheet programs.

DTF Cable files are saved as *.xml files.

Cable files are saved and recalled from the "Cables" folder. If the folder does not already exist on a USB or SD card, it is created automatically before storing the file.

[See ALL MMEM commands.](#)

Relevant Modes CAT (DTF), SA

Parameters

- <string> Filename of the cable file WITHOUT an extension.
- <char> Memory device where the file is to be stored. Choose from:
- **INTernal** - internal storage device
 - **USB** - first USB device
 - **SD** - SD storage card

Examples `MMEM:STOR:CABL "MyCable",INT`

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

| | |
|-------------|---------------------|
| 26-Jan-2015 | Modified for source |
| 22-Aug-2012 | Fixed example |
| 22-Oct-2010 | New command (5.30) |

MMEM:STORe:FDATa <filename>

(Write-only) Saves the selected formatted trace to a CSV file.

[See ALL MMEM commands.](#)

Relevant Modes CAT, NA, SA, [Pulse Measurements](#)

Parameters

<filename> Filename and extension into which data will be loaded.

Examples `MMEM:STOR:FDAT "MyFile.csv"`

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

31-Oct-2013 Added Pulse

23-Apr-2012 Major modifications

:MMEMory:STORe:IMAGe <string>

(Write-only) Saves the current FieldFox screen to a *.png (picture) file. This file can NOT be read by the FieldFox.

Relevant Modes ALL

Parameters

<string> Filename and extension of the *.png file.

Examples `MMEMory:STORe:IMAGe "MyPic.png"`

[See an example using this command.](#)

Query Syntax Not Applicable

Default Not Applicable

MMEMory:STORe:SNP[:DATA] <filename>

(Write-only) Saves the selected trace to an SNP file.

[See ALL MMEM commands.](#)

Relevant Modes CAT, NA

Parameters

<filename> Filename and extension to which data will be saved.
 When saving 1-port data, use *.s1p
 When saving 2-port data, use *.s2p

Examples `'With S11 trace active:`

```
MMEM:STOR:SNP "MyFile.s1p"
```

'With S21 trace active:

```
MMEM:STOR:SNP "MyFile.s2p"
```

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

23-Apr-2012

Major modifications

MMEMory:STORe:STATe <string>

(Write-only) Saves the current settings to an instrument state file.

Relevant Modes ALL

Parameters

<string> Filename and extension of the state file.

Examples **MMEMory:STORe:STATe "MyStateFile.sta"**

Query Syntax Not Applicable

Default Not Applicable

:RECPlayback:ACTion:PAUSE

(Write-Only) Recording or playback is temporarily halted. When the command is resent, recording or playback is resumed. A session should first be opened and recording or playing. Otherwise, this command is ignored.

Relevant Modes SA

Parameters None

Examples **RECP:SESS:PAUS**

Query Syntax Not Applicable

Default Not Applicable

:RECPlayback:ACTion:PLAY

(Write-Only) Plays the current Record/Playback session. (Opt 236). A session with records should first be opened and stopped. Otherwise, this command is ignored.

Relevant Modes SA

Parameters None

Examples **RECP : SESS : PLAY**

Query Syntax Not Applicable

Default Not Applicable

:RECPlayback:ACTion:RECORD

(Write-Only) Begins or resumes recording into the current Record/Playback session. (Opt 236). A session must first be opened and stopped or paused during a recording. Otherwise, this command is ignored.

Relevant Modes SA

Parameters None

Examples **RECP : SESS : REC**

Query Syntax Not Applicable

Default Not Applicable

:RECPlayback:ACTion:SPOSITION <num>

(Read-Write) Set and return a state tag position. Use this command to move to a specific state number when playback is paused.

Relevant Modes SA

Parameters

<num> Enter a value between 1 and the total number of state tags.

Examples **RECP : SESS : SPOS 2**

Query Syntax :RECPlayback:ACTion:SPOSITION?

Default Not Applicable

:RECPlayback:ACTion:STOP

(Write-Only) Stops recording or playback or a Record/Playback session. (Opt 236). A session must first be opened and recording, playing, or paused. Otherwise, this command is ignored.

Relevant Modes SA

Parameters None

Examples **RECP : SESS : STOP**

Query Syntax Not Applicable

Default Not Applicable

:RECPlayback:ACTion:TPOSITION <num>

(Read-Write) Set and return the current trace position. Use this command to move to a specific trace recording number when playback is paused.

Relevant Modes SA

Parameters

<num> Enter a value between 1 and the total number of recorded traces.

Examples `RECP:SESS:TPOS 2`

Query Syntax :RECPlayback:ACTion:TPOSition?

Default Not Applicable

:RECPlayback:CONFig:FMTRigger:DATA <data> - Superseded

Note: This command is replaced by [RECPlayback:CONFig:FMTRigger:LI Data](#) which can be used with Relative masks.

(Read-Write) Set and query the data to complete the Frequency Mask Trigger (FMT) table, used for Record Playback. Measured power levels above an upper limit and below a lower limit will trigger recording.

For ACP measurements, use [CALC:ACP:OFFS:LIST:LIMit:NEG\[:UPPer\]:DATA](#) and [CALC:ACP:OFFS:LIST:LIM:POS\[:UPPer\]:DATA](#).

Relevant Modes SA

Parameters

<data> Data for all FMT segments in the following format:

- **n** = number of segments, followed by segment data.
- each segment: **State, Type, BegStim, EndStim, BegResp, EndResp**
- Where:

State 0 for limit line disabled
1 for limit line enabled.

Type Type of limit segment. Choose from:
0 - Upper limit
1 - Lower limit

BegStim Start of X-axis value (freq, power, time)

EndStim End of X-axis value

BegResp Y-axis value that corresponds with Start of X-axis value

EndResp Y-axis value that corresponds with End of X-axis value

Subsequent segments are appended to the data in the same manner.

Examples **'The following writes three upper limit segments.
' individual segments are colored for readability.**
**RECP:CONF:FMTR:DATA 3,1,0,2e7,3e7,-
30,0,1,0,3e7,5e7,0,0,1,0,5e7,6e7,0,-30**

Query Syntax RECP:CONF:FMTR:DATA?

Return Type Block data

Default 0 - Limit line data off

Last Modified:

16-Aug-2012

Superseded A.06.00

:RECPlayback:CONF:FMTRigger:ENABLE <bool>

(Read-Write) Set and return the state of Frequency Mask Triggering. Use [RECPlayback:CONF:FMTRigger:DATA](#) to construct Frequency Mask Trigger limits.

Relevant Modes SA

Parameters

<bool> Frequency Mask Trigger state. Choose from:
 OFF or 0 - Frequency Mask Trigger disabled.
 ON or 1 - Frequency Mask Trigger enabled.

Examples **RECP:CONF:FMTR:ENABLE 1**

Query Syntax :RECPlayback:CONF:FMTRigger:ENABLE?

Default OFF

:RECPlayback:CONF:FMTRigger:LLData <data>

Note: This command replaces [RECPlayback:CONF:FMTRigger:DATA](#) which can be used ONLY with a Fixed mask. This command can also be used with Relative masks.

(Read-Write) Set and query the data to complete the Frequency Mask Trigger (FMT) table, used for Record Playback. Measured power levels above an upper limit and below a lower limit will trigger recording.

For ACP measurements, use [CALC:ACP:OFFS:LIST:LIMit:NEG\[:UPPer\]:DATA](#) and [CALC:ACP:OFFS:LIST:LIM:POS\[:UPPer\]:DATA](#).

Relevant Modes SA

Parameters

- <data> Data for all FMT segments in the following format:
- **n** = number of segments, followed by segment data.
 - Where:
 - <nL> number of FMT segments to follow
 - State** 0 - segment disabled
1 - segment enabled.
 - Fixed/Rel** 0 - Relative
1 - Fixed
 - Upper/Lower** 0 - Upper segment
1 - Lower segment
 - <nP> Number of points to follow
 - Freq value** X-axis value
 - Amp value** Y-axis value

Subsequent points are appended to the data in the same manner.

Examples `' The following writes three upper segments.
' individual segments are colored for readability.
RECP:CONF:FMTR:LLData 1,1,0,0,4,-30e6,-20,-20e6,-10,-
10e6,0,10e6,0,20e6,-10,30e6,-20`

Query Syntax RECP:CONF:FMTRigger:LLData?

Return Type Block data

Default 0 - Limit line data off

Last Modified:

16-Aug-2012 New command

:RECPlayback:CONF:PTInterval <num>

(Read-Write) Set and return the Playback Time Interval - the delay that occurs between each trace as it is played back.

Relevant Modes SA

Parameters

<num> Playback Time Interval (in seconds). Choose a delay value between 0 (play as fast as possible) and 100.

Examples `RECP:CONF:PTIN 10`

Query Syntax :RECPlayback:CONFig:PTINterval?

Default 0

:RECPlayback:CONFig:RSCLength <num>

(Read-Write) Set and return the Record Segment Counting Length - the number of traces to record, after which the recording will automatically pause. Use [Pause/Resume](#) or [Record](#) to capture another <num> traces, or [Stop](#) to end recording.

When set, a counter appears in the lower-left corner which counts UP to the specified number of recordings.

Relevant Modes SA

Parameters

<num> Number of traces to record. Choose a value between 0 (no limit to the number of traces) and 100.

Examples **RECP:CONF:RSCL 10**

Query Syntax :RECPlayback:CONFig:RSCLength?

Default OFF - NO limit to the number of traces to be recorded.

:RECPlayback:CONFig:RSORource <char>

(Read-Write) Set and return the Record Source - the location in the FieldFox data flow from where data is recorded.

Relevant Modes SA

Parameters

<num> Record Source. Choose from:
RAWM - Records raw measurement data
TRA1 - Trace 1
TRA2 - Trace 2
TRA3 - Trace 3
TRA4 - Trace 4

Examples **RECP:CONF:RSO RAWM**

Query Syntax :RECPlayback:CONFig:RSORource?

Default RAWM

:RECPlayback:CONFig:RTINerval <num>

(Read-Write) Set and return the Record Time Interval - the delay between each recording.

Relevant Modes SA

Parameters

<num> Record Time Interval (in seconds). Choose a delay value between 0 (record as fast as possible) and 10,000.

Examples **RECP:CONF:RTIN 10**

Query Syntax :RECPlayback:CONFig:RTINterval?

Default 0

:RECPlayback:CONFig:RTLSeconds <num>

(Read-Write) Set and return the Record Time limit seconds - the time duration for the recording, after which the recording will automatically pause. Use Pause/Resume to capture another <num> seconds, or Stop to end recording.

When set, a timer appears in the lower-left corner which counts DOWN from the specified number of seconds.

Relevant Modes SA

Parameters

<num> Record Time limit (in seconds). Choose a delay value between 0 (NO limit -MAX) and 1e6 seconds.

Examples **RECP:CONF:PTLS 100**

Query Syntax :RECPlayback:CONFig:RTLSeconds?

Default 0 - NO limit to the number of seconds for a recording.

:RECPlayback:SESSion:CARecords

(Write-Only) Clears all recorded traces from the currently-open Record/Playback session. (Opt 236)

Relevant Modes SA

Parameters None

<string> Filename and extension of the state file.

Examples **RECP:SESS:CAR**

Query Syntax Not Applicable

Default Not Applicable

:RECPlayback:SESSion:CLoSe

(Write-Only) Closes the currently-open Record/Playback session. (Opt 236). The session can be opened again for recording or playback using [:RECPlayback:SESSion:OPEN?](#)

| | |
|----------------|---------------------------|
| Relevant Modes | SA |
| Parameters | None |
| Examples | RECP : SESS : CLOS |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

:RECPlayback:SESSion:NEW

(Write-Only) Creates and opens a new Record/Playback session with an auto-generated name "AutoSession xx". (Opt 236).

| | |
|----------------|--------------------------|
| Relevant Modes | SA |
| Parameters | None |
| Examples | RECP : SESS : NEW |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

:RECPlayback:SESSion:OPEN? <string>

(Read-Only) Opens an existing Record/Playback session and returns 2 numbers separated by a comma.

1. The current quantity of traces in the session.
2. The current quantity of states in the session.
 - -1, -1 means nothing was opened. A session may already be open.
 - 0, 0 means the session was opened but currently empty.

| | |
|----------------|--|
| Relevant Modes | SA |
| Parameters | None |
| | <string> Name of the session to be opened, enclosed in quotes. Not case sensitive. |
| Examples | RECP : SESS : OPEN? "MyOldSession" |
| Default | Not Applicable |

:RECPlayback:SESSion:SDEvice <char>

(Read-Write) Storage device to be used for record playback. (Opt 236)

| | |
|----------------|---|
| Relevant Modes | SA |
| Parameters | |
| | <char> Storage device. Choose from: INTernal - Internal storage |

SD - SD card
 USB - USB device

Examples `RECP:SESS:SDEV USB`

Query Syntax `RECPlayback:SESSion:SDEvice?`

Default `INTernal`

:RECPlayback:SESSion:TRLimit <num>

(Read-Write) Trace record limit for the current record playback session (Opt 236). An upper limit is set when the session opens. You can reduce this value to save storage space, but you cannot increase it beyond the upper default limit.

Relevant Modes SA

Parameters

<num> Trace record limit. Choose a value from 1 to the default upper limit. Send a query before setting this value to learn the upper limit.

Examples `RECP:SESS:TRL 100`

Query Syntax `RECPlayback:SESSion:TRLimit?`

Default Not Applicable

[:SENSe]:ACPower:LIMit[:STATe] <bool>

(Read-Write) Set and query the limit testing On/Off state in an Adjacent Channel Power measurement. To establish limits, use:

`[:SENSe]:ACPower:OFFSet:LLIMit` (Lower limit)

`[:SENSe]:ACPower:OFFSet:ULIMit` (Upper limit)

Relevant Modes SA

Parameters

<bool> ACP limit testing ON | OFF state. Choose from:
0 or OFF - Limit testing OFF
1 or ON - Limit testing ON

Examples `ACPower:LIMit ON`

Query Syntax `[:SENSe]:ACPower:LIMit[:STATe]?`

Return Type Boolean

Default OFF

[:SENSe]:ACPower:MREference <num>

(Read-Write) Set and query the reference value for the measured offset power in an Adjacent Channel Power measurement. See also: [\[:SENSe\]:ACPower:MREFerence:AUTO](#)

Relevant Modes SA

Parameters

<num> Reference value in dB or dBc.

Examples ACP:MREF -1.5

Query Syntax [:SENSe]:ACPower:MREF?

Return Type Numeric

Default 0

Last Modified:

16-Aug-2012 New command

[:SENSe]:ACPower:MREFerence:AUTO <bool>

(Read-Write) Set and query the method of computing the measured carrier power from the measured offset power in an Adjacent Channel Power measurement.

Relevant Modes SA

Parameters

<bool> **Choose from:**
1 or ON (Automatic) - dB or dBc value is computed by subtracting the measured carrier power from the measured offset power.
0 or OFF (Manual) - dB or dBc value is computed by subtracting the entered Ref Value from the measured offset power. Use [\[:SENSe\]:ACPower:MREFerence](#) to enter a value.

Examples ACP:MREF:AUTO 1

Query Syntax [:SENSe]:ACPower:MREFerence:AUTO?

Return Type Boolean

Default ON

Last Modified:

16-Aug-2012 New command

[:SENSe]:ACPower:MTYPe <char>

(Read-Write) Set and query the ACP measurement type. This setting determines how the measured carrier and offset power levels are presented.

Relevant Modes SA

Parameters

<num> Measurement type. Choose from:

TPWR - Total Power Ref

PSDR - Power Spectral Density

Examples ACP:MREF -1.5

Query Syntax [:SENSe]:ACPower:MTYPE?

Return Type Character

Default TPWR

Last Modified:

16-Aug-2012

New command

[:SENSe]:ACPower:OFFSet<n>:BWIDth <num>

(Read-Write) Set and query the integration bandwidths for the 3 offset channels in an Adjacent Channel Power measurement.

Relevant Modes SA

Parameters

<n> Offset number to be set. Choose from 1, 2, or 3.

<num> Offset Integration Bandwidth in Hz. Choose a number between the Minimum Integration Bandwidth (100 Hz) and Maximum Integration Bandwidth (100 MHz)

Examples ACP:OFFS1:BWID 2e6
Sets integration bandwidth of offset 1 to 2 MHz

Query Syntax [:SENSe]:ACPower:OFFSet:BWIDth?

Return Type Numeric

Default 2 MHz

[:SENSe]:ACPower:OFFSet<n>:FREQuency <num>

(Read-Write) Set and query the Offset frequencies for all 3 offset channels in an Adjacent Channel Power measurement.

Relevant Modes SA

Parameters

<n> Offset number to be set. Choose from 1, 2, 3.

<num> Offset Channel Frequency in Hz. For each offset, choose a number between the Minimum Offset Frequency (0 Hz) and Maximum Offset Frequency (500 MHz).

Examples `ACP:OFFS1:FREQ 2e6`

Sets offset 1 to 2 MHz

Query Syntax `[:SENSe]:ACPower:OFFSet:FREQuency?`

Return Type Numeric

Default 3 MHz, 0 Hz, 0 Hz

`[:SENSe]:ACPower:OFFSet<n>:LLIMit <num>`

(Read-Write) Set and query the limit for the 3 Lower offset channels in an ACP measurement. Power measurements that exceed this limit will FAIL. To turn limit testing ON and OFF, use `[:SENSe]:ACPower:LLIMit[:STATe]`.

Relevant Modes SA

Parameters

<n> **Offset number. Choose from 1, 2, or 3**

<num> **Limit value for Lower offsets in dBc. For each offset, choose a value between 500 and -1000.**

Examples `ACP:OFFS1:LLIM -10`

Sets the first lower offset limit value to -10 dBc.

Query Syntax `[:SENSe]:ACPower:OFFSet<n>:LLIMit?`

Return Type Numeric

Default 0 dBc for all offsets

Last Modified:

17-Aug-2012

New command- replaces CALC command

`[:SENSe]:ACPower:OFFSet<n>:STATe <bool>`

(Read-Write) Set and query the On/Off state for the 3 offset channels in an Adjacent Channel Power measurement.

Relevant Modes SA

Parameters

- <n> Offset number. Choose from 1, 2, 3.
- <bool> ACP Limit Test ON | OFF state. For each offset, choose from:
 0 or OFF - Offset OFF
 1 or ON - Offset ON

Examples ACP:OFFS1:STAT ON

Query Syntax [:SENSe]:ACPower:OFFSet:STATe?

Return Type Boolean

Default ON, OFF, OFF

[:SENSe]:ACPower:OFFSet<n>:ULIMit <num>

(Read-Write) Set and query the limit for the 3 Upper offset channels in an ACP measurement. Power measurements that exceed this limit will FAIL. To turn limit testing ON and OFF, use [\[:SENSe\]:ACPower:LIMit\[:STATe\]](#).

Relevant Modes SA

Parameters

- <n> **Offset number. Choose from 1, 2, or 3**
- <num> **Limit value for Upper offsets in dBc. For each offset, choose a value between 500 and -1000.**

Examples ACP:OFFS1:ULIM -10
 Sets the first upper offset limit value to -10 dBc.

Query Syntax [:SENSe]:ACPower:OFFSet<n>:ULIMit?

Return Type Numeric

Default 0 dBc for all offsets

Last Modified:

17-Aug-2012 New command- replaces CALC command

[:SENSe]:AMPLitude:ALIGNment:NOW

(Write-only) An "InstAlign" alignment is performed once just before the next sweep and applied to subsequent sweeps. If the FieldFox is not sweeping, a single sweep is triggered and alignment is performed.

Relevant Modes SA, [CPM](#)
 All models with InstAlign (All EXCEPT N9912A)

Parameters None

| | |
|---------------------|----------------|
| Examples | AMPL:ALIG:NOW |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

Last Modified:

| | |
|-------------|--------------------|
| 1-Apr-2014 | Added CPM |
| 17-Jul-2012 | New command (6.00) |

[[:SENSe]:AMPLitude:ALIGnment[:STATe] <char>

(Read-Write) Set and query the SA mode amplitude alignment (InstAlign) state.

| | |
|-----------------------|---|
| Relevant Modes | SA, CPM |
| | All models with InstAlign capability (All EXCEPT N9912A). |

Parameters

| | |
|--------|---|
| <char> | InstAlign state. Choose from: AUTO - The alignment process is performed every 300 seconds or when the temperature has changed about 1 degree. It occurs only at the beginning of a sweep and takes about 0.5 seconds to complete. HOLD - The alignment process is stopped, but the last alignment values are applied to subsequent sweeps. OFF - The alignment process is NOT performed. Only factory correction values are used. |
|--------|---|

| | |
|---------------------|--|
| Examples | AMPL:ALIG HOLD |
| Query Syntax | [[:SENSe]:AMPLitude:ALIGnment[:STATe]? |
| Return Type | Character |
| Default | AUTO |

Last Modified:

| | |
|-------------|----------------------------------|
| 1-Apr-2014 | Added CPM |
| 28-Mar-2013 | Changed time from 30 to 300 secs |
| 17-Jul-2012 | New command (6.00) |

[[:SENSe]:AMPLitude:CORRections:ANTenna:DEFault

(Write-only) Clears the Receiver Antenna Correction table. This is the same as selecting the **New** softkey and then confirming “Yes” from the Edit/Save/Recall Antennas menu.

If using only one antenna correction, use this command.

For source antenna, use: [:SENSe]:AMPLitude:CORRections:SANTenna:DEFault

| | |
|-----------------------|-------------------|
| Relevant Modes | SA |
| Parameters | None |
| Examples | AMPL:CORR:ANT:DEF |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

Last Modified:

26-Jan-2015 Modified for Src/Rec

17-Jul-2012 New command (6.00)

[:SENSe]:AMPLitude:CORRections:ANTenna[:STATe] <bool>

(Read-Write) Set and query the Receiver Antenna Corrections ON/OFF state.

If using only one antenna correction, use this command.

For source antenna, use: [:SENSe]:AMPLitude:CORRections:SANTenna[:STATe]

| | |
|-----------------------|--|
| Relevant Modes | SA |
| Parameters | |
| <bool> | Antenna correction state. Choose from: OFF (or 0) - Antenna correction OFF. ON (or 1) - Antenna correction ON. |
| Examples | AMPL:CORR:ANT 1 |
| Query Syntax | [:SENSe]:AMPLitude:CORRections:ANTenna[:STATe]? |
| Return Type | Boolean |
| Default | OFF |

Last Modified:

26-Jan-2015 Modified for Src/Rec

17-Jul-2012 New command (6.00)

[[:SENSe]:AMPLitude:CORRections:CABLe:DEFault

(Write-only) Clears the Receiver Cable Correction table. This is the same as selecting the **New** softkey and then confirming “Yes” from the Edit/Save/Recall Antennas menu.

If using only one cable correction, use this command. For source cable, use [:SENSe]:AMPLitude:CORRections:SCABLe:DEFault

| | |
|-----------------------|--------------------|
| Relevant Modes | SA |
| Parameters | None |
| Examples | AMPL:CORR:CABL:DEF |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

Last Modified:

| | |
|-------------|----------------------|
| 26-Jan-2015 | Modified for Src/Rec |
| 17-Jul-2012 | New command (6.00) |

[[:SENSe]:AMPLitude:CORRections:CABLe[:STATe] <bool>

(Read-Write) Set and query the Receiver Cable Corrections ON/OFF state.

If using only one cable correction, use this command.

For source cable, use: [:SENSe]:AMPLitude:CORRections:SCABLe[:STATe]

| | |
|-----------------------|--|
| Relevant Modes | SA |
| Parameters | <p><bool> Cable correction state. Choose from: OFF (or 0) - Cable correction OFF. ON (or 1) - Cable correction ON.</p> |
| Examples | AMPL:CORR:CABL 1 |
| Query Syntax | [[:SENSe]:AMPLitude:CORRections:CABLe[:STATe]]? |
| Return Type | Boolean |
| Default | OFF |

Last Modified:

| | |
|-------------|----------------------|
| 26-Jan-2015 | Modified for source. |
| 20-Oct-2010 | New command (5.30) |

[[:SENSe]:AMPLitude:CORRections[:STATe] <bool>

(Read-Write) Set and query the SA mode corrections ON/OFF state. This setting is labeled "Apply Corrections" on the FieldFox softkeys.

[See all corrections commands](#)

Relevant Modes SA

Parameters

<bool> Correction state. Choose from:
OFF (or 0) - Correction OFF.
ON (or 1) - Correction ON.

Examples AMPL:CORR 1

Query Syntax [:SENSe]:AMPLitude:CORRections[:STATe]?

Return Type Boolean

Default OFF

Last Modified:

20-Oct-2010 New command (5.30)

[[:SENSe]:AMPLitude:SCALe <char>

(Read-Write) Set and query the scale type.

Relevant Modes SA

Parameters

<char> Scale type. Choose from:
LOG -units in dB
LIN - units in mV

Examples AMPL:SCAL LIN

Query Syntax [:SENSe]:AMPLitude:SCALe?

Return Type Character

Default LOG

[[:SENSe]:AMPLitude:UNIT <char>

(Read-Write) Set and query the Display Units, regardless of the current Scale setting. The UNIT choice affects the following: Reference Level, Trigger Level, Limit Lines, Marker annotation, Channel Power and Adjacent Channel Power.

This command affects the [TRACe:DATA?](#) return values.

Antenna correction units are available ONLY by loading an Antenna file that contains the desired units setting. Use [MMEMory:LOAD:ANTenna](#).

Relevant Modes SA, [CPM](#)

Parameters

<char> Display Units with Antenna correction OFF, choose from:

- W - watts
- DBM - dBm

The following are SA ONLY - not allowed for CPM

- DBMV - dB milliVolts
- DBUV - dB microvolts
- DBMA - dB milliAmps
- DBUA - dB microAmps
- V - volts
- A - amps

Examples AMPL:UNIT W

Query Syntax [:SENSe]:AMPLitude:UNIT?

Return Type Character

Default DBM

Last Modified:

24-Mar-2014 Added CPM

20-Oct-2010 New command (5.30)

[:SENSe]:AVERage:CLEar

Write-only) Resets sweep averaging to zero so that the next sweep performed will be back to AVG 1.

This command does NOT trigger the sweep.

Relevant Modes CAT, NA

Parameters None

Examples **AVER:CLE**

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

23-Aug-2011

New command

[[:SENSe]:AVERage:COUNT <num>**(Read-Write)** Set and query the number of sweep averages.**Relevant Modes** ALL**Parameters**

<num> Number of averages. Choose from: 1 to 100.
Average count of 1 = No averaging.

Examples **AVER:COUNT 10****Query Syntax** [[:SENSe]:AVERage:COUNT?**Return Type** Numeric**Default** Depends on measurement

Last Modified:

24-Mar-2014

Added

[[:SENSe]:AVERage[:ENABLE] <value>**(Read-Write)** Set and query the averaging state.**Relevant Modes** **CPM****Parameters**

<value> (Boolean) Choose from:
ON (or 1) - Averaging ON. Set the number of averages using [\[:SENSe\]:AVERage:COUNT](#)
OFF (or 0) - Performs NO averaging.

Examples AVER 1**Query Syntax** [[:SENSe]:AVERage[:ENABLE]?**Return Type** Boolean**Default** ON

Last Modified:

24-Mar-2014

New command

[[:SENSe]:AVERage[:MODE] <char>

(Read-Write) Set and query the averaging mode for Power Meter measurements.

Relevant Modes Power Meter, [Pulse Measurements](#)

Parameters

<char> Average Mode.

Choose from:

AUTO - Allows the USB Power Sensor to use its Auto Averaging settings.

MAN - Manually enter an averaging count by setting [SENSe\]:AVERage:COUNT](#)

OFF - Performs NO averaging.

Examples AVER MAN

Query Syntax [[:SENSe]:AVERage[:MODE]?

Return Type Character

Default AUTO

[[:SENSe]:AVERage:MODE <char>

(Read-Write) Set and query the averaging mode for NA measurements.

Relevant Modes NA

Only Sweep averaging is allowed in CAT mode.

Parameters

<char> Average Mode. Choose from:

SWEEp - Each data point is based on the average of the same data point being measured over <n> consecutive sweeps. The average counter shows the number of previous sweeps that have been averaged together to form the current trace. When the counter reaches the specified count, then a 'running average' of the last <n> sweeps is displayed.

POINT - Each data point is measured <n> times and averaged before going to the next data point. On subsequent sweeps, averaging restarts by measuring each data point again <n> times. The average counter is not updated because data is not displayed until all the averages have been applied.

Examples AVER:MODE POINT

Query Syntax [[:SENSe]:AVERage:MODE?

Return Type Character

Default SWEEP

Last Modified:

17-Jul-2012

New command (6.00)

[SENSe]:AVERage:SDETECT <bool>

(Read-Write) Set and query the step detection mode state for Power Meter measurements.

Relevant Modes Power Meter

Parameters

<bool> Step Detection state. Choose from:
ON (or 1) - Step Detection enabled.
OFF (or 0) - Step Detection disabled.

Examples AVER:SDET On

Query Syntax [:SENSe]:AVERage:SDETECT?

Return Type Boolean

Default ON

[SENSe]:AVERage:TYPE <char>

(Read-Write) Set and query the averaging type for SA measurements.

Relevant Modes SA

Parameters

<char> Average type. Choose from:
AUTO - The FieldFox chooses the most appropriate type of averaging for the current settings. When Detection Method is set to Average, a Noise Marker is present, or a Channel measurement is active, then Power Average is ALWAYS selected. Otherwise, Log Average is selected.
POWER - (Linear) Averaging – Best for measuring true power levels. Used in Detection Average and Noise Marker Average. Mathematically, trace noise is 2.5 dB higher than when using Log Average. **PAvg** is shown on the left side of the FieldFox screen when selected.
LOG - Best for displaying Trace Averaging. **LgAv** is shown on the left side of the FieldFox screen when selected.

Examples AVER:TYPE POW

Query Syntax [:SENSe]:AVERage:TYPE?

Return Type Character

Default AUTO

[SENSe]:BANDwidth:IF:OUT <char>

(Read-Write) Set and query IF Output state.

Relevant Modes SA Mode
 All models with an IF Output connector.

Parameters

- <char> Choose from:
- OFF** - The IF output signal is NOT processed.
 - NARRow** - The IF output signal is processed and has approximately 5 MHz bandwidth.
 - WIDE** - The IF output signal is processed and has approximately 25 MHz bandwidth.

Examples `BAND:IF:OUT NARR`

Query Syntax `[:SENSe]:BANDwidth:IF:OUT?`

Return Type Character

Default OFF

Last modified:

17-Jul-2012 New command (A.06.00)

`[:SENSe]:BANDwidth[:RESolution] <num>`

(Read-Write) Set and query the resolution bandwidth.

Relevant Modes SA

Parameters

- <num> Resolution Bandwidth in Hz. Choose from: 10 Hz to 2 MHz.
This command will accept MIN and MAX as arguments.

Examples `BAND 10e3`

Query Syntax `[:SENSe]:BANDwidth[:RESolution]?`

Return Type Numeric

Default 2 MHz

`[:SENSe]:BANDwidth[:RESolution]:AUTO <bool>`

(Read-Write) Set and query the automatic resolution bandwidth state.

Relevant Modes SA

Parameters

- <bool> Choose from:
- 0** or **OFF** - Set Resolution BW manually using `BAND:RES <num>`
 - 1** or **ON** - Automatic Bandwidth setting

| | |
|--------------|---------------------------------------|
| Examples | BAND:AUTO 0 |
| Query Syntax | [:SENSe]:BANDwidth[:RESolution]:AUTO? |
| Return Type | Boolean` |
| Default | ON |

[:SENSe]:BWIDth:VIDeo <char>

(Read-Write) Set and query the video bandwidth for the measurement.

Relevant Modes [Pulse Measurements](#)

Parameters

- <char> Video Bandwidth. Choose from the following:
- **OFF** - Video Bandwidth is disabled.
 - **LOW** - Similar to a low pass filter, ripple in the pass band is minimized but allows higher side-lobes on the filter skirt.
 - **MEDium** - Smooth pass band with reasonable transition ripple.
 - **HIGH** - The pass band ripple is similar to the OFF setting, but the transition skirts are smoother.

| | |
|--------------|------------------------|
| Examples | BWID:VID LOW |
| Query Syntax | [:SENSe]:BWIDth:VIDeo? |
| Return Type | Character |
| Default | OFF |

Last modified:

31-Oct-2013 New command

[:SENSe]:BANDwidth:VIDeo <num>

(Read-Write) Set and query the video bandwidth. Also set [BAND:VID:AUTO OFF](#).

Relevant Modes SA

Parameters

- <num> Video bandwidth. Choose a value between 1 and 2E6.

| | |
|--------------|------------------------|
| Examples | BAND:VID 1e3 |
| Query Syntax | SENSe:BANDwidth:VIDeo? |
| Return Type | Numeric |
| Default | 2E6 |

[[:SENSe]:BANDwidth:VIDeo:AUTO <bool>

(Read-Write) Set and query the ON | OFF state of Video Bandwidth.

Relevant Modes SA

Parameters

<bool> Choose from:
0 or **OFF** Set Video BW manually using BAND:VIDeo <num>
1 or **ON** Automatic Bandwidth setting.

Examples **BAND:VID:AUTO 1**

Query Syntax :SENSe:BANDwidth:VIDeo:AUTO?

Return Type Boolean

Default ON

[[:SENSe]:BURSt:ALIGnment:NOW

(Write-only) A RF Burst alignment is performed once just before the next sweep and applied to subsequent sweeps. If the FieldFox is not sweeping, a single sweep is triggered and alignment is performed.

Relevant Modes SA Mode
 All models with RF Burst triggering (All EXCEPT N9912A)

Parameters None

Examples BURS:ALIG:NOW

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

28-Mar-2013 New command (6.25)

[[:SENSe]:BURSt:ALIGnment[:STATe] <char>

(Read-Write) Set and query the SA mode RF Burst alignment state.

Relevant Modes SA Mode
 All models with RF Burst triggering capability (All EXCEPT N9912A).

Parameters

<char> RF Burst alignment state. Choose from:

AUTO - The alignment process is performed every 45 minutes or when the temperature has changed about 3 degrees. It occurs only at the beginning of a sweep and takes about 0.5 seconds to complete.

HOLD - The alignment process is stopped, but the last alignment values are applied to subsequent sweeps.

OFF - The alignment process is NOT performed.

Examples BURS:ALIG HOLD

Query Syntax [:SENSe]:BURSt:ALIGment[:STATe]?

Return Type Character

Default OFF

Last Modified:

28-Mar-2013

New command (6.25)

[:SENSe]:BWID <num>

(Read-Write) Set and query the IF Bandwidth for the measurement.

Relevant Modes NA
CAT (Read-only)
VVM

Parameters

<num> Bandwidth in Hz. Choose a value between 300 (min) and 30 kHz.

Examples **BWID 1e3**

Query Syntax SENSe:BWID?

Return Type Numeric

Default 30 kHz for NA and CAT
1 kHz for VVM

Last modified:

3-Aug-2010 Added VVM mode (A.05.30)

[:SENSe]:CMEasurement:AVERage:ENABLE <bool>

(Read-Write) Set and query the state of averaging for an SA channel measurement.

Relevant Modes SA

Parameters

<bool> Average State. Choose from:
OFF or **0** - Averaging OFF
ON or **1** - Averaging ON

Examples CME:AVER:ENAB 1

Query Syntax [:SENSe]:CMEasurement:AVERage:ENABLE?

Return Type Boolean

Default ON

[SENSe]:CMEasurement:IBW <num>

(Read-Write) Set and query the Channel Integrating Bandwidth. This value specifies the range of integration used in calculating the power in the main channel. It is applied to both ACP and Channel Power Measurements in SA mode.

Relevant Modes SA

Parameters

<num> Channel Integrating Bandwidth value in Hz. Choose a number between the Minimum Integration Bandwidth (100 Hz) and Maximum Integration Bandwidth (3 GHz).

Examples SENS:CME:IBW 3e6

Query Syntax [:SENSe]:CMEasurement:IBW?

Return Type Numeric

Default 2 MHz

[SENSe]:CMEasurement:RRCFilter <bool>

(Read-Write) Set and query the state of RRC (Root-Raised-Cosine) filter weighting for Channel Power and ACPR measurements.

Relevant Modes SA

Parameters

<bool> RRC State. Choose from:
OFF or **0** - RRC weighting OFF
ON or **1** - RRC weighting ON

Examples CME:RRCF 1

Query Syntax [:SENSe]:CMEasurement:RRCFilter?

Return Type Boolean

Default OFF

[[:SENSe]:CMEasurement:RRCFilter:ALPHA <num>

(Read-Write) Set and query the value of RRC (Root-Raised-Cosine) filter weighting for Channel Power and ACPR measurements. When RRC weighting is applied to transmitted and received power, the edges of the channel are "smoothed" to help prevent interference.

Relevant Modes SA

Parameters

<num> RRC value. Choose a value between 0 (no smoothing) and 1 (most smoothing).

Examples CME:RRCF:ALPH .50

Query Syntax [[:SENSe]:CMEasurement:RRCFilter:ALPHA?

Return Type Numeric

Default .22

[[:SENSe]:CORRection:CALReady:TYPE <char>

(Write-Read) Specifies the type of CalReady calibrations that is performed when the FieldFox is Preset.

Relevant Modes CAT, NA

To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<char> Choose from:

TWOPort - Corrects all four S-parameters. Requires a forward and reverse sweep, which causes slower trace measurements.

ERESponse - (Enhanced response) Corrects forward (S21 and S11) and reverse (S12 and S22) measurements separately. Therefore, when measurements in only one direction are required, this choice provides faster trace measurements than a full 2-port cal.

Note: There is no programming command to choose 'reciprocal' for Enhanced Response as there is from the User Interface.

Examples CORR:COLL:CALR:TYPE TWOPort

Query Syntax [[:SENSe]:CORRection:CALReady:TYPE?

Default TWOPort

Last Modified:

18-Oct-2012

New command

[[:SENSe]:CORRection:COAX <char>**(Read-Write)** Set and query the state of Cable Correction in DTF measurements.**Relevant Modes** CAT**Parameters**

<char> Choose from:

MAN - DTF cable specifications are entered manually.**AUTO** - DTF cable specifications are entered from a cable file.**Examples** **CORR:COAX MAN****Query Syntax** [[:SENSe]:CORRection:COAX?**Return Type** Character**Default** MAN**[[:SENSe]:CORRection:COEFFicient[:DATA] <char>,<resp1,stim2>,<data>****(Read-Write)** Set and query the correction coefficients (error terms) for the current calibration.**Relevant Modes** CAT, NA**Parameters**

<char> Error term. Choose from:

ES - Source match**ER** - Reflection tracking**ED** - Directivity**All models EXCEPT N9912A:****EL** - Load Match**ET** - Transmission tracking**EX** - Isolation

<resp1,stim2> Response port, Stimulus port.

For N9912A, choose **1,1**.

For all other models, choose from 1 or 2 for each port.

- For ES, ER, or ED, the response port and the stimulus port must be the same.
- For EL, ET, or EX, the response port and the stimulus port must be different.

<data> Two values per data point: (Real value, Imaginary value), separated by commas.

Examples **'Writes 3 data points of complex source match data**
CORR:COEF ES,1,1,2.626292E-01,1.823261E-01,2.537209E-
01,1.943861E-01,2.448751E-01,2.059776E-01

Query Syntax [:SENSe]:CORRection:COEFFicient[:DATA]? <char>, <resp1, stim2>

Return Type Numeric

Default Not Applicable

Last Modified:

18-Oct-2012 Added new models

[:SENSe]:CORRection:COLLect[:ACQuire]:INT <num>

(Write-Only) Measures the internal (Quick Cal) standard for the specified port. Prompt to leave the port OPEN for this step.

Use [\[:SENSe\]:CORRection:COLLect:METhod:QCALibrate:CALibrate](#) for both 1-port and 2-port QuickCal.

Use [\[:SENSe\]:CORRection:COLLect\[:ACQuire\]:LOAD](#) for the optional LOAD measurement.

This command is overlapped. This means that it will execute and, while the FieldFox measures the cal standard, it will also accept new commands. Follow this command with [*OPC2](#) to cause the FieldFox to wait before accepting subsequent commands.

Relevant Modes CAT, NA

To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<num> Port number to calibrate.
 N9912A - Choose 1 (RF OUT)
 All others - Choose 1 or 2

Examples **CORR:COLL:INT 1**
[See Cal Examples](#)

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

18-Oct-2012 Modified for new models

[[:SENSe]:CORREction:COLLect[:ACQuire]:LOAD <num>

(Write-Only) Measures the LOAD calibration standard that is connected to the specified port.

This command is overlapped. This means that it will execute and, while the FieldFox measures the cal standard, it will also accept new commands. Follow this command with [*OPC?](#) to cause the FieldFox to wait before accepting subsequent commands.

Relevant Modes CAT, NA
To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<num> Port number to which the LOAD standard is connected.
N9912A - Choose 1 (RF OUT)
All other models - Choose 1 or 2

Examples **CORR:COLL:LOAD 1**
[See Cal Examples](#)

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

18-Oct-2012 Added new models

[[:SENSe]:CORREction:COLLect[:ACQuire]:OPEN <num>

(Write-Only) Measures the OPEN calibration standard that is connected to the specified port.

This command is overlapped. This means that it will execute and, while the FieldFox measures the cal standard, it will also accept new commands. Follow this command with [*OPC?](#) to cause the FieldFox to wait before accepting subsequent commands.

Relevant Modes CAT, NA
To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<num> Port number to which the OPEN standard is connected.
N9912A - Choose 1 (RF OUT)
All other models - Choose 1 or 2

Examples **CORR:COLL:OPEN 1**
[See Cal Examples](#)

Query Syntax Not Applicable

Default Not Applicable

mode.

Parameters

<p1>,<p2> Port numbers to which the THRU standard is connected.
Choose 1,2

Examples **CORR:COLL:THRU 1,2**
[See Cal Examples](#)

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

18-Oct-2012 Reviewed for new models

[[:SENSe]:CORRection:COLLect:CKIT:LABel <port>,<ckit>

(Write-Read) Set and read the Cal Kit to use for the specified port number.

Relevant Modes CAT, NA

To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<port> Port number for the Cal Kit.
N9912A, choose 1
All other models, choose 1 or 2

<ckit> (String) Cal Kit for the specified port number. Case-sensitive.
Use [\[:SENSe\]:CORRection:COLLect:CKIT:LABel:CATalog?](#) to read a list of valid Cal Kits.

CORR:COLL:CKIT:LAB 1,"85052D"
[See Cal examples](#)

Using ECal

ECal modules that are connected to a FieldFox USB port with connectors that match the specified <port> are appended to the end of the list of valid Cal Kits that are returned using [\[:SENSe\]:CORRection:COLLect:CKIT:LABel:CATalog?](#).

NOTE: The ECal module MUST be connected.

To specify an ECal module, instead of <ckit> use the following (String) syntax:

<model>;[serial];[char index]

- <model> - ECal module model number
- [serial] - Optional argument. If unspecified, then the first module

detected with a matching model and characterization index will be used.

- [char index] - Optional argument. If unspecified, then 0 (factory characterization) is used.

The following are valid ECal specifiers:

```
'Specify all three arguments including User Char 1:
CORR:COLL:CKIT:LAB 1,"N4431A;02673;1"

'The first N4431A will be used with the Factory Characterization
CORR:COLL:CKIT:LAB 1,"N4431A"

'Use the Factory Char.
CORR:COLL:CKIT:LAB 1,"N4431A;02673"

'The first N4431A will be used with User Char 1
CORR:COLL:CKIT:LAB 1,"N4431A;;1"

See ECal example program
```

Query Syntax [:SENSe]:CORRection:COLLect:CKIT:LABel? <port>
Default Not Applicable

Last Modified:

- 26-Jul-2013 Added ECal
- 18-Oct-2012 Added new models

[:SENSe]:CORRection:COLLect:CKIT:LABel:CATalog?

(Read-Only) Reads the available Cal Kits in the FieldFox.

ECal reference strings for attached ECal modules are included in the list. The format of ECal reference strings can be found at [\[:SENSe\]:CORRection:COLLect:CKIT:LABel](#).

Relevant Modes CAT, NA

Parameters None

Examples

```
CORR:COLL:CKIT:LAB:CAT?
'Returns comma-separated strings:
'The following is NOT a complete list
"85054D", "85052D", "85039B", "85038A", "85036B/E",
"85033D/E", "85032F", "85032B/E", "85031B"

See Cal examples
```

Default Not Applicable

Last Modified:

- 26-Jul-2013 Edited for ECal

18-Oct-2012

Reviewed for new models

[[:SENSe]:CORRection:COLLect:CONNector <port>,<type -gen-,imp>**(Write-Read)** Set and read the DUT connector that will be connected to the specified FieldFox port.**Relevant Modes** CAT, NA

To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<port> Port number for the Cal Kit.

N9912A, choose 1

All other models, choose 1 or 2

<type -gen-,imp> (String) Type, gender, and impedance of the DUT connector.

> **Type:** choose from: **Type-N | 3.5 mm | 7 mm | 7/16 | Type F | Other**

- For QuickCal above 18 GHz, select **Other**.

> **Gender:** choose from one of the following when the connector type includes gender. 7mm and 7/16 do NOT include gender.

- **-M-** (Male)
- **-F-** (Female)
- **Be VERY careful with the leading and trailing dashes. Some text editors change the dash style.**
- Provide a space before each.

> **Impedance:** choose from: **50** or **75**.

- Provide a leading comma as in the following examples.

A regular expression/compact sequence for the connector name could be expressed as:

`" [^\s] .* (-M|F-) ?, \d+ "`**Examples** `CORR:COLL:CONN 1,"Type-N -M-,50"``Correction:Collect:Connector 2, "7 mm,50"`[See Cal examples](#)**Query Syntax** [[:SENSe]:CORRection:COLLect:CONNector? <port>**Default** Not Applicable

Last Modified:

22-Oct-2012 Updated for new models

16-Feb-2011 Updated

[[:SENSe]:CORRection:COLLect:ECAL:AORient <bool>

(Write-Read) Set and read the state of auto orientation for a calibration using an ECal module.

Relevant Modes CAT, NA
To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<bool> Auto orientation state. Choose from the following:
ON or **1** - Automatically detect the orientation of the ECal module.
OFF or **0** - Connect the ECal module to the FieldFox ports as prompted during calibration. Select when using low power to the module.

Examples **CORR:COLL:ECAL:AOR 1**
Sense:Correction:Collect:Ecal:Aorient off
[See Cal examples](#)

Query Syntax [[:SENSe]:CORRection:COLLect:ECAL:AORient ?

Default ON or 1

Last Modified:

26-Jul-2013 New topic

[[:SENSe]:CORRection:COLLect:ECAL:SIMPle <bool>

(Write-Read) Choose to receive a single prompt to connect the ECal or one for each reference plane.

Relevant Modes CAT, NA
To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<bool> Simple ECal state. Choose from the following:
ON or 1 (default) - The FieldFox assumes that both ports of the ECal module can be connected at both calibration reference planes. You therefore receive a single prompt to connect the ECal module to both ports.
OFF or 0 - Select when physical restrictions prohibit the ECal module from being connected to both calibration reference planes simultaneously. You will receive separate prompts to connect the ECal module to Port 1, then to connect the ECal to Port 2.

Examples **CORR:COLL:ECAL:SIMP 1**
Sense:Correction:Collect:Ecal:Simple off
[See Cal examples](#)

Query Syntax [[:SENSe]:CORRection:COLLect:ECAL:SIMPle ?

Default ON or 1

Last Modified:

1-Nov-2013 New command

[[:SENSe]:CORRection:COLLect:GUIDed:SCOunt?

(Read-Only) Returns the number of steps required to complete the guided calibration.

Relevant Modes CAT, NA
To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters None

Examples **CORR:COLL:GUID:SCO?**
[See Example Program](#)

Default Not Applicable

Last Modified:

18-Oct-2012 New command

[[:SENSe]:CORRection:COLLect:GUIDed:STEP:ACQuire <num>

(Write-Only) Measures the standard for the specified step number in the guided cal. Use [\[:SENSe\]:CORRection:COLLect:GUIDed:SCOunt](#) to read the number of steps required for the cal.

This command is overlapped. This means that it will execute and, while the FieldFox measures the cal standard, it will also accept new commands. Follow this command with ***OPC?** to cause the FieldFox to wait before accepting subsequent commands.

Relevant Modes CAT, NA
To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<num> Step number of the guided calibration.

Examples **CORR:COLL:GUID:STEP:ACQ 1**
[See Guided Cal Example](#)

Query Syntax Not Applicable

Default Not Applicable

(reverse).

Examples `CORR:COLL:METH:ERES 1,2`
[See Cal examples](#)

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

18-Oct-2012 Added new models

[[:SENSe]:CORRection:COLLect:METHod:ORESpOse <p1>

(Write-Only) During a Guided calibration, sets the Cal method to 1-port Response using an Open standard. Prompt for, then measure standards:

- [Open](#) on the <p1> port.

[Learn more about FieldFox Cal Methods using SCPL.](#)

Relevant Modes CAT, NA (NOT available on N9912A)
 To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<p1> Port number to be calibrated.

Examples `CORR:COLL:METH:ORES 2`
[See Cal examples](#)

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

25-Mar-2014 New command

[[:SENSe]:CORRection:COLLect:METHod:QCALibrate:CALibrate <p1>[,p2]

(Write-Only) Sets the Cal Method to 1-port or 2-port QuickCal.

For 1-port QuickCal:

- Prompt for [INT Stds](#) on <p1>, then optional [LOAD](#) on <p1>

For 2-port QuickCal with Insertable connectors, performs [QSOLT](#).

- Prompt for [INT Stds](#) on <p1>, then optional [LOAD](#) on <p1>, then Flush [THRU](#)

For 2-port QuickCal with Non-Insertable connectors, performs [SOLR](#).

- Prompt for [INT Stds](#) on <p1> and <p2>, then optional [LOAD](#) on <p1> and <p2>, then ANY [THRU](#).

[Learn more about FieldFox Cal Methods using SCPI.](#)

Relevant Modes CAT, NA

To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<p1> First port to calibrate.

- For N9912A, choose 1.
- For all other models, choose 1 or 2.

[p2] For all models with Full S-parameter option, second port to calibrate. Choose 1 or 2 (alternate to <p1>).

Examples `CORR:COLL:METH:QCAL:CAL 1,2`

[See Cal examples](#)

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

18-Oct-2012 Added new models

`[:SENSe]:CORRection:COLLect:METHod:QCALibrate:ERESponse <p1>,<p2>`

(Write-Only) Sets the Cal Method to QuickCal - Enhanced Response. Calibrates either forward (S11/S21) or reverse (S22/S12) measurements.

This Cal Method requires mating (insertable) DUT connectors. Use [\[:SENSe\]:CORRection:COLLect:CONNector](#) to change connector and gender.

Requires QuickCal Option.

- Prompt to "Leave ports OPEN", then use [\[:SENSe\]:CORRection:COLLect\[:ACQuire\]:INT](#) to measure internal OPEN and SHORT.
- Optional - Prompt to "Connect LOAD to ports", then use [\[:SENSe\]:CORRection:COLLect\[:ACQuire\]:LOAD](#) to measure LOAD.
- For 2-port Cal - Prompt to connect THRU between ports, then use [\[:SENSe\]:CORRection:COLLect\[:ACQuire\]:THRU](#) to measure THRU

[Learn more about FieldFox Cal Methods using SCPI.](#)

Relevant Modes N9912A with Opt 110: CAT, NA - ONLY <1,2> are supported (NOT 2,1 reverse)

All other models with Full S-parameter option, CAT, NA modes.

To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

- <p1> First port.
- For N9912A, choose 1.
 - For all other models, choose 1 or 2.
- <p2> Second port to calibrate.
- For N9912A, choose 2.
 - For all other models, choose 1 or 2 (alternate to <p1>).

Examples `CORR:COLL:METH:QCAL:ERES 1,2`
[See Cal example](#)

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

18-Oct-2012 Added new models

[[:SENSe]:CORRection:COLLect:METhod:QSOLt <p1,p2>

(Write-Only) Sets the Cal Method to 2-port QSOLT. Calibrate for sweeps in BOTH directions.

This Cal Method is NOT available on N9912A and all other models without full 2-port S-parameter option.

This Cal Method requires mating (insertable) DUT connectors. Use

[\[:SENSe\]:CORRection:COLLect:CONNector](#) to change connector and gender.

Prompt for, then measure standards:

- **OPEN**, **SHORT**, and **LOAD** on the <p1> (source) port. (This selection is NOT available from the user interface.)
- FLUSH **THRU** connection between the ports.

This Cal Method requires mating (insertable) connectors. Use [\[:SENSe\]:CORRection:COLLect:CONNector](#) to change connector and gender.

[Learn more about FieldFox Cal Methods using SCPI.](#)

Relevant Modes CAT and NA Mode

To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

- <p1,p2> Port numbers to calibrate.
 Choose **1,2** or **2,1**

Examples `CORR:COLL:METH:QSOLt 1,2`

[See Cal example](#)

Query Syntax Not Applicable
Default Not Applicable

Last Modified:

18-Oct-2012 Added new models

[[:SENSe]:CORRection:COLLect:METhod[:RESPonse]:OPEN <p1>

(Write-Only) Sets the Cal method to Open Response using a Mechanical Cal Kit.

Prompt for, then measure standards:

- **OPEN** on the <p1> port.

[Learn more about FieldFox Cal Methods using SCPL.](#)

Relevant Modes CAT, NA
 To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<p1> Port number to be calibrated.
 For N9912A and all other models without full 2-port S-parameter option, choose 1.
 For all models with full 2-port S-parameter option, choose 1 or 2.

Examples **CORR:COLL:METh:OPEN 2**
[See Cal examples](#)

Query Syntax Not Applicable
Default Not Applicable

Last Modified:

18-Oct-2012 Edited for new models

[[:SENSe]:CORRection:COLLect:METhod[:RESPonse]:SHORt <p1>

(Write-Only) Sets the Cal method to Short Response using a Mechanical Cal Kit.

Prompt for, then measure standards:

- **SHORt** on the <p1> port.
- **THRU** connection between the ports.

[Learn more about FieldFox Cal Methods using SCPL.](#)

| | |
|-----------------------|--|
| Relevant Modes | CAT, NA To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode. |
| Parameters | |
| <p1> | Port number to be calibrated. For N9912A and all other models without full 2-port S-parameter option, choose 1. For all models with full 2-port S-parameter option, choose 1 or 2. |
| Examples | CORR:COLL:METH:SHOR 1 See Cal examples |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

Last Modified:

18-Oct-2012 Edited for new models

[[:SENSe]:CORRection:COLLect:METHod[:RESPonse]:THRU <ports>**(Write-Only)** Sets the Cal method to THRU Response (also known as Normalization cal).

Prompt for, then measure standard:

- **THRU** connection between the ports.

[Learn more about FieldFox Cal Methods using SCPL.](#)

| | |
|-----------------------|--|
| Relevant Modes | CAT, NA To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode. |
| Parameters | |
| <ports> | Port numbers to be calibrated. Choose 1,2 |
| Examples | CORR:COLL:METH:THRU 1,2 See Cal examples |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

Last Modified:

18-Oct-2012 Edited for new models

[[:SENSe]:CORRection:COLLect:METHod:SOLT1 <p1>

(Write-Only) Sets the Cal Method to 1-port OSL calibration.

Prompt for, then measure standards:

- **OPEN**, **SHORT**, and **LOAD** on the <p1> (source) port.

[Learn more about FieldFox Cal Methods using SCPL.](#)

Relevant Modes CAT, NA

To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<p1> Port number to be calibrated.
For N9912A, choose 1.
For all other models, choose 1 or 2.

Examples **CORR:COLL:METH:SOLT1 1**

[See Cal examples](#)

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

18-Oct-2012 Edited for new models

[[:SENSe]:CORRection:COLLect:METHod:SOLT2 <p1,p2>

(Write-Only) Sets the Cal Method to 2-port SOLT calibration. Calibrate for sweeps in BOTH directions.

This Cal Method is NOT available on N9912A and all other models without Opt 122.

NOTE: [\[:SENSe\]:CORRection:COLLect:METHod:SOlR](#) is usually a more accurate 2-port calibration. [Learn more about FieldFox Cal Methods using SCPL.](#)

Prompt for, then measure standards:

- **OPEN**, **SHORT**, and **LOAD** on BOTH ports.
- **THRU** connection between the ports. This should be a known (characterized) THRU standard.

Relevant Modes CAT and NA Mode

To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<p1,p2> Port numbers to be calibrated. Choose 1,2.

Examples **CORR:COLL:METH:SOLT2 1,2**

[See Cal examples](#)

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

18-Oct-2012 Edited for new models

[[:SENSe]:CORRection:COLLect:METhod:SRESponse <p1>

(Write-Only) During a Guided calibration, sets the Cal method to 1-port Response using a Short standard.

Prompt for, then measure standards:

- **SHORT** on the <p1> port.

[Learn more about FieldFox Cal Methods using SCPL.](#)

Relevant Modes CAT, NA (NOT available on N9912A)

To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<p1> Port number to be calibrated.

Examples **CORR:COLL:METh:SRES 2**

[See Cal examples](#)

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

25-Mar-2014 New command

[[:SENSe]:CORRection:COLLect:METhod:TRL <p1,p2>

(Write-Only) Sets the Cal Method to 2-port TRL calibration. Calibrate for sweeps in BOTH directions.

This Cal Method is NOT available on N9912A.

Use the [Guided Calibration interface](#) to:

1. Select the DUT connectors: [\[:SENSe\]:CORRection:COLLect:CONNector](#)
2. Select a TRL Cal Kit: [\[:SENSe\]:CORRection:COLLect:CKIT:LABel](#)
3. Query number of steps: [\[:SENSe\]:CORRection:COLLect:GUIDed:SCOunt](#)
4. Display prompts: [\[:SENSe\]:CORRection:COLLect:GUIDed:STEP:PROMpt](#)
5. Acquire standards: [\[:SENSe\]:CORRection:COLLect:GUIDed:STEP:ACQuire](#)

Relevant Modes CAT and NA Mode
 To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<p1,p2> Port numbers to be calibrated. Choose 1,2.

Examples **CORR:COLL:METH:TRL 1,2**

[See Cal examples](#)

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

13-Nov-2013 New command

[[:SENSe]:CORRection:COLLect:METHod:TYPE?

(Read-Only) Query the current calibration type.

Relevant Modes CAT, NA
 To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

Examples **CORR:COLL:METH:TYPE?**

[See Cal examples](#)

Default Depends on installed options.

Last Modified:

18-Oct-2012 Edited for new models

[[:SENSe]:CORRection:COLLect:METHod:SOLR <p1>,<p2>

(Write-Only) Sets the Cal Method to Short-Open-Load-Reciprocal Thru. (Also known as 2-port Unknown Thru).

This Cal Method is NOT available on the N9912A.

Prompt for, then measure standards:

- [OPEN](#), [SHORT](#), and [LOAD](#) on the <p1> and <p2> source ports.
- [THRU](#) connection between the ports.

The Unknown Thru Standard:

- Can have up to about 40 dB of loss and long electrical length.
- Must be reciprocal: $S_{21}=S_{12}$.

[Learn more about FieldFox Cal Methods using SCPI.](#)

| | |
|-----------------------|--|
| Relevant Modes | CAT, NA To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode. |
| Parameters | |
| <p1>,<p2> | Port numbers to be calibrated. Choose 1,2 |
| Examples | CORR:COLL:METH:SOLR 1,2 See Cal examples |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

Last Modified:

18-Oct-2012 Edited for new models

[[:SENSe]:CORRection:COLLect:OISolation <bool>

(Write-Read) Set and query the state of the Omit Isolation setting.

The optional isolation step of a calibration corrects for crosstalk which is the internal signal leakage between the test ports. The additional Isolation step measures Load standards that are connected to both FieldFox test ports.

Perform an isolation calibration when you are testing a device with high insertion loss, such as the stop band of a filter or a switch in the open position. See FieldFox User's Guide for more information.

| | |
|-----------------------|---|
| Relevant Modes | CAT, NA To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode. |
| Parameters | |
| <bool> | Choose from the following: ON or 1 - Omit the Isolation step. OFF or 0 - Perform the Isolation step |
| Examples | CORR:COLL:OIS 1 Sense:Correction:Collect:Oisolation off |
| Query Syntax | [[:SENSe]:CORRection:COLLect:OISolation? |
| Default | ON or 1 |

Last Modified:

1-Nov-2013 New command

[[:SENSe]:CORRection:COLLect:SAVE <num>

(Write-Only) Ends the calibration, computes the error terms, and turns correction ON.

Relevant Modes CAT, NA
 To Cal in VVM mode, perform a Cal in CAT or NA mode, then switch to VVM mode.

Parameters

<num> Cal Set to which the Cal is saved. Choose 0

Examples **CORR:COLL:SAVE 0**

[See Cal Examples](#)

Query Syntax Not Applicable

Default Not Applicable

Last Modified:

18-Oct-2012 Reviewed for new models

[[:SENSe]:CORRection:EXTension:PORT1 <num>

(Read-Write) Set and query the port extension value on port 1.

Use [\[:SENSe\]:CORRection:EXTension\[:STATe\]](#) to turn port extensions ON and OFF.

Use [\[:SENSe\]:CORRection:RVELOCITY:COAX](#) to set velocity factor.

Relevant Modes CAT, NA

Parameters

<bool> Port extension in seconds. Choose a value between -10.0 to +10.0.

Examples **CORR:EXT:PORT1 1e-10**

Query Syntax [:SENSe]:CORRection:EXTension:PORT1?

Return Type Numeric

Default 0

Last Modified:

10-Aug-2010 New command (5.30)

[[:SENSe]:CORRection:EXTension:PORT2 <num>

(Read-Write) Set and query the port extension value on port 2.

Use [\[:SENSe\]:CORRection:EXTension\[:STATe\]](#) to turn port extensions ON and OFF.

Use [\[:SENSe\]:CORRection:RVELocity:COAX](#) to set velocity factor.

Relevant Modes CAT, NA

Parameters

<bool> Port extension in seconds. Choose a value between -10.0 to +10.0.

Examples **CORR:EXT:PORT2 1e-10**

Query Syntax [:SENSe]:CORRection:EXTension:PORT2?

Return Type Numeric

Default 0

Last Modified:

10-Aug-2010 New command (5.30)

[[:SENSe]:CORRection:EXTension[:STATe] <bool>

(Read-Write) Set and query the port extension ON | OFF state.

Use [\[:SENSe\]:CORRection:EXTension:PORT1](#) and [\[:SENSe\]:CORRection:EXTension:PORT2](#) to set port extensions value.

Use [\[:SENSe\]:CORRection:RVELocity:COAX](#) to set velocity factor.

Relevant Modes CAT, NA

Parameters

<bool> Port extensions state. Choose from:

0 or **OFF** - Port extensions OFF

1 or **ON** - Port extensions ON

Examples **CORR:EXT 1**

Query Syntax [:SENSe]:CORRection:EXTension[:STATe]?

Return Type Boolean

Default OFF

Last Modified:

10-Aug-2010 New command (5.30)

[[:SENSe]:CORRection:GAIN2[:INPut][:MAGNitude] <num>

(Read-Write) Set and query the Power Meter Offset value.

Relevant Modes [Power Meter](#), [Pulse Measurements](#), [CPM](#)

Parameters

<bool> Offset value in dB. A positive value compensates for a component with loss. A negative value compensates for a component with gain.

Examples **CORR:GAIN2 3**

Query Syntax [:SENSe]:CORRection:GAIN2?

Return Type Numeric

Default 0

Last modified:

1-Apr-2014 Added CPM

31-Oct-2013 Added Pulse

[[:SENSe]:CORRection:GAIN2:STATe <bool>

(Read-Write) Set and query the ON | Off state of Power Meter Offset.

Relevant Modes [Power Meter](#), [Pulse Measurements](#), [CPM](#)

Parameters

<bool> Offset state. Choose from:
0 or OFF - Offset OFF
1 or ON - Offset ON

Examples **CORR:GAIN2:STAT 1**

Query Syntax [:SENSe]:CORRection:GAIN2:STATe?

Return Type Boolean

Default 0

Last modified:

1-Apr-2014 Added CPM

31-Oct-2013 Added Pulse

[[:SENSe]:CORRection:IMPedance[:INPut][:MAGNitude] <num>

(Read-Write) Set and query the system impedance.

Relevant Modes NA

Parameters

<num> System impedance. Choose either 50 or 75.

Examples **CORR:IMP 75**

Query Syntax [:SENSe]:CORRection:IMPedance[:INPut][:MAGNitude]?

Return Type Numeric

Default 50

[[:SENSe]:CORRection:LOSS:COAX <num>

(Read-Write) Set and query the electrical loss of transmission cable to be used with DTF measurements.

Relevant Modes CAT

Parameters

<num> Loss in dB.

Examples **CORR:LOSS:COAX .5**

Query Syntax [:SENSe]:CORRection:LOSS:COAX?

Return Type Numeric

Default 0

[[:SENSe]:CORRection:LOSS:WAVeguide

Type topic text here.

[[:SENSe]:CORRection:MEDIum <char>

(Write-Read) Set and query the calibration media type.

If the measurement requires electrical delay or port extensions, available ONLY in NA Mode, you must specify the waveguide Media Type and Cutoff Frequency. These settings are needed to help specify dispersion. They are NOT used if electrical delay and port extensions are both zero.

Relevant Modes NA, CAT

Parameters

<bool> Media type. Choose from the following:
COAX - Calibration standards are coaxial.
WAVeguide - Calibration standards are waveguide.

Examples `CORR:MED WAV`
Sense:Correction:Medium Waveguide
[See Cal examples](#)

Query Syntax `[:SENSe]:CORRection:MEDium?`

Default COAX

Last Modified:

1-Nov-2013 New command

[:SENSe]:CORRection:RVELocity:COAX <num>

(Read-Write) Set and query the velocity factor to be used with DTF measurements (CAT mode) and with Port Extensions (NA mode).

Relevant Modes CAT, NA

Parameters

<num> Velocity factor. Choose a number between 0 and 1
 .66 = polyethylene dielectric
 .7 = PTFE dielectric

Examples `CORR:RVEL:COAX .7`

Query Syntax `[:SENSe]:CORRection:RVELocity:COAX?`

Return Type Numeric

Default 1

Last Modified:

27-Apr-2012 Edited for PTFE
 10-Aug-2010 New command for NA mode (5.30)

[:SENSe]:CORRection[:STATe] <bool>

(Read-Write) Set and query the correction ON | OFF state.
 This will turn ALL calibration OFF, including "Cal Ready". This can NOT be done from the user-interface.
 See also [\[:SENSe\]:CORRection:USER\[:STATe\]](#)

Relevant Modes CAT, NA

Parameters

<bool> Correction state. Choose from:

0 or OFF - Error Correction OFF

1 or ON - Error Correction ON

Examples CORR 1

Query Syntax [:SENSe]:CORRection[:STATe]?

Return Type Boolean

Default ON

Last Modified:

18-Oct-2012 Edited for new models

[:SENSe]:CORRection:USER:FREQuency:STARt:MINimum

Type topic text here.

[:SENSe]:CORRection:USER:FREQuency:STOP:MAXimum

Type topic text here.

[:SENSe]:CORRection:USER[:STATe] <bool>

(Read-Write) Set and query the User Calibration (correction) ON | OFF state.

N9912A - This includes Preset Cal correction.

All other models - This does NOT include "Cal Ready" correction, which can ONLY be turned OFF using [\[:SENSe\]:CORRection\[:STATe\]](#).

Relevant Modes CAT, NA

Parameters

<bool> User calibration state. Choose from:

0 or OFF - User calibration OFF

1 or ON - User calibration ON

Examples CORR 1

Query Syntax [:SENSe]:CORRection:USER[:STATe]?

Return Type Boolean

Default On after calibration

Last Modified:

18-Oct-2012 Edited for new models

[[:SENSe]:CORRection:USER:WGCutoff

Type topic text here.

[[:SENSe]:CORRection:WAVeguide:STANdard <char>

(Read-Write) Set and query the waveguide standard to use for the measurement. See also [\[:SENSe\]:CORRection:MEDium](#).

Relevant Modes CAT

Parameters

<char> Waveguide standard. Choose from:
 USER - A predefined user standard.
 WR137
 WR90
 WR42
 WR112

Examples **CORR:WAV:STAN WR137**

Query Syntax [:SENSe]:CORRection:WAVeguide:STANdard?

Return Type Character

Default FieldFox model dependent.

Last Modified:

25-Mar-2014 New command

[[:SENSe]:CORRection:WGCutoff <num>

(Read-Write) Set and query the waveguide cutoff frequency. This is the minimum frequency of the waveguide. See also [\[:SENSe\]:CORRection:MEDium](#).

Relevant Modes NA, CAT

Parameters

<num> Waveguide cutoff frequency in Hz. The value is usually on the data sheet of the Waveguide Cal Kit.

Examples **CORR:WGC 100e6**

Query Syntax [:SENSe]:CORRection:WGCutoff?

Return Type Numeric

Default 18 GHz

Last Modified:

1-Nov-2013

New command

[[:SENSe]:CORRection:ZERO:REFerence <char>**(Read-Write)** Set and query the reference to use when zero is performed.**Relevant Modes** VVM**Parameters**

<char> VVM Zero reference. Choose from:
OPEN - Display Phase = 0.0 Deg when zeroed.
SHORT - Display Phase = 180.0 Deg when zeroed

Examples **CORR:ZERO:REF SHOR****Query Syntax** [[:SENSe]:CORRection:ZERO:REFerence?**Return Type** Character**Default** OPEN

Last Modified:

22-Sept-2014

New command

[[:SENSe]:CORRection:ZERO:STATe <char>**(Read-Write)** Set and query the Zero State of a VVM measurement.**Relevant Modes** VVM**Parameters**

<char> VVM Zero state. Choose from:
OFF - Set Zeroing OFF
ON - Zero the measurement

Examples CORR:ZERO:STAT OFF**Query Syntax** [[:SENSe]:CORRection:ZERO:STATe?**Return Type** Character**Default** OFF**[[:SENSe]:DETEctor:FUNCTion <char>****(Read-Write)** Set and query the SA detector function.

Relevant Modes SA

Parameters

<bool> Choose from:
 AUTO
 NORMal
 POSitive
 NEGative
 SAMPlE
 AVERage

Examples **DET:FUNC POS**

Query Syntax [:SENSe]:DETECTOR:FUNCTION?

Return Type Character

Default AUTO

[:SENSe]:FREQUENCY <num>

(Read-Write) Set and query the frequency of the power meter measurement. This is used to set the proper correction value of the power sensor.

Relevant Modes Power Meter, [Pulse Measurements](#), [CPM](#)

Parameters

<num> Frequency in Hz. Choose a number between the minimum and maximum frequency of the FieldFox.
 This command will accept MIN and MAX as arguments.

Examples **FREQ 10E6**
FREQ MAX

Query Syntax [:SENSe]:FREQUENCY?

Return Type Numeric

Default Center frequency of the FieldFox

Last Modified:

| | |
|-------------|-------------|
| 1-Apr-2014 | Added CPM |
| 29-Oct-2013 | Added Pulse |

[:SENSe]:FREQUENCY:CENTER <num>

(Read-Write) Set and query the center frequency of the trace. This is also used for single frequency (CW)

traces, such as the frequency of power meter measurements.

Relevant Modes CAT, NA, SA, VVM

Parameters

<num> Center frequency in Hz. Choose a number between the minimum and maximum frequency of the FieldFox.

This command will accept MIN and MAX as arguments.

Examples **FREQ:CENT 10E6**

FREQ:CENT MAX

Query Syntax [:SENSe]:FREQuency:CENTer?

Return Type Numeric

Default CAT, NA, SA modes - Center frequency of the FieldFox.
VVM mode - 2 MHz

[:SENSe]:FREQuency:CENTer:STEP <num>

(Read-Write) Set and query the step size for use with the front panel up/down keys.

Use [\[:SENSe\]:FREQuency:CENTer:STEP:AUTO](#) to set step size manually. (Not available with CPM).

Relevant Modes SA, CPM

Parameters

<num> Step size in Hz. Choose a number between 1 and maximum frequency of the FieldFox.

Examples **FREQ:CENT:STEP 10E6**

Query Syntax [:SENSe]:FREQuency:CENTer:STEP?

Return Type Numeric

Default Dependent on frequency span

Last Modified:

1-Apr-2014

Added CPM

[:SENSe]:FREQuency:CENTer:STEP:AUTO <bool>

(Read-Write) Set and query the state of setting center frequency step size. Used with the front panel up/down keys.

Relevant Modes SA

Parameters

<bool> Step size state. Choose from:

ON or **1** - Step size is set automatically. Each press of the ▲|▼ arrows increments or decrements the value by 1/10th (one division) of the current frequency span.

OFF or **0** - Step size is set manually with `[[:SENSe]:FREQuency:CENTer:STEP.`

Examples `FREQ:CENT:STEP:AUTO 1`
`sense:frequency:center:step:auto off`

Query Syntax `[[:SENSe]:FREQuency:CENTer:STEP:AUTO?`

Return Type Boolean

Default ON or 1

`[[:SENSe]:FREQuency:DATA?`

(Read-Write) Returns a comma separated array of the current x-axis frequency values. The size of the array equals the number of data points.

Relevant Modes CAT, NA

Parameters None

Examples `FREQ:DATA?`

Return Type Comma-separated numeric array

Default Not Applicable

Last Modified:

4-May-2016

New command

`[[:SENSe]:FREQuency:SPAN <num>`

(Read-Write) Set and query the frequency span of the trace.

Relevant Modes [CAT](#), [NA](#), [SA](#), [CPM](#)

CPM Mode: Limited to between 10 Hz and 100 MHz. SPAN is equivalent to the “channel power integration bandwidth”.

Parameters

<num> Frequency span in Hz. Choose a number between the maximum MINUS the minimum frequency of the FieldFox.

This command will accept MIN and MAX as arguments.

Examples `FREQ:SPAN 10E6`
`FREQ:SPAN MIN`

Query Syntax `[[:SENSe]:FREQuency:SPAN?`

| | |
|--------------------|--|
| Return Type | Numeric |
| Default | Maximum MINUS minimum frequency range of the FieldFox. |

Last Modified:

1-April-2014 Added CPM

[[:SENSe]:FREQuency:SPAN:FULL

(Write-Only) Set the frequency span to the entire span of the FieldFox.

| | |
|-----------------------|---------------------------|
| Relevant Modes | SA |
| Parameters | None |
| Examples | FREQ : SPAN : FULL |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

[[:SENSe]:FREQuency:SPAN:ZERO

(Write-Only) Set the frequency span to 0 Hz. The center frequency is unchanged.

| | |
|-----------------------|---------------------------|
| Relevant Modes | SA |
| Parameters | None |
| Examples | FREQ : SPAN : ZERO |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

[[:SENSe]:FREQuency:STARt <num>

(Read-Write) Set and query the start frequency of the trace.

| | |
|-----------------------|---|
| Relevant Modes | CAT, NA, SA |
| Parameters | |
| <num> | Start frequency in Hz. Choose a number between the minimum and maximum frequency of the FieldFox. This command will accept MIN and MAX as arguments. |
| Examples | FREQ : STAR 10E6 FREQ : STAR MIN |
| Query Syntax | [[:SENSe]:FREQuency:STARt? |

Return Type Numeric
Default Start frequency of the FieldFox

[[:SENSe]:FREQuency:STEP <value>

(Read-Write) Set and query the frequency step size between data points. This is another method to set the number of data points for the measurement.

Relevant Modes EQPS (Opt 208)

Parameters

<value> Frequency step size in Hz.

Examples **FREQ:STEP 1e6**

Query Syntax [:SENSe]:FREQuency:STEP?

Return Type Numeric

Default 50 kHz

Last modified:

19-Mar-2014 New command (A.07.50)

[[:SENSe]:FREQuency:STOP <num>

(Read-Write) Set and query the stop frequency of the trace.

Relevant Modes CAT, NA, SA

Parameters

<num> Stop frequency in Hz. Choose a number between the minimum and maximum frequency of the FieldFox.

This command will accept MIN and MAX as arguments.

Examples **FREQ:STOP 10E6**

FREQ:STOP MAX

Query Syntax [:SENSe]:FREQuency: STOP?

Return Type Numeric

Default Stop frequency of the FieldFox

[[:SENSe]:MEASurement:AOFF

(Write-Only) Turns OFF the currently-displayed Channel or Interference Analysis measurements. Reverts to standard SA display.

| | |
|----------------|--------------------|
| Relevant Modes | SA |
| Parameters | None |
| Examples | MEAS : AOFF |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

[[:SENSe]:MEASurement:CHANnel <char>

(Read-Write) Set and query the current SA mode channel measurement.

| | |
|----------------|---|
| Relevant Modes | SA |
| Parameters | <p><char> Channel measurement. Choose from:</p> <p>CHP - Channel Power</p> <p>OBW - Occupied Bandwidth</p> <p>ACPR - Adjacent Channel Power</p> <p>NONE - No current channel measurement.</p> |
| Examples | MEAS : CHAN ACPR |
| Query Syntax | [[:SENSe]:MEASurement:CHANnel? |
| Return Type | Character |
| Default | NONE |

SENSe:MEASurement:ERTA:PNID

(Read-Write) Set and query the partner IP address.

| | |
|----------------|---|
| Relevant Modes | ERTA |
| Parameters | <p><string> Network identity of the partner (source) FieldFox, enclosed in quotes. Currently we recommend using the IP address. But in the future, we may accept a hostname string.</p> |
| Examples | MEAS : ERTA : PNID "192.168.0.0" |
| Query Syntax | [[:SENSe]:MEASurement:ERTA:PNID? |
| Return Type | String |
| Default | Not applicable |

Last Modified:

4-May-2015

New command (8.04)

[[:SENSe]:MEASurement:ERTA:PSTatus

(Read-Write) Set and read Partnership status. Can only set Master (Receiver).

Relevant Modes [ERTA](#)

Parameters

<char> Receiver status. Choose from:
OFF - No partnership exists.
MAST - Master status

Examples **MEAS:ERTA:PST OFF**

Query Syntax [:SENSe]:MEASurement:ERTA:PSTatus?

Return Type Character

Default OFF

Last Modified:

20-Jan-2015

New command (8.00)

[[:SENSe]:MEASurement:ERTA:PVERIFY?

(Read-only) Returns whether or not the partner (source) FieldFox is ERTA network capable.

Relevant Modes [ERTA](#)

Parameters None

Return Type Boolean
1 - Partner is ERTA capable.
0 - Partner is NOT ERTA capable

Default Not applicable

Last Modified:

4-May-2015

New command (8.04)

[[:SENSe]:MEASurement:ERTA:ROLE?

(Read-only) Read the ERTA stimulus-response role.

| | |
|-----------------------|---|
| Relevant Modes | ERTA |
| Parameters | None |
| Return Type | Character |
| | NONE - No partnership exists. |
| | SRC - FieldFox is a Source (follower). |
| | RCVR - FieldFox is a Receiver (master) |
| Default | None |

Last Modified:

20-Jan-2015 New command (8.00)

[[:SENSe]:MEASurement:INTerference <char>

(Read-Write) Set and query the current SA mode Interference Analysis (Opt 236) display.

| | |
|-----------------------|---|
| Relevant Modes | SA |
| Parameters | |
| | <char> Interference Analysis display. Choose from: |
| | SPECTrogram |
| | WATERfall |
| | NONE - no Interference Analysis measurement displayed. |
| Examples | MEAS : INT SPEC |
| Query Syntax | [[:SENSe]:MEASurement:INTerference? |
| Return Type | Character |
| Default | NONE |

[[:SENSe]:MEASurement:PRESet

(Write-Only) Resets the currently-displayed channel measurement to its default settings. The Center Frequency, Preamp ON|OFF, RF Attenuation, Markers, Limits, and Radio Standard settings are NOT reset.

| | |
|-----------------------|--------------------|
| Relevant Modes | SA |
| Parameters | None |
| Examples | MEAS : PRES |
| Query Syntax | Not Applicable |

Default Not Applicable

[[:SENSe]:MEAS:TAListen <char>

(Read-Write) Set and query the Tune and Listen demodulation type for SA Mode.

Relevant Modes SA

Parameters

<char> Tune and Listen demodulation type. Choose from:
AM - AM
FMN - FM Narrow
FMW - FM Wide
NONE - Tune and Listen OFF.

Examples **MEAS:TAL FMW**

Query Syntax [:SENSe]:MEAS:TAListen?

Return Type Character

Default NONE

[[:SENSe]:OBW:PPOW <num>

(Read-Write) Set and query the Power Percent for an Occupied Bandwidth measurement.

Relevant Modes SA

Parameters

<num> Power Percent. Choose a number from 10 to 99.99.

Examples **OBW:PPOW 20**

Query Syntax [:SENSe]:OBW:PPOW?

Return Type Numeric

Default 10

[[:SENSe]:POINT:DWELI <value>

(Read-Write) Set and query the settling time after the internal source steps to the next frequency and before the power sensor makes a measurement.

Relevant Modes **FOPS** (Opt 208)

Parameters

<value> Dwell time in seconds.

Examples **POIN:DWEL .01**

Query Syntax [:SENSe]:POINt:DWELl?

Return Type Numeric

Default 0

Last modified:

19-Mar-2014 New command (A.07.50)

[:SENSe]:POINt:READ:MAX <value>

(Read-Write) Set and query the maximum number of readings the power sensor will make to achieve settling.

Each power sensor reading is "settled" when either:

- two consecutive readings are within the Tolerance value (see [\[:SENSe\]:TOL](#)) or
- when the Max Number of Readings has been met.

The readings that were taken are averaged together to become the "settled" reading.

Relevant Modes [FOPS](#) (Opt 208)

Parameters

<value> Max number of readings. Choose a value between 1 and 20

Examples **POIN:READ:MAX 5**

Query Syntax [:SENSe]:POINt:READ:MAX?

Return Type Numeric

Default 4

Last modified:

19-Mar-2014 New command (A.07.50)

[:SENSe]:POWer[:RF]:ATTenuation <num>

(Read-Write) Set and query RF attenuation value. Also set [POW:ATT:AUTO OFF](#).

Relevant Modes [SA](#), [CPM](#)

Parameters

<num> Attenuation value in dB. Choose a number between the minimum and maximum

attenuation of the FieldFox.

This command will accept MIN and MAX as arguments.

CPM mode only accepts two values: 10 dB or 30 dB

Examples `POW:ATT 30`

Query Syntax `[:SENSe]:POWer[:RF]:ATTenuation?`

Return Type Numeric

Default 10

Last Modified:

1-April-2014

Added CPM

[:SENSe]:POWer[:RF]:ATTenuation:AUTO <bool>

(Read-Write) Set and query the Auto RF Attenuation state.

Relevant Modes SA

Parameters

<num> Auto RF Attenuation state. Choose from:
0 or **OFF** - RF Attenuation is set manually
1 or **ON** - RF Attenuation is set automatically

Examples `POW:ATT:AUTO 1`

Query Syntax `[:SENSe]:POWer[:RF]:ATTenuation:AUTO?`

Return Type Boolean

Default ON

[:SENSe]:POWer[:RF]:EXTGain <num>

(Read-Write) Set and query external gain value. Use to compensate the trace and scale when using an external amp or attenuator. May automatically increase the amount of attenuation.

Relevant Modes SA

Parameters

<num> Amount of gain (positive value) or loss (negative value) in dB.
 This command will accept MIN and MAX as arguments.

Examples `POW:EXTG 10`

Query Syntax `[:SENSe]:POWer[:RF]:EXTGain?`

Return Type Numeric

Default 0

[[:SENSE]:POWER[:RF]:GAIN[:STATE] <bool>

(Read-Write) Set and query preamplifier state. Available with Option 235.

Relevant Modes SA

Parameters

<bool> Preamp ON | OFF state. Choose from:
 0 or OFF - Preamp OFF
 1 or ON - Preamp ON

Examples **POW:GAIN 0**

Query Syntax [:SENSE]:POWER[:RF]:GAIN[:STATE]?

Return Type Boolean

Default OFF

[[:SENSE]:QUANtity:TACTive?

(Read-only) Returns the number of active traces and the number of traces that are currently allowed.

Some SA measurements allow only one measurement trace, such as Channel Mode measurements. In this case, 1,1 would be returned.

Use [TRACe<n>:DATA?](#) to read SA trace data.

Use [TRACe<n>:TYPE](#) to set the trace type.

Relevant Modes SA

Parameters

Examples **QUAN:TACT?**

**'With a general SA measurement active, returns 1,4
 'With a Channel power measurement active, returns 1,1**

Return Type Numeric, Numeric

Default 1,4

Last Modified:

20-Oct-2010

New command (5.30)

[[:SENSE]:RADio:CHANnel:CENTer <num>

(Read-Write) Set and query the channel number that appears in the center of the current channel measurement. First select a Radio Standard `[[:SENSe]:RADio:STANdard` then activate the channel frequency-drive commands by changing `[[:SENSe]:RADio:TEUNit` to **CHAN**.

Relevant Modes [SA](#), [CPM](#)

Parameters

<num> Channel number. The range of valid channel numbers depends on the current radio standard. If a channel number outside the acceptable range is entered, the channel will be set to the closest valid channel number.

Examples RAD:CHAN:CENT 10

Query Syntax [[:SENSe]:RADio:CHANnel:CENTer?

Return Type Numeric

Default Center channel of the radio standard.

Last Modified:

1-Apr-2014 Added CPM

[[:SENSe]:RADio:CHANnel:DIRection <char>

(Read-Write) Set and query the frequency Uplink or Downlink direction. First select a Radio Standard `[[:SENSe]:RADio:STANdard` then activate the channel frequency-drive commands by changing `[[:SENSe]:RADio:TEUNit` to **CHAN**.

NOT all Radio Standards contain Uplink and Downlink frequencies.

Relevant Modes [SA](#), [CPM](#)

Parameters

<char> Choose from:
UP - Uplink
DOWN - Downlink

Examples RAD:CHAN:DIR UP

Query Syntax [[:SENSe]:RADio:CHANnel:DIRection?

Return Type Character

Default DOWN

Last Modified:

1-Apr-2014 Added CPM

[[:SENSe]:RADio:CHANnel:STARt <num>

(Read-Write) Set and query the channel number that appears at the start (left edge) of the current channel measurement. First select a Radio Standard [\[:SENSe\]:RADio:STANdard](#) then activate the channel frequency-drive commands by changing [\[:SENSe\]:RADio:TEUNit](#) to **CHAN**.

Relevant Modes SA

Parameters

<num> Channel number. The range of valid channel numbers depends on the current radio standard. If a channel number outside the acceptable range is entered, the channel will be set to the closest valid channel number.

Examples RAD:CHAN:STAR 10

Query Syntax [:SENSe]:RADio:CHANnel:STARt?

Return Type Numeric

Default -1 (Start and Stop channels not activated)

[[:SENSe]:RADio:CHANnel:STEP <num>

(Read-Write) Set and query the channel number step size which determines the number of channels that are incremented and decremented each time the Up/Down arrows are pressed on the FieldFox front-panel.

First select a Radio Standard [\[:SENSe\]:RADio:STANdard](#) then activate the channel frequency-drive commands by changing [\[:SENSe\]:RADio:TEUNit](#) to **CHAN**.

Relevant Modes SA, CPM

Parameters

<num> Channel number step size. Choose a value between 1 and 100.

Examples RAD:CHAN:STEP 10

Query Syntax [:SENSe]:RADio:CHANnel:STEP?

Return Type Numeric

Default 1

Last Modified:

1-Apr-2014

Added CPM

[[:SENSe]:RADio:CHANnel:STOP <num>

(Read-Write) Set and query the channel number that appears at the stop (right edge) of the current channel measurement. First select a Radio Standard [\[:SENSe\]:RADio:STANdard](#) then activate the channel frequency-drive commands by changing [\[:SENSe\]:RADio:TEUNit](#) to **CHAN**.

Relevant Modes SA

Parameters

<num> Stop channel number. The range of valid channel numbers depends on the current radio standard. If a channel number outside the acceptable range is entered, the channel will be set to the closest valid channel number.

Examples RAD:CHAN:STOP 10

Query Syntax [:SENSe]:RADio:CHANnel:STOP?

Return Type Numeric

Default -1 (Start and Stop channels not activated)

[:SENSe]:RADio[:SELEct]:STANdard <char> - Obsolete

The command is replaced with [\[:SENSe\]:RADio:STANdard\[:SELEct\]](#) which uses a string argument. (Read-Write) Set and query the Radio Standard for use in channel measurements.

Relevant Modes SA

Parameters

<char> Radio Standard. Not case-sensitive. Choose from:

- NONE
- GSM450
- GSM480
- GSM850
- GSM900
- EGSM900
- RGSM900 // more band extension beyond E-GSM 900
- GSM1800
- GSM1900
- IDEN800
- IDEN900
- WCDMA850
- WCDMA1900
- WCDMA2100
- WCDMAAWS
- TDSCDMACHINA
- CDMA2K850
- CDMA2K1900
- CDMA2KJAPAN
- CDMA2KKOREA
- LTE700US // E-UTRA band 13 for 700M US LTE
- LTE2600 // E-UTRA band 7 for 2600M International LTE
- WIMAXMOBILE
- DVBTVHF
- DVBTUHF

Examples radio:standard gsm1800

Query Syntax [:SENSe]:RADio[:SElect]:STANdard?

Return Type Character

Default None

[:SENSe]:RADio:STANdard[:SElect] <string>

This command replaces [\[:SENSe\]:RADio:STANdard](#).

(Read-Write) Set and query the Radio Standard for use in channel measurements.

Relevant Modes [SA](#), [CPM](#)

Parameters

<string> Radio Standard. Choose from those listed in the User Interface when the Radio Standard softkey is pressed, including custom radio standards.
Case-sensitive. Include spaces and enclose in double-quotes.
 Select **"None"** to turn radio standards OFF.

Examples radio:standard "GSM 1800"

Query Syntax [:SENSe]:RADio:STANdard[:SElect]?

Return Type String

Default None

Last Modified:

1-Apr-2014 Added CPM

11-Aug-2011 New command

[:SENSe]:RADio:TEUNit <char>

(Read-Write) Set and query the whether channel measurements are tuned using frequency or channel numbers.

Relevant Modes SA, CPM

Parameters

<num> Tune entry units. Choose from:
FREQ - Channel measurement tuning is accomplished using Frequency (Sens:Freq:Start, Stop ,Center, Span)
CHAN - Channel measurement tuning is accomplished using Channel numbers (Sens:Rad:Chan:Start, Stop ,Center). Must also select a Radio Standard [:SENSe]:RADio:STANdard.

Examples RAD:TEUN CHAN

Query Syntax [:SENSe]:RADio:TEUNit?

Return Type Character

Default FREQ

Last Modified:

1-Apr-2014 Added CPM

[:SENSe]:RESolution <char>

(Read-Write) Set and query the number of data points for the Pulse measurement.

Relevant Modes [Pulse Measurements](#)

Parameters

<char> Resolution setting. Choose from the following:
LOW - 240 data points.
MED - 1000 data points.
HIGH - Calculated value - approximately 8000 data points.

Examples **RES LOW**

Query Syntax [:SENSe]:RESolution?

Return Type Character

Default LOW

Last Modified:

29-Oct-2013 New command

[:SENSe]:ROSCillator:SOURce <char>

(Read-Write) Set and query the source of the 10 MHz reference oscillator.

Relevant Modes ALL

Parameters

<num> Choose from:
INTernal - Internal FieldFox reference.
EXTernal -An external reference.

Examples **ROSC : SOUR INT**

Query Syntax [:SENSe]:ROSCillator:SOURce?

Return Type Character

Default INTernal

[:SENSe]:ROSCillator:STATus?

(Read-Only) Returns the status of the reference loop.

-1 External Reference Unlocked

0 Internal Reference

+1 External Reference Locked

Relevant Modes ALL

Examples **ROSC : STAT?**

Return Type Numeric
Default Not Applicable

[[:SENSe]:SPECTrogram:BPLevel <num>

(Read-Write) Set and query the Blue power level limit used with Waterfall and Spectrogram displays (Interference Analyzer Opt 236).

See also: [\[:SENSe\]:SPECTrogram:RPLLevel](#) (Red power level)

Relevant Modes SA

Parameters

<num> Select the LOWEST power levels (in dB) that you expect to measure. This power level, and those measured lower than this level, appear Blue.
 Enter a value between the -150 and the current Red (Highest) limit. (Default Red is -50)

Examples SPEC:BPL -80

Query Syntax [:SENSe]:SPECTrogram:BPLevel?

Return Type Numeric

Default -90

[[:SENSe]:SPECTrogram:RPLLevel <num>

(Read-Write) Set and query the Red power level limit used with Waterfall and Spectrogram displays (Interference Analyzer Opt 236).

See also: [\[:SENSe\]:SPECTrogram:BPLLevel](#) (Blue power level)

Relevant Modes SA

Parameters

<num> Select the HIGHEST power levels (in dB) that you expect to measure. This power level, and those measured higher than this level, appear Red.
 Enter a value between 0 and the current Blue (Lowest) limit. (Default Blue is -90)

Examples SPEC:BPL -10

Query Syntax [:SENSe]:SPECTrogram:RPLLevel?

Return Type Numeric

Default -50

[[:SENSe]:SPECTrogram:TMARker:STATe <char>

(Read-Write) Set and query the state of the time and delta markers used with Waterfall and Spectrogram displays (Interference Analyzer Opt 236).

A Time marker alone displays the time from the first record to the location of the time marker.

A Delta marker display the difference between the time marker and the delta marker.

Spectrogram displays the most recent record at the top of the screen. Waterfall displays the most recent record at the bottom.

Use [\[:SENSe\]:SPECtrogram:TMARker:VALue](#) to move the Time and Delta markers.

Relevant Modes SA

Parameters

<num> Marker state. Choose from:
OFF - Time and Delta markers OFF
DELT - Delta markers enabled.
TIME - Time marker enabled.

Examples SPEC:TMAR:STAT DELT

Query Syntax [:SENSe]:SPECtrogram:TMARker:STATe?

Return Type Character

Default OFF

Last Modified:

24-Jan-2012 New command

[\[:SENSe\]:SPECtrogram:TMARker:VALue <num>](#)

(Read-Write) Set and query the location of the Time or Delta marker, used with Waterfall and Spectrogram displays (Interference Analyzer Opt 236).

Use [\[:SENSe\]:SPECtrogram:TMARker:STATe](#) to enable the Time or Delta marker.

Spectrogram displays the most recent record at the top of the screen. Waterfall displays the most recent record at the bottom.

There is currently no command to read the Time that is displayed on the screen.

Relevant Modes SA

Parameters

<num> Time or Delta marker location. Enter a value between 0 (bottom of screen) and the maximum number of records visible on the screen. The max number depends on the [Waterfall view](#) and [Spectrogram Angle](#) settings.

Examples SPEC:TMAR:VAL 10

Query Syntax [:SENSe]:SPECtrogram:TMARker:VALue?

Return Type Numeric

Default 0

Last Modified:

17-Aug-2012 Edited for both marker types

[[:SENSe]:SPECTrogram:VIEW <char>

(Read-Write) Set and query the Spectrogram View setting, which changes how the spectrogram is displayed relative to the data trace. This setting affects the total number of trace records that can be displayed. (Interference Analyzer Opt 236).

Relevant Modes SA

Parameters

- <num> Spectrogram view. Choose from:
- OVERlay** - Displays the data trace over the spectrogram with NO graticules. Total trace records: 340.
 - FULL** - Displays the spectrogram with NO data trace. Total trace records: 340.
 - TOP** - Displays the data trace above the spectrogram. Total trace records: 130.
 - BOTTOM** - Displays the data trace below the spectrogram. Total trace records: 130.

Examples SPEC:VIEW TOP

Query Syntax [[:SENSe]:SPECTrogram:VIEW?

Return Type Character

Default OVERlay

[[:SENSe]:SPECTrogram:WANGLE <char>

(Read-Write) Set and query the Waterfall Angle setting, which allows you to show more or less detail. More detail provides fewer (time) records. (Interference Analyzer Opt 236).

Relevant Modes SA

Parameters

- <char> Choose from:
- MOD** - (Moderate) Compromise between detail and number of records.
 - STEEp** - Least detail with highest number of records.
 - GRAD** - (Gradual) Most detail with lowest number of records.
 - WIDE** - (Wide Angle) Moderate angle with increased space between records.

Examples SPEC:WANG WIDE

Query Syntax [:SENSe]:SPECTrogram:WANGle?
Return Type Character
Default MOD

[:SENSe]:SWEep:ACQuisition <num>

(Read-Write) Set and query the sweep acquisition parameter. This effectively sets the sweep time in SA mode. Adjust this setting in order to increase the probability of intercepting and viewing pulsed RF signals. Also set [\[:SENSe\]:SWEep:ACQuisition:AUTO](#) to 0 (OFF).

Relevant Modes SA

Parameters

<num> Choose a relative acquisition value between 1 and 5000, where:
 1 = Fastest sweep possible
 5,000 = Slowest sweep possible.

Examples **SWE:ACQ 25**

Query Syntax [:SENSe]:SWEep:ACQuisition?
Return Type Numeric
Default 1

[:SENSe]:SWEep:ACQuisition:AUTO <bool>

(Read-Write) Set and query sweep acquisition state.

Relevant Modes SA

Parameters

<bool> Choose from:
 ON or 1 - Automatically set to the fastest sweep possible with the current settings.
 OFF or 0 - Manually set the acquisition parameter using [\[:SENSe\]:SWEep:ACQuisition](#)

Examples **SWE:ACQ:AUTO 1**

Query Syntax [:SENSe]:SWEep:ACQuisition:AUTO?
Return Type Boolean
Default ON or 1

[[:SENSe]:SWEep:MTIME?

(Read-only) Query the measurement sweep time. This is the time reported on screen after a measurement completes.

Use with INIT:IMM ; OPC? in order to guarantee the most recently updated sweep time result.

| | |
|-----------------------|--------------------|
| Relevant Modes | SA, NA, CAT |
| Parameters | None |
| Examples | SWE : MTIM? |
| Return Type | Numeric |
| Default | Not Applicable |

Last Modified:

18-Mar-2014 New command (7.50)

[[:SENSe]:SWEep:POINts <num>

(Read-Write) Set and query the number of data points in the trace.

| | |
|-----------------------|--|
| Relevant Modes | CAT, NA, SA, FOPS VVM - Query only |
|-----------------------|--|

Parameters

<num> Number of data points. Choose a number from 3 to 10001.

| | |
|-----------------|-----------------------|
| Examples | SWE : POIN 250 |
|-----------------|-----------------------|

Query Syntax [[:SENSe]:SWEep:POINts?

Return Type Numeric

| | |
|----------------|---------------------|
| Default | 401 - SA mode |
| | 201 - CAT, NA, FOPS |
| | 2 - VVM mode |

Last Modified:

20-Mar-2014 Added FOPS

[[:SENSe]:SWEep:RX <value>

(Read-Write) Set and query the direction in which the receivers are swept.

| | |
|-----------------------|-------------|
| Relevant Modes | FOPS |
|-----------------------|-------------|

Parameters

<value> Choose from the following:

FORWARD - Used for systems for which the output frequency is Offs + Src. The output frequency of the DUT and the receiver sweeps in the same direction as the source.

REVERSE - Used for systems for which the output frequency is Offs - Src. The output frequency of the DUT and the receiver sweeps in reverse direction as compared to the source.

Examples `SWE:RX REV`

Query Syntax `[:SENSe]:SWEep:RX?`

Return Type Character

Default FORWARD

Last modified:

19-Mar-2014 New command (A.07.50)

`[:SENSe]:SWEep:TIME <num>`

(Read-Write) Set and query the sweep time of the measurement. The actual sweep time that is displayed on the screen will usually be higher than this value due to the overhead sweep time.

In SA mode, use this command for Zerospan measurements.

To set and read sweep time for Non-zerospan measurements in SA mode, use [\[:SENSe\]:SWEep:ACquisition](#).

Relevant Modes CAT, NA, SA

Parameters

<num> Sweep time in seconds.

Examples `SWE:TIME .250`

Query Syntax `[:SENSe]:SWEep:TIME?`

Return Type Numeric

Default 0

Last Modified:

17-Aug-2012 Added SA mode

`[:SENSe]:SWEep:TYPE <char>`

(Read-Write) Set and query the SA mode sweep type.

Relevant Modes SA

Parameters

<char> Choose from:

AUTO - FieldFox chooses the sweep type that yields the most accurate data most efficiently. When ResBW is set to 200 kHz and below, FFT is selected. Above 200 kHz, STEP is selected.

FFT - Use FFT sweep.

STEP - Use STEP sweep.

Examples **SWE:TYPE STEP**

Query Syntax [:SENSe]:SWEep:TYPE?

Return Type Character

Default AUTO

Last Modified:

1-Feb-2011 New command

[:SENSe]:SWEep:TYPE <value>

(Read-Write) Set and query the sweep type.

Relevant Modes **FOPS** (Opt 208)

Parameters

<value> Choose from the following:

CW - Used to make standard (non-offset) power meter measurements at a single frequency.

SWEpt - Used to make swept FOPS measurements.

Examples **SWE:TYPE SWEpt**

Query Syntax [:SENSe]:SWEep:TYPE?

Return Type Character

Default CW

Last modified:

19-Mar-2014 New command (A.07.50)

[[:SENSe]:TAListen:AVOLume <num> - Obsolete

This command is replaced with [SYSTem:AUDio:VOLume](#)

(Read-Write) Set and query the Tune and Listen volume.

To enable TuneListen mode, use [\[:SENSe\]:MEASurement:TAListen](#)

Relevant Modes SA

Parameters

<char> Tune and Listen volume. Choose a value in percent between 0 and 100 (loudest).

Examples **TAL:AVOL 50**

Query Syntax [:SENSe]:TAListen:AVOLume?

Return Type Numeric

Default 60

[[:SENSe]:TAListen:DState <bool>

(Read-Write) Set and query the Tune and Listen demodulation state.

To enable TuneListen mode, use [\[:SENSe\]:MEASurement:TAListen](#)

Relevant Modes SA

Parameters

<bool> Tune and Listen demod state. Choose from:

OFF or **0** - Do not demodulate. Stops the audio demodulation and performs only the normal SA sweeps

ON or **1** - Demodulate

Examples **TAL:DST 0**

Query Syntax [:SENSe]:TAListen:DState?

Return Type Boolean

Default ON

[[:SENSe]:TAListen:DTYPe <char>

(Read-Write) Set and query the Tune and Listen demodulation type. This command allows you to change the demod type without enabling Tune and Listen.

To enable TuneListen mode and set the demod type, use [\[:SENSe\]:MEASurement:TAListen](#)

Relevant Modes SA

Parameters

<char> Tune and Listen demodulation type. Choose from:

AM - Amplitude Modulation.

FMN - FM Narrow

FMW - FM Wide

Examples `TAL:DTYP AM`

Query Syntax `[:SENSe]:TAListen:DTYPe?`

Return Type Character

Default AM

[:SENSe]:TAListen:LTIME <num>

(Read-Write) Set and query the Listen time for Tune & Listen.

While Tune & Listen is actively demodulating a signal, the SA does not sweep and update the display. Listen Time sets the amount of time that the FieldFox demodulates. It then stops to perform a single sweep and update the display, then again demodulates for this amount of time.

To enable TuneListen mode, use [\[:SENSe\]:MEASurement:TAListen](#)

Relevant Modes SA

Parameters

<char> Listen time in seconds. Choose a value between 0.1 and 100.

Examples `TAL:LTIM 20`

Query Syntax `[:SENSe]:TAListen:LTIME?`

Return Type Numeric

Default 2.5

[:SENSe]:TAListen:TFRReq <num>

(Read-Write) Set and query the tune frequency for Tune & Listen. First set [\[:SENSe\]:MEASurement:TAListen](#).

The Tune & Listen tuner is separate from the SA display. This allows you to listen to one frequency while displaying a different range of frequencies.

See Also: [CALCulate:MARKer:SET](#)

To enable TuneListen mode, use [\[:SENSe\]:MEASurement:TAListen](#)

Relevant Modes SA

Parameters

<char> Tune frequency in Hz. Choose a value between the FieldFox MIN and MAX frequency.

Examples `TAL:TFR 101.7e6`

Query Syntax `[:SENSe]:TAListen:TFRReq?`

Return Type Numeric

Default 3.0 GHz

[[:SENSe]:TOL <value>

(Read-Write) Set and query the power sensor measurement tolerance.

Each power sensor reading is "settled" when either:

- two consecutive readings are within this Tolerance value or
- when the Max Number of Readings ([\[:SENSe\]:POINT:READ:MAX](#)) has been met.

The readings that were taken are averaged together to become the "settled" reading.

Relevant Modes [FOPS](#) (Opt 208)

Parameters

<value> Tolerance in dB. Choose a value between 0.0 and 10.0
When consecutive power meter readings are within this value of each other, then the reading is considered settled.

Examples **TOL .05**

Query Syntax [:SENSe]:TOL?

Return Type Numeric

Default .1

Last modified:

19-Mar-2014 New command (A.07.50)

[[:SENSe]:TRACe[:DATA]?

(Read-only) Read the data from a Power Meter measurement.

For Pulse Measurements ONLY: This command returns a single 'Meter-style' value. To read data for a trace graph, use [CALCulate\[:SElected\]:TRACe:DATA](#)

Relevant Modes Power Meter, [Pulse Measurements](#), [CPM](#)

Examples **TRAC?**

Query Syntax [:SENSe]:TRACe[:DATA]?

Return Type Numeric

Default Not Applicable

Last Modified:

1-Apr-2014 Added CPM
29-Oct-2013 Added Pulse

[[:SENSe]:TRACe:LIMit:LOWer <num>

(Read-Write) Set and query the minimum (lower) limit value. Also set [\[:SENSe\]:TRACe:LIMit:LOWer:STATe ON](#).

Relevant Modes [Power Meter](#), [Pulse Measurements](#), [CPM](#)

Parameters

<num> Minimum (lower) limit value.

Examples **TRAC:LIM:LOW -50**

Query Syntax [:SENSe]:TRACe:LIMit:LOWer?

Return Type Numeric

Default -80

Last modified:

1-Apr-2014 Added CPM
31-Oct-2013 Added Pulse

[[:SENSe]:TRACe:LIMit:LOWer:STATe <bool>

(Read-Write) Set and query the ON|OFF state for minimum (lower) limit testing.

Relevant Modes [Power Meter](#), [Pulse Measurements](#), [CPM](#)

Parameters

<bool> Minimum limit state. Choose from:
0 or **OFF** - Minimum limit OFF
1 or **ON** - Minimum limit ON

Examples **TRAC:LIM:LOW:STATe 0**

Query Syntax [:SENSe]:TRACe:LIMit:LOWer:STATe?

Return Type Boolean

Default OFF

Last modified:

1-Apr-2014 Added CPM

31-Oct-2013 Added Pulse

[[:SENSe]:TRACe:LIMit:UPPer <num>

(Read-Write) Set and query the maximum (upper) limit value. Also set [\[:SENSe\]:TRACe:LIMit:UPPer:STATe ON](#).

Relevant Modes [Power Meter](#), [Pulse Measurements](#), [CPM](#)

Parameters

<num> Maximum (upper) limit value.

Examples **TRAC:LIM:UPP 0**

Query Syntax [:SENSe]:TRACe:LIMit:UPPer?

Return Type Numeric

Default -20

Last modified:

1-Apr-2014 Added CPM

31-Oct-2013 Added Pulse

[[:SENSe]:TRACe:LIMit:UPPer:STATe <bool>

(Read-Write) Set and query the ON|Off state for maximum (upper) limit testing.

Relevant Modes [Power Meter](#), [Pulse Measurements](#), [CPM](#)

Parameters

<bool> Maximum limit state. Choose from:

0 or OFF - Maximum limit OFF

1 or ON - Maximum limit ON

Examples **TRAC:LIM:UPP:STATe 0**

Query Syntax [:SENSe]:TRACe:LIMit:UPPer:STATe?

Return Type Boolean

Default OFF

Last modified:

1-Apr-2014 Added CPM

31-Oct-2013 Added Pulse

[[:SENSe]:TRACe:MEASurement:REFerence <num>

(Read-Write) Set and query the Pulse Top setting which adjusts the measurement reference.

Relevant Modes [Pulse Measurements](#)

Parameters

<num> Pulse Top in percent. Choose a value between 0 and 100.

Examples TRAC:MEAS:REF 90

Query Syntax [SENSe]:TRACe:MEASurement:REFerence?

Return Type Numeric

Default 100

Last Modified:

29-Oct-2013 New command

[[:SENSe]:TRACe:MEASurement <value>

(Read-Write) Set and query the measurement to display.

Relevant Modes [FOPS](#)

Parameters

<value> Choose from the following:

SPOWer - Not available until source data is stored into memory. Displays only the source power memory trace.

OUTPower - Displays the raw output power at the USB power sensor.

GAIN - Not available until source data is stored into memory. Displays the Output power / Source power (memory trace).

Examples TRAC:MEAS GAIN

Query Syntax [SENSe]:TRACe:MEASurement?

Return Type Character

Default OUTPower

Last modified:

19-Mar-2014 New command (A.07.50)

SOURce:ENABLE <bool>

(Read-Write) Set and query the Source Enable ON|OFF setting. Set the power level using [SOURce:POWer](#).

Relevant Modes Power Meter

Parameters

<bool> Choose from:
OFF - Source OFF
ON - Source ON

Examples **SOUR:ENAB ON**

Query Syntax SOURce:ENABLE?

Return Type Boolean

Default OFF

Last Modified:

1-Nov-2013 New command

SOURce:ENABLE <bool>

Note: This command was previously named [:SENSE]:ISource:ENABLE. That syntax still work, but the new syntax should be used for new development.

(Read-Write) Set and query the Independent source state.

Relevant Modes SA

Parameters

<bool> Independent source state. Choose from:
ON (1) - Independent source ON
OFF (0) - Independent source OFF

Examples **SOUR:ENAB 1**

Query Syntax SOURce:ENABLE?

Return Type Boolean

Default OFF

Last Modified:

25-Mar-2014 Changed name

20-Oct-2010 New command (5.30)

SOURce:FREQuency:CENTer <value>

(Read-Write) Set and query the center frequency. Also send [SOURce:FREQuency:SPAN](#)

Relevant Modes [FOPS](#) (Opt 208)

Parameters

- <value> Center Frequency in Hz. The frequency limits for the measurement are determined by the limits of both the FieldFox and the power sensor.
- The LOW frequency is limited by the higher of either the FieldFox or the power sensor minimum frequencies.
 - The HIGH frequency is limited by the lower of either the FieldFox or the power sensor maximum frequencies.

Examples **SOUR:FREQ:CENT 1e9**

Query Syntax SOURce:FREQuency:CENTer?

Return Type Numeric

Default 50 MHz

Last modified:

19-Mar-2014 New command (A.07.50)

SOURce:FREQuency[:CW] <num>

Note: This command was previously named [:SENSe]:ISource:FREQuency[:CW]. That syntax will still work, but the new syntax should be used for new development.

(Read-Write) Set and query the Independent Source CW frequency.

Use [SOURce:MODE](#) to set Independent Source to CW mode.

Use [SOURce:FNABLE](#) to enable Independent Source.

Relevant Modes SA

Parameters

- <num> CW frequency. Choose a value within the SA mode frequency range.

Examples **SOUR:FREQ 1e9**

Query Syntax SOURce:FREQuency[:CW]?

Return Type Numeric

Default SA mode center frequency

Last Modified:

25-Mar-2014 Name change

10-Oct-2010

New command (5.30)

SOURce:FREQuency:SPAN <value>

(Read-Write) Set and query the frequency span of the measurement. Also send [SOURce:FREQuency:CENTer](#)

Relevant Modes [FOPS](#) (Opt 208)

Parameters

- <value> Frequency span in Hz. The frequency limits for the measurement are determined by the limits of both the FieldFox and the power sensor.
- The LOW frequency is limited by the higher of either the FieldFox or the power sensor minimum frequencies.
 - The HIGH frequency is limited by the lower of either the FieldFox or the power sensor maximum frequencies.

Examples **SOUR:FREQ:SPAN .5e9**

Query Syntax SOURce:FREQuency:SPAN?

Return Type Numeric

Default 10 MHz

Last modified:

19-Mar-2014 New command (A.07.50)

SOURce:FREQuency:STARt <value>

(Read-Write) Set and query the start frequency of the measurement. Also send [SOURce:FREQuency:STOP](#)

Relevant Modes [FOPS](#) (Opt 208)

Parameters

- <value> Start frequency in Hz. The frequency limits for the measurement are determined by the limits of both the FieldFox and the power sensor.
- The LOW frequency is limited by the higher of either the FieldFox or the power sensor minimum frequencies.
 - The HIGH frequency is limited by the lower of either the FieldFox or the power sensor maximum frequencies.

Examples **SOUR:FREQ:STAR .5e9**

Query Syntax SOURce:FREQuency:STARt?

Return Type Numeric

Default 45 MHz

Last modified:

19-Mar-2014 New command (A.07.50)

SOURce:FREQuency:STOP <value>

(Read-Write) Set and query the stop frequency of the measurement. Also send [SOURce:FREQuency:START](#)

Relevant Modes [FOPS](#) (Opt 208)

Parameters

<value> Stop frequency in Hz. The frequency limits for the measurement are determined by the limits of both the FieldFox and the power sensor.

- The LOW frequency is limited by the higher of either the FieldFox or the power sensor minimum frequencies.
- The HIGH frequency is limited by the lower of either the FieldFox or the power sensor maximum frequencies.

Examples **SOUR:FREQ:STOP 1.5e9**

Query Syntax SOURce:FREQuency:STOP?

Return Type Numeric

Default 55 MHz

Last modified:

19-Mar-2014 New command (A.07.50)

SOURce:MODE <char>

Note: This command was previously named [:SENSE]:ISource:MODE. That syntax will still work, but the new syntax should be used for new development.

(Read-Write) Set and query the Independent Source mode setting.

Use [SOURce:ENABle](#) to enable Independent Source.

Relevant Modes SA

Parameters

<bool> Independent source mode. Choose from:

CW - The internal source is set to CW. Use [SOURce:FREQuency\[:CW\]](#) to set the

frequency.

SRTS - "Stimulus Response Tracking Sweep". The internal source tracks with the SA receiver. Use [SOURce:NORMalize](#) to normalize the trace.

Examples **SOUR:MODE CW**

Query Syntax SOURce:MODE?

Return Type Character

Default CW

Last Modified:

25-Mar-2014 Name change

10-Oct-2010 New command (5.30)

SOURce:NORMalize <bool>

Note: This command was previously named [:SENSe]:ISource:NORMalize. That syntax will still work, but the new syntax should be used for new development.

(Read-Write) Set and query the state of Independent source normalization.

Independent source must be ON ([SOURce:ENABLE](#)) and in tracking mode ([\[:SENSe\]:ISource:MODE SRTS_](#)

Relevant Modes SA

Parameters

<bool> Normalization state. Choose from:

ON (1) - Normalization ON

OFF (0) - Normalization OFF

Examples **SOUR:NORM 1**

Query Syntax SOURce:NORMalization?

Return Type Boolean

Default OFF

Last Modified:

25-Mar-2014 Name change

10-Oct-2010 New command (5.30)

SOURce:POWER <num>

(Read-Write) Set and query the source power level. This command sets [SOURce:POWER:ALC\[:MODE\]](#) to

MANual.

- For N9912A and N9923A models: This command changes the source attenuation (dB) to effectively set the power level at the test port.
- All other models: This command directly changes the power level in dBm.

Relevant Modes CAT, NA, VVM, Power Meter

Parameters

<num> Source power/attenuator level.

- **N9912A:** 0 to -31 dB in 1 dB steps
- **N9923A:** 0 to -47 dB in .5 dB steps
- **All other models:** Set power level from +3 to -45 dBm in .1 dB steps.

This command also supports sending MIN and MAX power levels as arguments:

- For N9912A and N9923A, MAX is equivalent to the HIGH setting. See the User's Guide for your FieldFox model.
- For all other models, MAX is equivalent to the maximum leveled setting (+3)

Examples `SOUR:POW -10`
`Source:power max`

Query Syntax :SOURce:POWer?

Return Type Numeric

Default 0

Last modified:

| | |
|-------------|--|
| 1-Nov-2013 | Added Power Meter |
| 3-Apr-2013 | Major edits (LH) |
| 15-Aug-2012 | Added link to ALC mode |
| 17-Jul-2012 | Added all other models (A.06.00) |
| 1-Feb-2011 | Fixed and reworded to emphasize negative power levels. |

SOURce:POWer <num>

Note: This command was previously named [:SENSe]:ISource:POWer. That syntax will still work, but the new syntax should be used for new development.

(Read-Write) Set and query the Independent Source power level. This command automatically sets `SOURce:POWer:MAXimum` to OFF.

Use `SOURce:ENABle` to enable Independent Source.

Relevant Modes SA (All models EXCEPT N9912A - See `[:SENSe]:ISource:POWer:ATTenuation` for this model).

Parameters

<num> Power level in dBm. Choose a value between -45 and 0.
This command will accept MIN and MAX as arguments.

Examples **SOUR:POW -20**
source:power min

Query Syntax SOURce:POWer?

Return Type Numeric

Default -15 dBm

Last Modified:

| | |
|-------------|--------------------|
| 25-Mar-2014 | Name change |
| 10-Oct-2010 | New command (6.00) |

SOURce:POWer:ALC[:MODE] <char>

(Read-Write) Set and query the source power ALC (automatic leveling control) setting.

To set source power to a specific level, use [SOURce:POWer](#). (Automatically sets SOUR:POW:ALC MAN.)

Relevant Modes CAT, NA, VVM

Parameters

<char> Source power. Choose from:

- **HIGH** - highest power level at each frequency (NOT flat)
- **LOW** - low power level (same as [SOUR:POW MIN](#) setting). For FieldFox models other than N9912A and N9923A, power is flat over the selected frequency range.
- **MAN** - Manual setting (Automatically set when [SOURce:POWer](#) is set.)

Examples **SOUR:POW:ALC HIGH**

Query Syntax SOURce:POWer:ALC[:MODE]?

Return Type Character

Default HIGH

Last Modified:

| | |
|-------------|--------------------------|
| 3-Apr-2013 | Edited leveling settings |
| 15-Aug-2012 | New command |

SOURce:POWer:ATTenuation <num>

Note: This command was previously named [:SENSe]:ISource:POWer:ATTenuation. That syntax will still work, but the new syntax should be used for new development.

(Read-Write) Set and query the Independent Source attenuation level.

Use [SOURce:FNABLE](#) to enable Independent Source.

Relevant Modes SA (N9912A ONLY - See [SOURce:POWer:MAXimum](#) and [SOURce:POWer](#) for all other models).

Parameters

<num> Independent source attenuation in dB. Choose a value between 31 and 0. This command will accept MIN and MAX as arguments.

Examples `SOUR:POW:ATT 20`
`source:power:att min`

Query Syntax SOURce:POWer:ATTenuation?

Return Type Numeric

Default 10

Last Modified:

| | |
|-------------|--------------------|
| 7-Apr-2014 | Name change |
| 10-Oct-2010 | New command (5.30) |

SOURce:POWer:MAXimum <bool>

Note: This command was previously named [:SENSe]:ISource:POWer:MAXimum. That syntax will still work, but the new syntax should be used for new development.

(Read-Write) Set and query the state of maximum Independent Source Power.

Use [SOURce:FNABLE](#) to enable Independent Source.

Relevant Modes SA (All models EXCEPT N9912A - See [SOURce:POWer:ATTenuation](#) for this model).

Parameters

<bool> Max Independent Source Power state. Choose from:
ON (or 1) - Independent Source Power level is set to the maximum achievable power at all frequencies.
OFF (or 0) - Independent Source Power level is set using [SOURce:POWer](#).

Examples `SOUR:POW:MAX 1`
`source:power:maximum off`

Query Syntax SOURce:POWer:MAXimum?

Return Type Boolean

Default OFF

Last Modified:

| | |
|-------------|--------------------|
| 25-Mar-2014 | Name change |
| 10-Oct-2010 | New command (6.00) |

SOURce:POWer:MEMorize

(Write-Only) Stores the current data trace into memory.

Relevant Modes **FOPS**

Examples **SOUR : POW : MEM**

Query Syntax Not Applicable

Default Not Applicable

Last modified:

| | |
|-------------|-------------|
| 19-Mar-2014 | New command |
|-------------|-------------|

SOURce:POWer <num>

(Read-Write) Set and query the source power level. This command sets **SOURce:POWer:ALC[:MODE]** to MANual.

- For N9912A and N9923A models: This command changes the source attenuation (dB) to effectively set the power level at the test port.
- All other models: This command directly changes the power level in dBm.

Relevant Modes CAT, NA, VVM, Power Meter

Parameters

<num> Source power/attenuator level.

- **N9912A:** 0 to -31 dB in 1 dB steps
- **N9923A:** 0 to -47 dB in .5 dB steps
- **All other models:** Set power level from +3 to -45 dBm in .1 dB steps.

This command also supports sending MIN and MAX power levels as arguments:

- For N9912A and N9923A, MAX is equivalent to the HIGH setting. See the User's Guide for your FieldFox model.
- For all other models, MAX is equivalent to the maximum leveled setting (+3)

Examples `SOUR:POW -10`
`Source:power max`

Query Syntax :SOURce:POWer?

Return Type Numeric

Default 0

Last modified:

- 1-Nov-2013 Added Power Meter
- 3-Apr-2013 Major edits (LH)
- 15-Aug-2012 Added link to ALC mode
- 17-Jul-2012 Added all other models (A.06.00)
- 1-Feb-2011 Fixed and reworded to emphasize negative power levels.

SOURce:POWer <num>

Note: This command was previously named [:SENSe]:ISource:POWer. That syntax will still work, but the new syntax should be used for new development.

(Read-Write) Set and query the Independent Source power level. This command automatically sets [SOURce:POWer:MAXimum](#) to OFF.

Use [SOURce:ENABLE](#) to enable Independent Source.

Relevant Modes SA (All models EXCEPT N9912A - See [\[:SENSe\]:ISource:POWer:ATTenuation](#) for this model).

Parameters

<num> Power level in dBm. Choose a value between -45 and 0.
 This command will accept MIN and MAX as arguments.

Examples `SOUR:POW -20`
`source:power min`

Query Syntax SOURce:POWer?

Return Type Numeric

Default -15 dBm

Last Modified:

- 25-Mar-2014 Name change
- 10-Oct-2010 New command (6.00)

SOURce:RECeiver:OFFSet <value>

(Read-Write) Set and query the receiver offset frequency of the measurement. Also send [SOURce:FREQuency:START](#)

Relevant Modes [FOPS](#) (Opt 208)

Parameters

<value> Offset frequency in Hz. (The frequency that the receiver is offset from the source.) This is typically the frequency of the LO that is used with the frequency converter. The frequency offset may be positive, negative, or zero.

Examples **SOUR:REC:OFFS .5e9**

Query Syntax SOURce:RECeiver:OFFSet?

Return Type Numeric

Default 0 Hz

Last modified:

19-Mar-2014 New command (A.07.50)

:STATus:OPERation:SAMode:CONDition?

(Read-Only) Reads the status of a RecordPlayback session.

Relevant Modes ALL - RecordPlayback is allowed ONLY in SA mode.

Examples **STAT:OPER:SAM:COND?**

Return Type Numeric:

0 - Record Playback session is NOT OPEN

64 - Record Playback session OPEN

Default Not Applicable

:STATus:QUESTionable:FREQuency:CONDition?

(Read-Only) Reads the status of External Reference unlock errors.

Relevant Modes ALL

Examples **STAT:QUES:FREQ:COND?**

Return Type Numeric:

0 - External reference NOT unlocked.

2 - External reference unlocked.

Default Not Applicable

:STATus:QUEStionable:INTegrity:CONDition?

(Read-Only) Reads the status of ADC Overrange errors.

Relevant Modes ALL - However, SA is the only mode that reports ADC overrange.

Examples `STAT:QUES:FREQ:COND?`

Return Type Numeric:

0 - ADC is NOT Overrange

2 - ADC Overrange occurs.

Default Not Applicable

:STATus:QUEStionable:LIMit:CONDition?

(Read-Only) Reads the status of limit line failures.

Relevant Modes ALL - Limit lines are allowed in CAT, NA, SA

Examples `STAT:QUES:LIM:COND?`

The following C# excerpt assumes 4 traces, and uses a "bitwise and" of the return value:

```

for (int i = 1; i < 5; ++i)
{
    if ((returnValueFromScpiCommandAsInt &
(int) (Math.Pow(2, i))) > 0)
    {
        tracePassFail[i] = "Fail";
    }
    else
    {
        tracePassFail[i] = "Pass";
    }
}

```

Return Type Numeric:

0 - All limit lines pass

2 - Any limit on trace#1 failed

4 - Any limit on trace #2 failed

8 - Any limit on trace #3 failed

16 - Any limit on trace #4 failed

The returned values are added together. For example, 6 would mean traces #1 and #2 failed, 12 would mean #2 and #3 failed, 30 would mean all 4 traces failed and so forth.

Default Not Applicable

Last Modified:

17-Jul-2012 Updated for A.06.00)

SYSTem:AUDio:MUTE <bool>

(Read-Write) Set and query the system volume MUTE state.

Relevant Modes ALL Modes.

Parameters

<char> Choose from:
ON (or 1) - Volume muted.
OFF (or 0) - Volume NOT muted.

Examples **SYST:AUD:MUTE 0**

Query Syntax SYSTem:AUDio:MUTE?

Return Type Boolean

Default OFF (or 0)

Last Modified:

4-Aug-2011 New command

SYSTem:AUDio:VOLume <num>

(Read-Write) Set and query the system volume level.

Relevant Modes ALL Modes.

Parameters

<num> Volume level. Choose a value between 0 (lowest volume) and 100 (highest volume).

Examples **SYST:AUD:VOL 93**

Query Syntax SYSTem:AUDio:VOLume?

Return Type Numeric

Default 75

Last Modified:

4-Aug-2011 New command

SYSTEM:BATTERY?

(Read-Only) Reads whether or not a battery is present in the FieldFox.

Relevant Modes ALL

Examples **SYST : BATT ?**

Return Type Boolean
1 - Battery is present
0 - Battery is not present

Default Not Applicable

Last Modified:

18-Oct-2012 New command

SYSTEM:BATTERY:ABSCCharge?

(Read-Only) Reads the absolute charge on the battery in percent.

Relevant Modes ALL

Examples **SYST : BATT : ABSC ?**

Return Type Numeric

Default Not Applicable

SYSTEM:BATTERY:ACURrent?

(Read-Only) Reads the average current flowing from the battery in amperes.

Relevant Modes ALL

Examples **SYST : BATT : ACUR ?**

Return Type Numeric

Default Not Applicable

SYSTEM:BATTERY:ARTTe?

(Read-Only) Returns the minutes of run time remaining based on running average of current being used.

| | |
|----------------|----------------------------|
| Relevant Modes | ALL |
| Examples | SYST : BATT : ARTT? |
| Return Type | Numeric |
| Default | Not Applicable |

SYSTem:BATTery:CHEMistry?

(Read-Only) Reads the chemistry type of the battery.

| | |
|----------------|----------------------------|
| Relevant Modes | ALL |
| Examples | SYST : BATT : CHEM? |
| Return Type | String |
| Default | LION (Lithium Ion) |

SYSTem:BATTery:CURRent?

(Read-Only) Reads amount of current being consumed when operating from internal battery. If battery is charging, indicates amount of charging current.

| | |
|----------------|----------------------------|
| Relevant Modes | ALL |
| Examples | SYST : BATT : CURR? |
| Return Type | Numeric |
| Default | Not Applicable |

SYSTem:BATTery:CYCLes?

(Read-Only) Reads the number of charge cycles battery has experienced. Charge cycle defined as $\geq 80\%$ change in relative state of charge.

| | |
|----------------|------------------------------|
| Relevant Modes | ALL |
| Examples | SYST : BATT : CYCLes? |
| Return Type | Numeric |
| Default | Not Applicable |

SYSTem:BATTery:DATE?

(Read-Only) Reads the date of manufacture of the battery.

| | |
|----------------|-----|
| Relevant Modes | ALL |
|----------------|-----|

Examples `SYST : BATT : DATE ?`

Return Type String

Default Not Applicable

SYSTEM:BATTERY:FCAPACITY?

(Read-Only) Reads the capacity of a full battery in milli-amp Hours. Theoretically, how long a full battery of this type should continue to provide energy.

Relevant Modes ALL

Examples `SYST : BATT : FCAP ?`

Return Type String

Default Not Applicable

SYSTEM:BATTERY:MAXERROR?

(Read-Only) Reads Reads the present accuracy of the battery gauge in percent. If the error exceeds 10%, you should recondition the battery.

Relevant Modes ALL

Examples `SYST : BATT : MAXE ?`

Return Type Numeric

Default Not Applicable

SYSTEM:BATTERY:MFGNAME?

(Read-Only) Reads the name of the manufacturer of the battery.

Relevant Modes ALL

Examples `SYST : BATT : MFGNAME ?`

Return Type String

Default Agilent

SYSTEM:BATTERY:RCAPACITY?

(Read-Only) Reads the remaining battery capacity in hours..

Relevant Modes ALL

Examples `SYST : BATT : RCAP ?`

Return Type String

Default Not Applicable

SYSTem:BATTery:RELCharge?

(Read-Only) Reads the current charge compared to actual full capacity in percent. This number lowers with age and number of battery cycles.

Relevant Modes ALL

Examples **SYST:BATT:REL?**

Return Type Numeric

Default Not Applicable

SYSTem:BATTery:RTTE?

(Read-Only) Reads the minutes of run time remaining based on amount of current being used now.

Relevant Modes ALL

Examples **SYST:BATT:RTTE?**

Return Type Numeric

Default Not Applicable

SYSTem:BATTery:SAVer <bool>

(Read-Write) Set and query the battery saver state.

Relevant Modes ALL

Parameters

<bool> Choose from:
OFF or **0** - Battery saver OFF. This leaves the source ON between sweeps.
ON or **1** - Battery saver ON

Examples **SYST:BATT:SAV OFF**

Query Syntax SYSTem:BATTery:SAVer?

Return Type Boolean

Default ON

SYSTem:BATTery:SN?

(Read-Only) Reads the serial number of the battery.

Relevant Modes ALL

Examples **SYST : BATT : SN?**

Return Type Numeric

Default Not Applicable

SYSTem:BATTeRy:STATus?

(Read-Only) Reads the use status of the FieldFox battery.

Relevant Modes ALL

Examples **SYST : BATT : STAT?**

Return Type Character

FULL - Battery is fully charged

CHAR - Battery is charging

NOB - No battery present

DISC - Battery is discharging; no AC Adaptor is present.

Default Not Applicable

Last Modified:

18-Oct-2012

New command

SYSTem:BATTeRy:TEMPerature?

(Read-Only) Reads the current battery temperature in degrees Celsius.

Relevant Modes ALL

Examples **SYST : BATT : TEMP?**

Return Type Numeric

Default Not Applicable

SYSTem:BATTeRy:VENDor?

(Read-Only) Reads the vendor / distributor of the battery.

Relevant Modes ALL

Examples **SYST : BATT : VEND?**

Return Type String

Default Not Applicable

SYSTem:BATTeRy:VOLTage?

(Read-Only) Reads the current battery voltage in volts.

| | |
|-----------------------|----------------------------|
| Relevant Modes | ALL |
| Examples | SYST : BATT : VOLT? |
| Return Type | Numeric |
| Default | Not Applicable |

SYSTem:DATE <year,mo,dy>

(Read-Write) Set and query the system date.

| | |
|-----------------------|-----------------------------------|
| Relevant Modes | ALL |
| Parameters | |
| <yr,mo,dy> | Year, month, and day. |
| Examples | SYST : DATE 2008 , 10 , 16 |
| Query Syntax | SYSTem:DATE? |
| Return Type | Comma-separated numeric |
| Default | Not Applicable |

SYSTem:DCSupply?

(Read-Only) Reads whether the DC Supply is connected to the FieldFox.

| | |
|-----------------------|---|
| Relevant Modes | ALL |
| Examples | SYST : DCS? |
| Return Type | Boolean 1 - DC Supply is connected 0 - DC Supply is NOT connected |
| Default | Not Applicable |

Last modified:

17-Jul-2012 New command (A.06.00)

SYSTem:ERASe <value>

(Write-Read) Immediately erases all user data from the FieldFox.

Warning: there is no confirmation message.

| | |
|-----------------------|--|
| Relevant Modes | ALL |
| Parameters | None |
| <value> | (String) Choose "USERDATA" (case sensitive) |
| Examples | SYST:ERAS "USERDATA" |
| Query Syntax | SYSTem:ERASe? "USERDATA" Returns the date of the last time that user data was erased. |
| Default | Not Applicable |

Last modified:

28-Mar-2013 Added read

SYSTem:ERRor[:NEXT]?

(Read-Only) Read the next error in the error queue.

Learn [How to Query the Error Queue](#).

| | |
|-----------------------|------------------|
| Relevant Modes | ALL |
| Examples | SYST:ERR? |
| Return Type | Numeric, String |
| Default | Not Applicable |

SYSTem:GPS:CNOise?

This query returns a string containing Carrier to Noise (C/No dBHz) data for each satellite currently in view of the FieldFox GPS.

Note: The C/No values returned are not calibrated at the factory or warranted for accuracy. The numbers retrieved are passed unprocessed directly from the GPS receiver in use.

| | |
|-----------------------|--|
| Relevant Modes | GPS |
| Examples | SYSTem:GPS:CNOise |
| Query Syntax | SYSTem:GPS:CNOise? |
| Return Type | Comma separated string in the form "sat#,cno,sat#,cno,...". If GPS mode is not enabled or there are no satellites in view, the query returns "0,0". If there are 10 satellites in view, this query generates 20 numbers in the SCPI return string. |
| Default | Not applicable |

SYSTem:GPS:DATA?

(Read-only) Returns current GPS data in the following form:
 <latitude>,<longitude>,<elevation (m)>,<timestamp (UTC)>

Relevant Modes ALL Modes

Parameters None

Examples **SYST:GPS:DATA?**

'Returns

"38 28.88657 N,122 42.66682 W,152,2010-06-28 23:35:38Z"

Return Type Comma-separated numeric

Default Not Applicable

Last modified:

20-Jul-2010 New command (A.05.33)

SYSTem:GPS:DATA:LAST?

(Read-only) Returns the data for the last successfully-locked GPS read in the form:
 <latitude>,<longitude>,<elevation (m)>,<timestamp (UTC)>,<seconds since last read>

Relevant Modes ALL Modes.

Parameters None

Examples **SYST:GPS:DATA:LAST?**

'Returns

"38 28.88657 N,122 42.66682 W,152,2010-06-28 23:35:38Z,4"

Return Type Comma-separated numeric

Default Not Applicable

Last modified:

20-Jul-2010 New command (A.05.33)

SYSTem:GPS:DISPlay:COORdinate:FORMat <char>

(Read-Write) Set and query the format of the Latitude / Longitude coordinates.

Relevant Modes ALL Modes.

Parameters

<char> Choose from:
DMS - degrees, minutes, seconds
DMM - degrees, decimal minutes

Examples **SYST:GPS:DISP:COORD:FORM DMM**

Query Syntax SYSTem:GPS:DISPlay:COORDinate:FORMat?

Return Type Character

Default DMS

Last modified:

20-Jul-2010 New command (A.05.33)

SYSTem:GPS:DISPlay:DISTance:UNIT <char>

(Read-Write) Set and query the units of elevation.

Relevant Modes ALL Modes

Parameters

<char> Choose from:
FEET
METers

Examples **SYST:GPS:DISP:DIST:UNIT MET**

Query Syntax SYSTem:GPS:DISPlay:DISTance:UNIT?

Return Type Character

Default METers

Last modified:

20-Jul-2010 New command (A.05.33)

SYSTem:GPS:DISPlay:STATe <bool>

(Read-Write) Set and query the GPS status line display state.

Relevant Modes ALL Modes

Parameters

<char> Choose from:
ON (1) - Status line ON

OFF (0) - Status line OFF

Examples **SYST:GPS:DISP:STAT 0**

Query Syntax SYSTem:GPS:DISPlay:STATe?

Return Type Boolean

Default ON (1)

Last modified:

20-Jul-2010 New command (A.05.33)

SYSTem:GPS:LState?

(Read-only) Returns the GPS lock state.

Relevant Modes ALL Modes

Parameters

Examples **SYST:GPS:LST?**

Return Type Numeric

0 - OFF

1 - Locked

2 - ON but unlocked

3 - ON but no GPS device present

Default 0 - OFF

Last modified:

20-Jul-2010 New command (A.05.33)

SYSTem:GPS[:STATE] <char>

(Read-Write) Set and query the GPS state.

Relevant Modes ALL Modes.

Parameters

<char> Choose from:

OFF - GPS OFF

EXTeRnal - External GPS ON

INTeRnal - Internal GPS ON. Requires Option 307 (Built-in GPS)

Examples **SYST:GPS EXT**

Query Syntax SYSTem:GPS[:STATe]?
Return Type Character
Default OFF

Last modified:

17-Jul-2012 Updated for Internal (A.06.00)
20-Jul-2010 New command (A.05.33)

SYSTem:GPS:SYNChronize <bool>

(Read-Write) Set and query the GPS clock sync state.

Relevant Modes ALL Modes

Parameters

<char> Choose from:
ON (1) - FieldFox clock synchronized with GPS clock.
OFF (0) - FieldFox clock NOT synchronized with GPS clock.

Examples **SYST:GPS:SYNC 0**

Query Syntax SYSTem:GPS:SYNChronize?
Return Type Boolean
Default OFF (0)

Last modified:

20-Jul-2010 New command (A.05.33)

SYSTem:PREFerences:DFLT

(Write-Only) Sets the system (language and display) preferences to their default settings.

Relevant Modes ALL

Parameters None

Examples **SYST:PREF:DFLT**

Query Syntax Not Applicable
Default Not Applicable

SYSTem:PREFerences:SAVE

(Read-Write) Saves the current language and display settings as your system preferences.

| | |
|----------------|----------------|
| Relevant Modes | ALL |
| Parameters | None |
| Examples | SYST:PREF:SAVE |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

:SYSTem:PRESet

(Write-Only) Perform a full preset on the FieldFox.

| | |
|----------------|-------------------|
| Relevant Modes | ALL |
| Examples | SYST: PRES |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

:SYSTem:PRESet:MODE

(Write-Only) Perform a Mode preset on the FieldFox. Only the current mode is preset to default settings.

| | |
|----------------|-------------------------|
| Relevant Modes | ALL |
| Examples | SYST: PRES: MODE |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

SYSTem:PWR:AUTO <value>

(Write-only) Determines how the FieldFox is turned ON after a charged battery or DC power has been removed from the FieldFox. This setting will remain until it is changed either using the command or the User Interface.

| | |
|----------------|--|
| Relevant Modes | ALL |
| Parameters | |
| <value> | 0 - Power comes ON only when the power button is pressed. 1 - Power comes ON automatically when either a charged battery or the DC adapter is inserted. |
| Examples | SYST: PWR: AUTO 1 |
| Query Syntax | Not Applicable |

Default Not Applicable

Last Modified:

7-May-2013 User Interface added (6.25)

1-Nov-2012 New command (A.06.06)

SYSTem:PWR:SHUTdown <value>

(Write-only) Turns the FieldFox OFF. You can use with [SYSTem:PWR:SHUTdown:DLY](#) and [SYSTem:PWR:SHUTdown:DURation](#).

Relevant Modes ALL

Parameters

<value> 1 - Reboots the FieldFox after the specified delay, and for the specified duration.
 0 - Immediately reboot.
 -1 Shuts down the FieldFox and do NOT reboot.

Examples **Shutdown after 5 seconds, for a duration of 3 seconds, then reboot**

```
SYST:PWR:SHUT:DLY 5
```

```
SYST:PWR:SHUT:DUR 3
```

```
SYST:PWR:SHUT 1
```

Query Syntax Not Applicable

Default Not Applicable

SYSTem:PWR:SHUTdown:DLY <value>

(Read-Write) Sets the time to delay before turning the FieldFox OFF.

Use [SYSTem:PWR:SHUTdown](#) to turn the FieldFox OFF.

Use [SYSTem:PWR:SHUTdown:DURation](#) to specify period of time before rebooting.

Relevant Modes ALL

Parameters

<value> Time (in seconds) to delay shutdown.

Examples **Reboot after 5 seconds, for a duration of 3 seconds:**

```
SYST:PWR:SHUT:DLY 5
```

```
SYST:PWR:SHUT:DUR 3
```

```
SYST:PWR:SHUT 1
```

Query Syntax SYSTem:PWR:SHUTdown:DLY?

Default 0 - Do NOT delay

SYSTem:PWR:SHUTdown:DURation <value>

(Read-Write) Sets the time to wait before rebooting the FieldFox.

Use [SYSTem:PWR:SHUTdown](#) to turn the FieldFox OFF.

Relevant Modes ALL

Parameters

<value> Time (in seconds) to wait before rebooting the FieldFox.

Examples **Reboot after 5 seconds, for a duration of 3 seconds:**

```
SYST:PWR:SHUT:DLY 5
```

```
SYST:PWR:SHUT:DUR 3
```

```
SYST:PWR:SHUT 1
```

Query Syntax SYSTem:PWR:SHUTdown:DURation?

Default -1 - Do NOT reboot after shutdown

SYSTem:PWR:SUSP <bool>

(Write-only) Puts the FieldFox into Standby mode. You can use with [SYSTem:PWR:SUSP:DLY](#) and [SYSTem:PWR:SUSP:DURation](#).

Relevant Modes ALL

Parameters

<bool> Choose 1 to put the FieldFox into Standby.

IMPORTANT: There is no SCPI command to recover from standby mode.

Examples **SYST:PWR:SUSP 1**

Query Syntax Not Applicable

Default Not Applicable

SYSTem:PWR:SUSP:DLY <value>

(Read-Write) Sets the time to delay before putting the FieldFox in Standby.

Use [SYSTem:PWR:SUSP](#) to put the FieldFox in Standby.

Use [SYSTem:PWR:SUSP:DURation](#) to cause the FieldFox to awaken after a specified period of time.

Relevant Modes ALL

Parameters

<value> Time (in seconds) to delay Standby.

Examples `SYST:PWR:SUSP:DLY 10`

Query Syntax `SYSTem:PWR:SUSP:DLY?`

Default 0 - Do NOT delay

SYSTem:PWR:SUSP:DURation <value>

(Read-Write) Sets the time to wait before awakening the FieldFox from Standby.

Use `SYSTem:PWR:SUSP` to put the FieldFox into Standby.

Relevant Modes ALL

Parameters

<value> Time (in seconds) to wait before awakening the FieldFox.

Examples `SYST:PWR:SUSP:DUR 10`

Query Syntax `SYSTem:PWR:SUSP:DURation?`

Default -1 Do NOT awaken after putting into standby.

SYSTem:UPReset:FPANel[:STATE] <bool>

(Read-Write) Set and query User Preset ON | OFF state.

Relevant Modes ALL Modes.

Parameters

<bool> Choose from:
OFF - User Preset OFF.
ON - User Preset ON.

Examples `SYST:UPR:FPAN 0`

Query Syntax `SYSTem:UPReset:FPANel[:STATE]?`

Return Type Boolean

Default OFF

Last modified:

1-Nov-2013 New command

SYSTem:UPReset:MODE

(Write-Only) Perform a User MODE Preset on the FieldFox. The settings for only the current mode are recalled from UserPreset.sta.

| | |
|----------------|----------------------|
| Relevant Modes | ALL |
| Examples | SYST:UPR:MODE |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

SYSTem:UPReset:SAVE

(Write-Only) Your FieldFox settings are saved to a standard State file (UserPreset.sta). However, unlike State files, calibration data is NOT saved.

| | |
|----------------|----------------------|
| Relevant Modes | ALL |
| Examples | SYST:UPR:SAVE |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

SYSTem:UPReset

(Write-Only) Perform a User Preset on the FieldFox. The entire UserPreset.sta file is recalled. ALL modes assume the settings that were in place when the User Preset was saved. The active mode is the mode that was visible when the file was saved.

| | |
|----------------|-----------------|
| Relevant Modes | ALL |
| Examples | SYST:UPR |
| Query Syntax | Not Applicable |
| Default | Not Applicable |

SYSTem:TIME <hr,min,sec>

(Read-Write) Set and query the current system time.

| | |
|----------------|--|
| Relevant Modes | ALL |
| Parameters | |
| <num> | Current time in hours (24 hr clock), minutes, seconds. |
| Examples | SYST:TIME 22,15,2 |
| Query Syntax | SYSTem:TIME? |
| Return Type | Comma-separated numeric |
| Default | Not Applicable |

SYSTem:TZONE <string>

(Read-Write) Set and query the current time zone setting.

Relevant Modes ALL Modes.

Parameters

<string> Use [SYSTem:TZONE:CATalog?](#) to read the valid time zone settings.

Examples **SYST:TZON "(GMT+10:00) Brisbane"**

Query Syntax SYSTem:TZONE?

Return Type String

Default "(GMT-08:00) Pacific Time (US & Canada)"

Last modified:

20-Jul-2010 New command (A.05.30)

SYSTem:TZONE:CATalog?

(Read-only) Query the list of valid time zone settings. Use [SYSTem:TZONE](#) to set and read the current time zone setting.

Relevant Modes ALL Modes.

Parameters None

Examples **SYST:TZON:CAT?**

Return Type Comma-separated strings

Default Not Applicable

Last modified:

20-Jul-2010 New command (A.05.30)

SYSTem:VERSion?

(Read-Write) Set and query the current version of the SCPI standard. For more information see: <http://www.ivifoundation.org/docs/scpi-99.pdf>

Relevant Modes ALL

Parameters None

Examples **SYST:VERS?**

Return Type String

Default Not Applicable

Last Modified:

16-Feb-2011

New command

SYSTem:VVS:CURRent?**(Read-only)** Query the amount of current draw in amperes.

Relevant Modes ALL Modes.
ALL models with Option 309 (Voltage Source)

Parameters None

Examples **SYST:VVS:CURR?**

Return Type Numeric

Default Not Applicable

Last Modified:

17-Jul-2012

New command

SYSTem:VVS:ENABLE <bool>**(Read-Write)** Set and query the voltage source state.

To clear a 'Tripped' condition, send SYSTem:VVS:ENABLE OFF, then SYSTem:VVS:ENABLE ON.

Query a tripped state using [SYSTem:VVS\[:STATe\]?](#)[See example program.](#)

Relevant Modes ALL Modes.
ALL models with Option 309 (Voltage Source)

Parameters

<bool> Voltage source state. Choose from:

- ON (or 1) - Voltage source enabled.
- OFF (or 0) - Voltage source disabled.

Examples **SYST:VVS:ENAB 1**

Query Syntax SYSTem:VVS:ENABLE?

Return Type Boolean

Default OFF

Last Modified:

23-Jul-2013 Added trip condition

17-Jul-2012 New command

SYSTem:VVS:MAXCurrent?

(Read-only) Query the maximum amount of current that can be drawn at the present voltage setting.

Relevant Modes ALL Modes.
ALL models with Option 309 (Voltage Source)

Parameters None

Examples **SYST:VVS:MAXC?**

Return Type Numeric

Default Not Applicable

Last Modified:

17-Jul-2012 New command

SYSTem:VVS:MVOLtage?

(Read-only) Query the present measured voltage.

Relevant Modes ALL Modes.
ALL models with Option 309 (Voltage Source)

Parameters None

Examples **SYST:VVS:MVOLtage?**

Return Type Numeric

Default Not Applicable

Last Modified:

17-Jul-2012 New command

SYSTem:VVS[:STATe]?

(Read-only) Query the present Voltage Source state.

Relevant Modes ALL Modes.
ALL models with Option 309 (Voltage Source)

| | |
|-------------|---|
| Parameters | None |
| Examples | SYST:VVS? |
| Return Type | Character - Returns one of the following: <ul style="list-style-type: none"> • ON - Voltage source enabled. • OFF - Voltage source disabled. • TRIPPED - The voltage source has drawn more current than the present capability. To clear a 'Tripped' condition, send SYSTem:VVS:ENABLE OFF, then SYSTem:VVS:ENABLE ON |
| Default | Not Applicable |

Last Modified:

| | |
|-------------|--------------------|
| 23-Jul-2013 | Added tripped note |
| 17-Jul-2012 | New command |

SYSTem:VVS:VOLTage <num>

(Read-Write) Set and query the output voltage.

| | |
|----------------|---|
| Relevant Modes | ALL Modes. ALL models with Option 309 (Voltage Source) |
|----------------|---|

Parameters

<num> Output voltage. Choose from 1.00 to 32.00 with .01 V resolution.

| | |
|----------|---------------------------|
| Examples | SYST:VVS:VOLT 5.05 |
|----------|---------------------------|

| | |
|--------------|---------------------|
| Query Syntax | SYSTem:VVS:VOLTage? |
|--------------|---------------------|

| | |
|-------------|---------|
| Return Type | Numeric |
|-------------|---------|

| | |
|---------|------|
| Default | 1.00 |
|---------|------|

Last Modified:

| | |
|-------------|-------------|
| 17-Jul-2012 | New command |
|-------------|-------------|

TRACe<n>:DATA? <char>

(Read-Only) Returns the current data trace values. If correction is ON, then the returned data is corrected.

- Set Units with [\[:SENSe\]:AMPLitude:UNIT](#).
- Set data format with [FORMat\[:DATA\]](#)

Relevant Modes SA
 VVM
 For [CAT mode](#) and [NA mode](#), use **CALCulate:DATA:<type>** commands.

Parameters

<n> Trace number of data to be returned. SA Only. Choose from 1 through 4.
 If unspecified, <n> is set to 1.

<char> **Note:** This parameter is NOT allowed for SA mode.
 Type of data to return. Choose from:
FDATA - Data in the current display format.
SDATA - Raw (non-formatted) complex data.
 VVM Mode always returns two data points: Mag and Phase.

Examples **TRACE:DATA? FDATA 'VVM mode**
TRAC2:DATA? 'SA mode

Return Type Comma-separated numeric

Default Not Applicable

Last modified:

28-Oct-2011 Added link to format:data

:TRACe<n>:TYPE <char>

(Read-Write) Set and query the type of SA Mode trace display state.
 Use [\[:SENSe\]:QUANtity:TACTive?](#) to read the number of active traces.

Relevant Modes SA

Parameters

<n> Trace number for which display state is to be set or queried. Choose from 1 through 4.

<char> Trace type. Choose from:
CLRw - Clear/Write
BLANk - Blank
MAXH - Max Hold
MINH - Min Hold
AVG - Average
VIEW - View

Examples **TRAC1:TYPE VIEW**

Query Syntax :TRACe<n>:TYPE?

Return Type Character

Default CLRW

TRIGger:DElay <num>

(Write-Read) Set and query the trigger delay time.

Relevant Modes [Pulse Measurements](#)

Parameters

<num> Trigger delay time in seconds. Choose a value between -10 to +10.

Examples **TRIG:DEL 5e-6**

Query Syntax TRIGger:DElay?

Default 0

Last Modified:

29-Oct-2013

New command

TRIGger:LEVel:AUTO <bool>

(Write-Read) Set and query whether the trigger level is set manually or is set to the default level in the USB Power Sensor.

Relevant Modes [Pulse Measurements](#)

Parameters

<bool> Choose from:
 ON or 1 - Trigger level is determined by the USB Power Sensor firmware.
 OFF or 0 - Trigger level is set manually using [TRIGger:LEVel](#).

Examples **TRIG:LEV 5e-6**

Query Syntax TRIGger:LEVel?

Default -15

Last Modified:

29-Oct-2013

New command

TRIGger:LEVel <num>

(Write-Read) Set and query the power level at which the USB power sensor is triggered when `TRIGger:LEVel:AUTO = OFF`.

Relevant Modes [Pulse Measurements](#)

Parameters

<num> Trigger level in dBm.

Examples **TRIG:LEV 5e-6**

Query Syntax TRIGger:LEVel?

Default -15

Last Modified:

29-Oct-2013 New command

:TRIGger[:SEQuence]:ATRigger <num>

(Read-Write) Set and query the auto-trigger time. If a trigger signal is not received before the specified auto trigger time, a sweep will occur automatically.

Relevant Modes SA

Parameters

<num> Auto trigger time in seconds. Choose a value between 0 and 65 seconds.
Enter 0 to set Auto Trigger OFF. When Auto Trigger is OFF, the FieldFox does NOT sweep unless a valid trigger signal is received.

Examples **TRIG:ATR 2**

Query Syntax TRIGger[:SEQuence]:ATRigger?

Return Type Numeric

Default 1

Last Modified:

6-Mar-2013 Modified for 6.25

:TRIGger[:SEQuence]:ATRigger:STATe <bool>

(Read-Write) Set and query the auto-triggering state.

Relevant Modes SA

Parameters

<bool> Auto trigger state. Choose from:
OFF or **0** - Auto Trigger OFF. The FieldFox does NOT sweep unless a valid trigger signal is received.
ON or **1** - Auto Trigger ON. If a trigger signal is not received before the specified Auto Trig Time ([TRIGger\[:SEquence\]:ATRigger](#)), a sweep will occur automatically.

Examples **TRIG:ATR:STAT 1**

Query Syntax TRIGger[:SEquence]:ATRigger:STATE?

Return Type Boolean

Default OFF (0)

Last Modified:

6-Mar-2013 Modified for 6.25

:TRIGger[:SEquence]:DELay <num>

(*Read-Write*) Set and query the trigger delay time. After a valid trigger signal is received, the sweep begins after the specified Trigger Delay time. Enable Trigger delay using [:TRIGger\[:SEquence\]:DELay:STATE](#)

Relevant Modes SA

Parameters

<num> Trigger delay time in seconds. Choose a value between 0 and 65 seconds.

Examples **TRIG:DEL 2**

Query Syntax TRIGger[:SEquence]:DELay?

Return Type Numeric

Default 0

Last Modified:

6-Mar-2013 Modified for 6.25

:TRIGger[:SEquence]:DELay:STATE <bool>

(*Read-Write*) Set and query the trigger delay state. Set delay time using [:TRIGger\[:SEquence\]:DELay](#)

Relevant Modes SA

Parameters

<bool> Trigger delay state. Choose from:
OFF or **0** - Trigger delay OFF.

ON or 1 - Auto Trigger ON.

Examples `TRIG:DEL:STAT 1`

Query Syntax TRIGger[:SEquence]:DElay:STATe?

Return Type Boolean

Default OFF (0)

Last Modified:

6-Mar-2013

Modified for 6.25

TRIGger[:SEquence]:FGATe:DElay <num>

(Read-Write) Set and query the trigger delay time. This effectively moves the gating area left (negative delay) or right (positive delay) within the gating window.

[See all FFT Gating commands.](#)

Relevant Modes SA

Parameters

<num> Trigger delay time in seconds.

Examples `TRIG:DEL 2`

Query Syntax TRIGger[:SEquence]:DElay?

Return Type Numeric

Default 0

Last Modified:

28-Mar-2013

New command (6.25)

TRIGger[:SEquence]:FGATe[:STATe]

(Read-Write) Set and query the FFT Gating On/Off state.

[See all FFT Gating commands.](#)

Relevant Modes SA

Parameters

<bool> FFT Gating state. Choose from:
 OFF or 0 - FFT Gating OFF.
 ON or 1 - FFT Gating ON.

Examples `TRIG:FGAT 1`

Query Syntax TRIGger[:SEQuence]:FGATe[:STATe]?

Return Type Boolean

Default OFF (0)

Last Modified:

6-Mar-2013 Modified for 6.25

TRIGger[:SEQuence]:FGATe:VIEW[:STATe] <bool>

Not finished

(*Read-Write*) Set and query the display of the FT Gating window. When ON, a time domain window is displayed below the frequency domain window.

[See all FFT Gating commands.](#)

Relevant Modes SA

Parameters

<num> Choose from:
 ON (or 1) - Gate window ON
 OFF (or 0) - Gate window OFF

Examples **TRIG:FGAT:VIEW 1**

Query Syntax TRIGger[:SEQuence]:FGATe:VIEW[:STATe]?

Return Type Boolean

Default OFF (or 0)

Last Modified:

28-Mar-2013 New command (6.25)

TRIGger[:SEQuence]:FGATe:VIEW:TIME <num>

Not finished

(*Read-Write*) Set and query the X-axis time span for the time domain window.

[See all FFT Gating commands.](#)

Relevant Modes SA

Parameters

<num> FFT gating view time in seconds. Choose a value between seconds.

Examples **TRIG:FGAT:VIEW:TIME 2**

Query Syntax TRIGger[:SEQuence]:FGATe:VIEW:TIME?
Return Type Numeric
Default 1.5e-3

Last Modified:

28-Mar-2013 New command (6.25)

TRIGger[:SEQuence]:FGATe:WIDTh <num>

Not finished

(Read-Write) Set and query the width of the gating area within the time domain window. The gating area is indicated by two vertical green lines.

[See all FFT Gating commands.](#)

Relevant Modes SA

Parameters

<num> Choose a value between 0 and 65 seconds.

Examples **TRIG:FGAT:WIDT 2**

Query Syntax TRIGger[:SEQuence]:FGATe:WIDTh?

Return Type Numeric

Default 1e-3

Last Modified:

28-Mar-2013 New command (6.25)

TRIGger[:SEQuence]:POSition <num>

(Read-Write) Set and query the trigger position. Available ONLY in Zerospan measurements.

This is an easy way to automatically set the Trigger Delay by positioning the trigger event (also known as T zero) at any graticule along the X-axis.

Also set [TRIGger\[:SEQuence\]:POSition:STATe](#)

Relevant Modes SA

Parameters

<num> Trigger position. Choose a value from 0 to 10:
 0 - T zero occurs at the left graticule.
 5 - T zero occurs at the center of the screen.

10 - T zero occurs at the far right graticule.

Examples `TRIG:POS 5`

Query Syntax `TRIGger[:SEQuence]:POSition?`

Return Type Numeric

Default 0

Last Modified:

28-Mar-2013 New command (6.25)

:TRIGger[:SEQuence]:POSition:STATe <bool>

(Read-Write) Set and query the trigger position state. Set trigger position using [TRIGger\[:SEQuence\]:POSition](#).

Relevant Modes SA

Parameters

<bool> Trigger position state. Choose from:
OFF or **0** - Trigger position OFF.
ON or **1** - Trigger position ON. [TRIGger\[:SEQuence\]:DELay](#) is set automatically and can NOT be overwritten.

Examples `TRIG:POS:STAT 1`

Query Syntax `TRIGger[:SEQuence]:POSition:STATe?`

Return Type Boolean

Default OFF (0)

Last Modified:

4-May-2016 New command

:TRIGger[:SEQuence]:SLOPe <char>

(Read-Write) Set and query the trigger slope. Trigger Slope determines which edge of a trigger signal initiates a sweep.

Relevant Modes SA

Parameters

<char> Trigger slope. Choose from:
POS - Sweep is triggered by the rising (positive) edge of signal.

NEG - Sweep is triggered by the falling (negative) edge of signal.

Examples `TRIG:SLOP NEG`

Query Syntax `TRIGger[:SEQuence]:SLOPe?`

Return Type Character

Default POS

Last Modified:

28-Mar-2013 Modified for 6.25

:TRIGger[:SEQuence]:SOURce <char>

(Read-Write) Set and query the source of FieldFox trigger signals.

Relevant Modes SA

Parameters

<char> Trigger slope. Choose from:

FREE - (Free run) Triggering is provided by the FieldFox internal circuitry. A new sweep begins when the previous sweep ends.

EXT - (External) A sweep is triggered on an external TTL signal at the External Trigger connector. External trigger is available only after first setting BNC Connector Use to Trigger.

VID - (Video) Available in Zerospan and FFT sweeps. A sweep is triggered on a signal at the SA RF Input connector when the amplitude of the incoming signal exceeds the settable Trigger Level.

RFB - (RF Burst) Available in Zerospan and FFT sweeps. Similar to Video triggering, a sweep is triggered from a signal at the SA RF Input connector. However, an RF Burst trigger is detected in the third IF stage. A sweep is triggered when the amplitude of the incoming signal exceeds the settable Trigger Level.

See Also

[TRIGger\[:SEQuence\]:VIDeo:LEVel](#)

Examples `TRIG:SOUR EXT`

Query Syntax `TRIGger[:SEQuence]:SOURce?`

Return Type Character

Default FREE

Last Modified:

28-Mar-2013

Added RF Burst (6.25)

:TRIGger[:SEQuence]:VIDeo:LEVel <num>

(Read-Write) Set and query the level at which a video or RF Burst trigger will occur. An incoming signal with this amplitude will initiate a sweep.

Relevant Modes SA

Parameters

<num> Trigger level. The Units depend on the Scale Type setting: (dB for Log and mV for Linear). Set with [\[:SENSe\]:AMPLitude:SCALE](#).

Examples **TRIG:VID:LEV -30**

Query Syntax TRIGger[:SEQuence]:VIDeo:LEVel?

Return Type Numeric

Default - 20 dBm (Log)
22.361 mv (Lin)

Last Modified:

28-Mar-2013

Modified for 6.25

TRIGger:SLOPe <char>

(Read-Write) Set and query the polarity of a valid external trigger signal.

Relevant Modes [NA](#), [Pulse Measurements](#)

Parameters

<char> Choose from:
POSitive - Sweep is triggered by the rising (positive) edge of signal at about 1.7 V.
NEGative - Sweep is triggered by the falling (negative) edge of signal at about 1.0 V.

Examples **TRIG:SLOP POS**

Query Syntax TRIGger:SLOPe?

Return Type Character

Default POSitive

Last Modified:

31-Oct-2013 Added Pulse
 6-Mar-2013 New command (6.25)

TRIGger:SOURce <char>

(Read-Write) Set and query the source of trigger signals which initiate a measurement. See [Trigger:Source command](#) for Pulsed Measurements Mode.

Relevant Modes NA,

Parameters

<char> Choose from:
INTernal - Sweeps are initiated by the FieldFox internal circuitry.
EXTernal - A sweep is initiated on the rising or falling edge of an external TTL signal at the Ref In/Trig In connector on the FieldFox top panel.

Examples **TRIG:SOUR EXT**

Query Syntax TRIGger:SOURce?

Return Type Character

Default INTernal

Last Modified:

6-Mar-2013 New command (6.25)

TRIGger:SOURce <char>

(Read-Write) Set and query the source of trigger signals which initiate a measurement. See [Trigger:Source command](#) for NA Mode.

Relevant Modes [Pulse Measurements](#)

Parameters

<char> Choose from:
FREerun - The USB Power Sensor acquires data without waiting for a trigger. This mode is NOT supported for Trace Graph measurements.
INTernal - The USB Power Sensor acquires data when a valid pulse signal is detected at the RF input. The following Trigger settings determine the validity of the trigger signal.
EXTernal - The USB Power Sensor acquires data when a valid TTL signal is detected at the USB Power Sensor external trigger input.

Examples **TRIG:SOU EXT**

Query Syntax TRIGger:SOUrce?

Return Type Character

Default INTernal

Last Modified:

30-May-2014

New command

UNIT:POWer <string>

(Read-Write) Set and query the units to display in Power Meter mode.

Relevant Modes Power Meter

Parameters

<string> Choose from:
 "W" (Watts)
 "DBM"

Examples **UNIT:POW "W"**

Query Syntax UNIT:POWer?

Return Type String

Default DBM